

Ford

THE UNIVERSAL CAR

Price List of Parts

MODEL T

Effective December 20th, 1922

Ford Motor Company

DETROIT, MICHIGAN

1925.
7.50

December 20th, 1922

Prices subject to change without notice

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

IMPORTANT

INSIST on getting **GENUINE** Ford Parts when your Ford car needs repairing. Don't allow "bogus" or imitation Parts to go in your car.

Parts Price List Index

	Page
Ammeter.....	25
Axle—Front.....	7
Axle—Rear.....	4
Battery Bracket and Parts.....	27
Bendix Drive.....	25
Body Parts.....	17
Carburetor.....	21
Carburetor Attachments.....	22
Carburetor Parts.....	19
Coil and Parts—Spark.....	25
Commutator.....	13
Cotter Pins.....	29
Cut-outs.....	25
Fan.....	19
Fenders.....	22
Frame.....	8
Gasoline Tank.....	8
Generator and Parts.....	27
Hood.....	19
Horn.....	29
Lamps.....	31
Magneto.....	13
Motor.....	9
Muffler.....	19
Radiator—Thermo Syphon.....	18
Running Boards and Shields.....	23
Spark Plugs.....	28
Springs.....	17
Starter Parts.....	27
Starting Crank.....	18
Steering Gear.....	15
Switch.....	25
Tools.....	29
Tops.....	32
Transmission.....	13
Transmission Control.....	14
Transmission Cover.....	14
Truck Parts.....	35
Wheels.....	7
Windshields.....	31
Wiring.....	25

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*
Ford Factory, Ford, Ontario, Canada
Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Buffalo	Columbus	Houston	Louisville	Omaha	San Francisco
Cambridge	Dallas	Indianapolis	Memphis	Philadelphia	Seattle
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Washington
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	
Cincinnati	Detroit	Kearny, N. J.	New Orleans	St. Louis	

FOREIGN BRANCHES, ASSOCIATED COMPANIES AND SERVICE STATIONS

Antwerp, Belgium	Copenhagen, Denmark	Montevideo, Uruguay	St. John, N. B.
Bordeaux, France	London, Eng.	Montreal, Que.	Toronto, Ont.
Buenos Aires, Argentina	London, Ontario	Regina, Sask.	Vancouver, B. C.
Cadiz, Spain	Manchester, Eng.	Sao Paulo, Brazil	Winnipeg, Manitoba
Calgary, Alta.			

There are Ford Dealers in all Principal Cities

Instructions for Ordering Parts

- 1—Order all parts through the nearest Branch or Dealer.
- 2—Always give **Catalog Number and Name** of each part ordered.
- 3—Mail and Parcel Post orders must be accompanied by an amount sufficient to cover **Postage**.
- 4—All prices are net f. o. b. **Branch, Factory or Dealer**.
- 5—Specify how shipments are to be made.
- 6—Orders for parts should be written **separately** from correspondence pertaining to other matters.

Telegraph Code

To save expense, to expedite ordering and for your convenience, we have arranged a code word for each part of the Ford Model T car. In addition, we list below a brief General Code covering miscellaneous instructions, questions and answers relative to the shipment of parts.

Toperig—Ship to me (us) by express.

Toperkleur—Ship by express to _____

Topersteen—Ship to me (us) by freight.

Toper—Ship to me (us) by parcel post.

Topfton—When and how did you ship parts called for in my (our) telegram of _____

Topflutch—When and how will you ship parts called for in my (our) telegram of _____

Topfwasser—When and how will you ship parts called for in my (our) letter of _____

PRICE LIST OF PARTS

FORD MODEL T 1909-1922



EFFECTIVE DECEMBER 20th, 1922

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
REAR AXLE									
2500	Rear axle assembly	1909-22		\$60 00	MH.	Aband	95E	1	
2501	Axle housing—right	1915-22		8 00	MH.	Abolve	7635C	1	
2502	Axle housing—left	1915-22		8 00	MH.	Absume	7636C	1	
2503E	Axle housing bolt	1913-22	$\frac{1}{2}$ " x $1\frac{1}{8}$ "	03		Ajoy	2854	7	
2503F	Axle housing bolt nut	1909-22		02		Doric	44	7	
2504	Rear axle case gasket	1919-22		03		Abraun	139	1	
2505	Axle shaft	1912-22		1 50	MH.	Abode	2818	2	
2506	Axle shaft washer	1909-22	$1\frac{1}{8}$ " dia. fibre	03		Abound	39	1	
2508	Axle shaft roller bearing	1909-22	$2\frac{1}{4}$ " x 4"	1 00		Abraze	253	4	
2509	Axle shaft R. B. sleeve—R.	1909-22	4" long.	20		Abay	170	2	
2509B	Axle shaft R. B. sleeve—L.	1909-22		20		Abate	161	2	
2510	Axle housing cap	1909-19	$2\frac{1}{4}$ " dia.	05		Abroad	56	2	
2510 $\frac{1}{2}$	Axle housing cap	1919-22		05		Abridge	56B	2	
2510A	Axle outer R. B. steel washer	1909-22	$2\frac{1}{4}$ " dia.	02		Absinthe	199B	2	
2510B	Axle outer R. B. felt washer	1909-22	$2\frac{1}{8}$ " dia.	05		Absist	54	2	
2512C	Diff. case—left	1914-22		1 40	MH.	Abut	84	1	
2513C	Diff. case—right	1914-22		90	MH.	Ache	81	1	
2514B	Diff. case stud	1915-22	$\frac{3}{8}$ " x $2\frac{1}{4}$ "	05		Ale	2865	3	
2514C	Diff. case bolt	1922		05		Algot	52C	3	
2515	Diff. case stud nut	1909-22		03		Egret	8	5	
2518	Diff. drive gear	1909-22	40 teeth	3 00	MH.	Accost	12B	1	
2519	Diff. drive gear screw	1909-22	$\frac{7}{8}$ " x $\frac{1}{2}$ "	03		Accoy	103	10	
2519A	Diff. gear lock ring	1909-22		02		Acetic	118	2	
2520B	Diff. gear	1909-22	24 teeth	1 00	MH.	Ace	13B	2	
2521B	Diff. gear key	1911-22	$1\frac{3}{8}$ " long.	05		Acrid	137	2	
2524C	Diff. pinion	1915-22	12 teeth	35	MH.	Admire	14D	3	
2526B	Diff. spider	1909-22		80	MH.	Adduce	15D	1	
2528	Diff. thrust washer	1909-22	$3\frac{3}{4}$ " dia. metal	15		Adleu	30	2	
2529	Diff. thrust plate	1909-22	$3\frac{3}{4}$ " dia. steel	15	MH.	Adjoin	31	4	
2531B	Diff. thrust plate pin	1917-22		02		Age	7640	6	
2532	Diff. housing oil plug	1909-22	$\frac{3}{4}$ " x 24 thds.	05		Agger	817	1	
2545	Rear axle grease cup	1909-22		10		Ajar	76	1	
2547	Rear radius rod—R.	1909-22		1 60	MH.	Altar	152	1	
2547B	Rear radius rod—L.	1909-22		1 60	MH.	Altaic	158	1	
2548	Radius rod nut	1909-22	$\frac{1}{2}$ " x 18 thds.	05		Amass	77	2	
2549	Radius rod lock nut	1909-22	$\frac{1}{2}$ " x 18 thds.	05		Amber	78	2	
2550	Radius rod lock washer	1909-22	$\frac{1}{2}$ " x 18 thds.	02		Ambush	2823	2	
2551	Radius rod bolt	1909-22	$\frac{1}{2}$ " x $1\frac{1}{2}$ "	05		Amplite	83	4	
2551B	Radius rod bolt nut	1909-22		13		Armor	60	4	
2557	Hub cam shaft—right	1909-22	$3\frac{1}{8}$ " long.	05		Amuck	92B	1	
2558	Hub cam shaft—left	1909-22	$3\frac{1}{8}$ " long.	15		Anchor	61B	1	
2559	Hub cam shaft bushing	1909-22	$\frac{1}{2}$ " bore, $\frac{1}{2}$ " dia.	05		Ancient	173	2	
2562	Cam shaft lever	1909-22	$\frac{1}{2}$ " bore	10		Arab	62	2	
2563	Cam shaft lever pin	1909-22	$\frac{1}{8}$ " x $\frac{1}{8}$ "	02		Arbor	7	4	
2564	Lever clevis pin	1909-22	$\frac{1}{8}$ " x 1"	03		Arcade	65	4	
2566	Hub brake shoe	1909-22	Cast iron.	40	MH.	Arctic	2814	2	
2567	Brake shoe support bolt	1909-22	$\frac{1}{2}$ " x $1\frac{1}{8}$ "	05		Argus	59	2	
2568	Brake shoe support nut	1909-22	Order 2551B						
2570B	Brake shoe coil spring	1913-22	$3\frac{3}{8}$ " long.	03		Asug	2862	4	
2571	UNIVERSAL JOINT ASSEMBLY	1909-22		1 50		Ashore	151B	1	
2572	Joint knuckle (male)	1909-22		50		Ashust	45B	1	
2573	Joint knuckle (female)	1909-22		60		Askev	46B	1	
2574	Joint knuckle pin	1909-22	$\frac{1}{2}$ " x $1\frac{1}{2}$ "	02		Asleep	6	1	
2575	Joint ring, complete	1909-22	$3\frac{1}{8}$ " dia.	05		Astert	49B	1	
2576	Joint ring rivets (per set 4)	1909-22	$\frac{1}{4}$ " x $1\frac{1}{8}$ "	05		Arche	50	4	
2577B	Univ. joint housing	1914-22		1 25		Atoll	7609	1	
2578	Joint housing plug	1909-22	$\frac{1}{2}$ " x 20 thds.	05		Atom	75	2	
2579	Ball joint grease cup	1909-22	$\frac{1}{4}$ " pipe thds.	15		Attic	195	1	
2580	Ball cap gasket	1909-22		05		Auburn	1518	1	
2581	Drive shaft housing front bushing	1909-22	Babbitt	30		Balkish	69	1	
2582	D. S. tubing	1911-22		7 00	MH.	Ballad	153B	1	
2583B	D. S. bearing housing	1920-22	Forging	1 40	MH.	Ballace	191C	1	
2584B	D. S. R. B. cap screw	1912-22	$\frac{1}{4}$ " x $4\frac{3}{8}$ "	05		Balneal	183B	6	
2584C	D. S. R. B. stud nut	1912-22		05		Feast	184R	6	
2584D	D. S. R. B. cap screw lock washer	1912-22		05		Balneary	157	6	
2586	D. S. R. B. housing set screw	1911-22	$\frac{1}{4}$ " x 20 thds.	05		Banco	101R	1	
2587	D. S. roller bearing	1911-22	$2\frac{3}{8}$ " long.	1 10		Baisam	108	1	
2588	D. S. R. B. distance plate	1911-21	$2\frac{1}{2}$ " dia.	05	MH.	Bandlet	106R	1	
2589	D. S. ball race	1911-21	$2\frac{3}{8}$ " dia.	25		Bandon	186R	1	
2589B	D. S. ball bearing assy.	1911-21		1 00		Bander	185AR	1	

††When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts



2510

2510-B

2508

2509




2512-C

2513-C

2518

2520-B



2524-C

2526-B

2528

2529

2532

2545



2547




2557-R

2558-L

2566

2570-B



2571

2572

2573


2575

2579

2577-B

2578



2580



2582



2583-B



2584-B

2586

2587

2589

2589-B

2590



2591

2591-B

2593

2596

2597-B

3368



2595-B



3468-R

3469-L



3470-R

3471-L




Plate No. 2

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Req. per Car
REAR AXLE—Continued								
2590	D. S. ball retainer	1911-21	2 1/4" dia.	\$ 0 03		Bandroe	190AR	1
2591	D. S. ball thrust collar	1911-22	2 1/4" dia.	25		Bandaunt	188A	2
2591B	D. S. thrust ball and retainer assembly	1920-22		25		Bandala	162	1
2592	D. S. ball bearings	1911-22	Order 2811					
2593	D. S. R. B. sleeve	1911-21	2 3/8" dia., 2 3/4" long.	1 50		Bangle	107R	1
2595B	D. S. only	1911-22	1 3/8" x 5 3/4"	3 00	MH	Banjo	87D	1
2596	D. S. sleeve	1911-22	1" bore, 3 1/8" long.	80		Banshee	163B	1
2597B	D. S. pinion	1911-22	Standard, 11 teeth.	1 00	MH	Banewort	16C	1
2597C	D. S. pinion	1911-22	Low gear, 10 teeth.	1 00	MH	Banneret	16D	1
2598	D. S. castle nut	1911-22	3/8" x 18 thds.	05		Banket	124	1
2598B	D. S. pinion key	1911-22		05		Banker	57B	1
FRONT AXLE								
2691	Front axle only	1909-22	56" tread	9 00	MH	Barber	202B	1
2694B	Spindle body—right	1911-22	Less cones and washer.	1 50	MH	Barblcan	280	1
2695B	Spindle body—left	1911-22	Less cones and washer.	1 50	MH	Barbiton	281	1
2696	Spindle arm—right or left	1911-19		50	MH	Bardism	7716	2
2696C	Spindle arm—right	1919-22		45	MH	Barm	7715B	1
2696D	Spindle arm—left	1911-22		45	MH	Barry	7716B	1
2697	Spindle arm nut	1911-22	Order 2548					
2704	Stationary cone	1909-22	1 1/8" bore	15		Barkless	205A	2
2705	Adj. cone—right thread	1909-22	3/8" x 16 thds.	15		Barley	206A	1
2706	Adj. cone—left thread	1909-22	3/8" x 16 thds.	15		Barrack	207A	1
2707	Spindle nut—right thread	1909-22	3/8" x 16	10		Barrow	209B	1
2708	Spindle nut—left thread	1909-22	3/8" x 16	10		Baron	208B	1
2709	Spindle washer	1909-22	3/8" hole x 1 3/8"	02		Barras	210	2
2710	Spindle bolt with oiler	1910-22	1/2" x 6 3/4"	20		Barter	7708	2
2711	Spindle bolt nut	1909-22	Order 2551B					
2713	Spindle body bush (pair)	1909-22	1/2" bore.	20		Bartram	223	2
2714	Spindle arm bushing	1909-22	1/8" bore, 1 1/4" dia., 1" L.	05		Barwood	225	2
2715C	Spindle oiler	1909-18	Order 3846					
2715D	Spindle oiler	1919-22	Order 3176C					
2717	Spindle con. rod	1909-22	46 3/4" long.	2 00	MH	Basalt	264	1
2718	Spindle con. rod bolt with oiler	1909-22	1 1/8" x 2 1/4"	15		Basan	7706	2
2719	Spindle con. rod bolt nut	1909-22	1 1/8" x 20 thds.	03		Bashful	220	2
2721	Spindle con. rod yoke	1909-18	2 3/4" long.	40		Bashule	248	1
2721C	Spindle con. rod yoke ball	1919-22		20		Baroko	226	1
†2721C	Spindle con. rod yoke	1919-22		50		Barse	248B	1
2722	Steering yoke clamp bolt and nut	1909-18	Order 3362 and 2515					
2725B	Steering gear con. rod	1909-22	Includes ball sockets.	80	MH	Baslard	289	1
2728	Ball socket cap	1909-22		10		Basent	254B	2
2729B	Ball socket bolt and nut	1909-22	Order 3362 & 2515.					
2733	Front radius rod	1909-19		2 00	MH	Beardless	263A	1
2733B	Front radius rod	1919-22		1 75	MH	Bedazzle	263B	1
2734	Front radius rod nut	1909-19	Order 2548					
2736	Front radius rod ball cap	1909-22		12		Beaufet	217	1
2737	Front radius rod ball socket	1911-22		20		Beckon	809B	1
2741	Radius rod ball cap stud	1911-22		03		Plateau	4365	2
2741B	Radius rod ball cap stud nut	1911-22	Order 2515					
2742	Radius rod ball cap spr'g	1911-22		03		Bicip	292	2
WHEELS								
2800	Front wheel—clincher	1909-22	30" x 3"	6 75		Becomb	291B	2
2800B	Front wheel—dem.	1919-22	Less rim & brgs., Kelsey	7 25		Barytom	291D	2
2800C	Front wheel—dem.	1919-22	Less rim & brgs., Hayes	7 25		Basanite	291E	2
2800D	Front wheel—clincher—less hub	1909-22		4 50		Basaltine	295AR	2
2800E	Front and rear wheel—dem.—less rim & hub	1919-22	Kelsey	4 75		Basilisk	293AR	4
2800F	Front and rear wheel—dem.—less rim & hub	1919-22	Hayes	4 75		Bascinet	293BR	2
2800G	Front wheel—dem.	1919-22	Less rim & brgs.—Ford	7 25	MH	Basquish	291G	2
2800H	Front and rear wheel—dem.—less rim & hub	1919-22	Ford	4 75	MH	Bassetto	293CR	4
2801	Front wheel comp. R or L—demountable	1919-22	Rim and R. B. Cups included, Kelsey	9 75		Bereave	7697A	2
2801B	Front wheel comp. R or L—demountable	1919-22	Rim and R. B. Cups included, Hayes	9 75		Beseech	7697B	2
2801C	Front wheel comp. R or L—demountable	1919-22	Rim and R. B. Cups included, Ford	9 75	MH	Beatify	7697C	2
2803	Front hub assembly	1909-22	With ball brgs.	1 80		Bedew	200	2
2803B	Front hub with R B cups	1909-22		2 00		Bedouin	219	2
2804	Outer race	1909-22	1 1/8" dia.	10		Bedferre	234	2
2805	Inner race	1909-22	2 1/8"	15		Bedight	235	2

†When substituting 2721C for old style yoke, also order 2721B Ball.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Req. per Car
WHEELS—Continued								
2806	Outer ball retainer	1909-22	1 3/4" dia.	\$ 0 02		Bedim	236	2
2807	Inner ball retainer	1909-22	2 1/4" dia.	03		Beside.	237	2
2808	Dust ring	1909-22	Steel, 2 1/4" dia.	05		Bedward	238	2
2809	Front and rear hub felt washer	1909-22	2 1/2" dia.	05		Bedije	239	4
2810	Large balls, each	1909-22	1/2"	04		Beefing	241	24
2811	Small balls, each	1909-22	3/8"	03		Beemol	249	22
2814C	Rear wheel—clincher	1912-22	30" x 3 1/2"	7 25		Beggah	2815	2
2814D	Rear wheel—clincher—less hub	1909-22		5 00		Basifier	2816	2
2814E	Rear wheel comp.—dem.	1919-22	Kelsey	9 50		Begin	7698A	2
2814F	Rear wheel comp.—dem.	1919-22	Hayes	9 50		Behoney	7698B	2
2814G	Rear wheel—dem.	1919-22	Less rim, Kelsey	7 00		Bashless	2815B	2
2814H	Rear wheel—dem.	1919-22	Less rim, Hayes	7 00		Basketry	2815C	2
2814J	Rear wheel comp.—dem.	1919-22	Ford	9 50	MH	Bedagat	7698C	2
2814K	Rear wheel—dem.	1919-22	Less rim—Ford	7 00	MH	Bedaggle	2815E	2
2815C	REAR HUB	1912-22		1 40	MH	Begol	2819	2
2816B	Rear hub key	1909-22	3/4" x 1/4" x 2 1/4"	03		Begloom	2863	2
2818	Rear hub brake drum	1909-22	3" hole, 8" dia.	40		Beguiler	3B	2
2819	Rear hub cap	1909-22	2 1/2" x 2 1/2" thds.	15		Behave	7727	4
2825	Rear hub bolt	1911-22	3/8" x 2 1/8" x 16 thds.	03		Belay	28B	24
2825B	Hub bolt nut	1911-22		03		Elk	29	24
2826	Front hub bolt	1911-22		03		Belgian	27	12
2827	Hub flange	1911-22	6" dia.	20		Below	233B	4
2828	Rear hub lock nut	1912-22	3/8" x 18 thds.	05		Bengal	242	2
2833	Front hub bearing cup—inner	1919-22		50		Benip	2955	2
2834	Inside cone and roller assembly	1919-22		1 10		Bent	205B	2
2836	Front hub bearing cup—outer	1919-22		40		Bepad	2956	2
2937	Outside cone and roller assy.—right thread	1919-22		75		Beplay	206B	1
2838	Outside cone and roller assy.—left thread	1919-22		75		Beplume	207B	1
2841	Front hub dust cap assy.	1919-22		10		Besunk	350	2
2845	Demountable rim only	1919-22	Kelsey	1 80		Bethrone	8774A	4
2845B	Demountable rim only	1919-22	Hayes	1 80		Bejape	8774B	4
2845C	Demountable rim only	1919-22	Ford	1 80		Bedrench	8774C	4
2846B	Demountable rim clamp	1919-22	Kelsey	10		Betor	8831B	16
2846C	Demountable rim clamp and nut assembly	1922	Ford	10		Betuline	8807	16
2847	Demountable rim bolt	1919-22		05		Bewax	8832A	16
2847B	Demountable rim bolt	1922	Ford	05		Bewreke	8832B	16
2848	Dem. rim bolt nut	1919-22	Hayes	05		Benison	8834B	16
2848B	Dem. rim bolt nut	1919-22	Kelsey	05		Belabor	8834A	16
2849	Spare rim carrier	1919-22		2 00	MH	Belamy	8848C	1
2849C	Spare rim carrier clamp support and bolt assy.	1921-22		15		Belvra	7511	1
2849D	Spare rim carrier clamp	1919-22		05		Benedict	7312C	1
2849E	Spare rim carrier clamp support bolt	1921-22		03		Benegro	7509B	1
2870	Spare rim carrier brkt.—R.	1919-22		50		Belate	8824AR	1
2870B	Spare rim carrier brkt.—R.	1922		50		Belle	8824B	1
2871	Spare rim carrier brkt.—L.	1919-22		50		Bellite	8825AR	1
2871B	Spare rim carrier brkt.—L.	1922		50		Bellch	8825B	1

FRAME

2850	Frame assembly	1909-22		13 00	MH	Belone	2916	1
2851B	Side member—right	1914-22		4 00		Benign	2914	1
2852B	Side member—left	1914-22		4 00		Berdash	2915	1
2853	Front cross member	1909-22	22 3/4" long	90		Beluga	303	1
2854B	Rear cross member	1914-22		1 20		Bendlet	2913	1
2855	Front corner bracket—R	1909-22		15		Benumb	305	1
2856	Front corner bracket—L	1909-22		15		Bequest	306	1
2857	Rear corner bracket—R	1909-22		15		Beslege	307	1
2858	Rear corner bracket—L	1909-22		15		Bespawl	308	1
2859	Front end spacer—L	1909-22		10		Benzoin	318B	1
2860	Front end spacer—R	1909-22		10		Bestial	319B	1
2863	Body bracket	1909-22	On frame	15		Bestow	344	4

GASOLINE TANK

2900B	Gas tank	1916-22	Sedan	6 00	MH	Binocle	7950	1
2900C	Gasoline tank	1909-22	Elliptical	5 00	MH	Blacid	1303B	1
2901	Filling plug	1909-22	2 3/8"	10		Biblist	1317	1
2902B	Sediment bulb	1909-22	With pet cock	90		Bickers	2088	1
2908	Pet cock	1909-22	Order 3079					
2909	Feed pipe	1909-22	40 3/8"	20		Billet	1364	1
2909B	Feed pipe	1916-22	51 3/8"	25		Bismuth	7965	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
2909C.	Feed pipe	1918-19	66 1/4"	\$ 0		Bisque	9775R	1	
2909D.	Feed pipe	1919-22	56 1/2"	40		Betray	8690	1	
2909E.	Feed pipe	1918-22	39 3/4"	20		Billad.	TT1364	1	
2910.	Feed pipe pack nut	1909-22	1/2" x 18 thds.	05		Billow.	1374	2	
2911.	Feed pipe	1915	78"	70		Betrap	1394R	1	
2913.	Feed pipe gasket	1909-22		02		Fester	5892	1	
2914.	Gas tank support	1917-20	For round tank	25		Bistor	2132	1	
2914B.	Gas tank support—R	1920-22	For elliptical tank	20		Bitum.	2132B	1	
2915.	Gas tank support—L	1917-20	For round tank	20		Bivous.	2133	1	
2915B.	Gas tank support—L	1920-22	For elliptical tank	20		Bizarre	2133B	1	
2916.	Feed pipe clamp	1921-22		02		Blacken	2118	1	


MOTOR

*2990	Engine assembly	1909-22			MH	Calamite	532C	1	
2991	Cylinder assembly	1909-22			MH	Calamus	449	1	
x3000C.	Cylinder	1909-22		25	00	MH	Calcox	400D	1
x3000B.	Cylinder (bore $\frac{1}{8}$ " oversize)	1909-22		16	00	MH	Caleche	400E	1
3001	Cylinder head	1909-22		6	00	MH	Cabin	401C	1
3002	Cyl. head gasket	1909-22		35		MH	Caboose	402B	1
3003	Cyl. head cap screw	1909-22	1/4" x 2 3/4"	05			Cackle	483B	15
3003B.	Cyl. head cap screw	1918-22	1/4" x 3 1/4"	05			Chub	483C	1
3004	Cyl. head outlet con.	1909-16		35		MH	Cadow	446C	1
3004B.	Cyl. head outlet con.	1917-22		35		MH	Cannis	8719	1
3005	Cyl. head outlet con. gasket	1909-22		05		MH	Caddy	445B	1
3006	Cyl. head outlet hose	1909-22	2" x 4"	15			Cadet	448B	1
3007	Cyl. head outlet hose clip	1909-22	2 3/8" dia.	05			Cadger	607B	2
3008	Cyl. head outlet con. screw	1909-22	1/4" x 1 1/2"	05			Cadmean	550C	2
3009B.	Cyl. front cover	1909-19		1	00	MH	Cage	690B	1
3009C.	Cyl. front cover	1919-22	Starter type	1	00	MH	Canard	690C	1
3010	Cyl. cover bolt and nut	1909-22	Order 4808 & 2515						
3011	Cyl. cover cap screw	1909-22	3/8" x 1 1/2"	03			Cahoot	432	3
3012	Cyl. cover felt	1909-22	Felt	05			Caitiff	504	1
3013	Cyl. cover liner	1909-19	Paper	02			Cajole	505B	1
3013B.	Cyl. cover liner	1919-22	Paper—Starter type	03			Cajom	505C	1
3014	Cyl. cover and crank case bolt and nut	1909-22	Order 3362 & 2515						
3015	Cyl. water inlet con.	1909-22	Cast iron	30		MH	Calcine	442B	1
3016	Cyl. inlet con. screw	1909-22	1/4" x 1 1/2"	05			Caldron	597	2
3017	Time gear cover	1919-22	Starter type	1	00	MH	Calico	1754	1
3017B.	Time gear cover	1919-22		80		MH	Callix	1769	1
3017C.	Time gear cover gasket	1919-22		02			Candid	1775	1
3017D.	Time gear cover plate	1919-22		05		MH	Canine	1773	1
3018	Cyl. water inlet gasket	1909-22	Copper	05		MH	Calefy	596	1
3019	Cyl. water jacket plug	1909-13	1/2" pipe plug	05			Capin	557	3
3019B.	Cyl. water jacket plug	1914-22		02			Canon	5919	3
3020	PISTON COMPLETE	1909-22	3 3/4" dia.	1	70	MH	Caligh	586C	4
3020C.	PISTON COMPLETE	1909-22	.0025" oversize	1	70	MH	Canopy	586DR	4
3020D.	PISTON COMPLETE	1909-22	.03125" oversize	1	70	MH	Capon	586ER	4
3020E.	PISTON COMPLETE	1909-22	.033" oversize	1	70	MH	Churn	586FR	4
3020F.	PISTON COMPLETE	1909-22	.005" oversize	1	70	MH	Capitule	586GR	4
3021	Piston only	1909-22	3 3/4" dia.	1	00	MH	Callous	418C	4
3021B.	Piston only	1909-22	.0025" oversize	1	00	MH	Chopin	418DR	4
3021C.	Piston only	1909-22	.03125" oversize	1	00	MH	Chord	418ER	4
3021D.	Piston only	1909-22	.033" oversize	1	00	MH	Chute	418FR	4
3021E.	Piston only	1909-22	.005" oversize	1	00	MH	Chyle	418GR	4
3022	Piston pin	1909-22		25			Callot	419B	4
3022 1/2	Piston pin bushing	1909-22		25			Callow	668	4
3023	Piston ring	1909-22	1/4" x 3 3/4"	15			Calmy	422C	12
3023B.	Piston ring	1909-22	.03125" oversize	15			Calf	422ER	12
3023C.	Piston ring	1909-22	.007" oversize	15			Caloric	422FR	12
3023D.	Piston ring	1909-22	.038" oversize	15			Caltrap	422FR	12
3024	CONNECTING ROD	1909-22	Includes bearings	1	20	MH	Calvish	641	4
3025	Con. rod cap bolt	1909-22	3/8" x 2" x 24 thds.	05			Calyz	489B	8
3026	Con. rod cap bolt nut	1909-22		05			Camlou	490	8
3029	Con. rod clamp screw	1909-22	3/8" x 1 1/4"	05			Cambrie	578	4
3030	CRANK SHAFT	1909-22	25 1/2" long	9	00	MH	Camel	498B	1
3031	C. S. rear bearing cap	1909-22	3 1/2" long, babbitted	50			Cameo	405AR	1
3032	C. S. front bearing cap	1909-22	1 1/2" long, babbitted	40			Camera	406B	1
3033	C. S. center bearing cap	1909-22	2 3/8" long, babbitted	40			Camlet	407B	1
3034	C. S. bearing bolt—center and front	1909-22	1/2" x 6 1/8" x 20 thds.	10			Camphor	408	4
3035	C. S. bearing bolt nut	1909-22	Order 2551B						
3036	C. S. rear bearing bolt	1909-22	1/2" x 4 1/2"	10			Candle	478	2
3038	C. S. bearing liner—center and front	1909-22	1 1/2" long, brass	01			Cannon	502B	8
3039	C. S. rear bearing liner	1909-22	3" long, brass	01			Canny	503B	4

*Specify with or without starter—Inquire of Dealer for price.
 xWhen used on car not equipped with starter, also order 3017B, 3017C, 3011, 3008 and 3016.
 †Used with 3000C cylinder on cars not equipped with starter.
 ††Connecting rods requiring new bearings will be exchanged by dealers at 60c each.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts



Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
MOTOR—Continued									
3040	C. S. starting pin	1909-20	$\frac{3}{8}$ " x 2 $\frac{3}{4}$ "	\$ 0	05	Canoe	529B	1	
3040B	C. S. starting pin	1920-22			05	Capable	529C	1	
3041	CAM SHAFT	1909-22		2	50	MH. Canteen	410	1	
3042	Cam shaft front bearing	1909-22	2" long		30	Canter	411	1	
3043	Cam shaft center bearing	1909-22	2 $\frac{1}{2}$ " long		30	Canthus	412B	1	
3044	Cam shaft rear bearing	1909-22	1 $\frac{1}{2}$ " long		15	Canto	413	1	
3045	Cam shaft bearing ring	1909-22	$\frac{1}{8}$ " x 1 $\frac{1}{2}$ "		03	Canvas	534	2	
3046	Camshaft bear'g setscr'w	1909-22	$\frac{1}{8}$ " x $\frac{3}{8}$ "		05	Capelln	414	2	
3047B	Time gear—large	1909-22	Spiral		90	MH. Clang	415B	1	
3048B	Time gear—small	1909-22	Spiral		60	MH. Claret	416B	1	
3049	Cam shaft gear dowel pin	1909-22	$\frac{1}{8}$ " x $\frac{1}{8}$ "		02	Capra	417	2	
3050B	Cam shaft gear lock nut	1909-22			10	Captive	4453	1	
3051	Small time gear key	1909-22			05	Capsize	477	1	
3052	Valve	1909-22	Standard		15	MH. Capstan	424B	8	
3052B	Valve	1909-22	$\frac{1}{8}$ " oversize stem		15	MH. Cake	424AR	8	
3053 $\frac{1}{2}$	Valve bushing	1909-22	$\frac{3}{8}$ " O. D. x 2" long		30	Captain	428	8	
3054	Valve spring	1909-22			05	Capture	431	8	
3056	Valve spring seat	1909-22			05	Carack	425	8	
3057	Valve spring seat pin	1909-22			05	Caranx	429	8	
3058	Push rod	1909-22	Standard		10	MH. Carat	426B	8	
3058B	Push rod	1909-22	$\frac{1}{8}$ " oversize stem		10	MH. Cantata	426AR	8	
3059 $\frac{1}{2}$	Push rod bushing	1909-22	Iron		25	Chippy	427	8	
3060B	Exhaust manifold	1913-22		1	25	MH. Chirp	4483	1	
3061	Exhaust pipe pack nut	1909-22	1 $\frac{1}{8}$ " x 18 thds.		20	Chitter	518	1	
3062	Inlet pipe	1909-22		1	00	MH. Chloris	512B	1	
3063	Inlet & exh. pipe gasket	1909-22	1 $\frac{1}{8}$ " O. D. copper		03	MH. Choker	513	6	
3064	Inlet & exh. pipe gland	1909-22	1 $\frac{1}{8}$ " dia. iron		02	Chopper	514	6	
3065	Inlet & exh. pipe clamp	1909-22	2 $\frac{3}{8}$ " long		10	MH. Choral	515	4	
3066	Inlet & exh. clamp stud	1909-22	$\frac{3}{8}$ " x 3 $\frac{1}{4}$ "		05	Chorus	516	4	
3066B	Inlet & exh. clamp stud nut	1909-22			03	Humbler	517	1	
3068	Breat'r pipe	1909-22	1 $\frac{1}{8}$ " long		10	MH. Chuck	4468	1	
3069B	C. C. front end support	1911-17		1	00	Clam	801C	1	
3069C	C. C. front end support	1917-22			50	Clack	801D	1	
3070B	C. C. & cyl. gasket—left	1909-22	Cork		05	Clder	886	1	
3071B	C. C. & cyl. gasket—right	1909-22	Cork		05	Cigar	887	1	
3072	C. C. and cyl. cover cap screw	1909-22	$\frac{3}{8}$ " x 1"		03	Cinter	1388	2	
3073	C. C. arm bolt—side	1909-22	$\frac{3}{8}$ " x 2 $\frac{1}{2}$ "		05	Grocer	479	2	
3074	C. C. arm bolt—top	1909-22	$\frac{3}{8}$ " x $\frac{3}{4}$ "		05	Heath	940	2	
3074B	C. C. arm bolt nut	1909-22	Order 2515						
3075B	C. C. front bearing and spring clip assy.	1921-22			90	Cirrcut	2921B	1	
†3076B	C. C. front bearing and spring clip	1921-22			60	Circean	320C	1	
3076C	C. C. front bearing and spring clip nut	1921-22	Order 2548						
3077	C. C. front bearing cap	1909-22	Iron		15	Cizar	321	1	
3078	C. C. front bearing screw	1909-22	$\frac{1}{8}$ " x $\frac{7}{8}$ "		05	Clabber	322	2	
3078B	C. C. front bearing screw	1921-22	Order 3008						
3078C	C. C. front bearing lock washer	1921-22			01	Clachan	5636	2	
3079	Crank case oil cock	1909-22			15	Clamber	1515	2	
3080	C. C. drain cup plug	1909-22	Order 2532						
3080B	C. C. drain cup plug gasket	1909-22			03	MH. Cliff	4339	1	
3081	Crank case oil tube	1909-22			20	Cleavast	543B	1	
3083	Crank case arm block	1909-22	Wood		05	Clergy	890	2	
3084	Engine pan—right	1909-22			35	MH. Clicket	1330	1	
3085	Engine pan—left	1909-22			35	MH. Clitenta	1331B	1	
3088B	Engine pan and hood board bolt	1909-22	$\frac{1}{4}$ " x 3 $\frac{1}{4}$ "		03	Pittrr	4074	2	
3088C	Engine pan and hood board bolt	1909-22	$\frac{1}{4}$ " x 3 $\frac{3}{8}$ "		03	Pitpan	4073	2	
3088D	Engine pan and hood board bolt	1918-22	Truck		03	Shamble	TT4073	2	
3088E	Engine pan and hood board bolt nut	1909-22			02	Missive	1309		
3100	CRANK CASE	1912-22		12	00	MH. Closet	1526E	1	
3101	CRANK case lower cover	1912-22	6 $\frac{1}{8}$ " x 15 $\frac{1}{2}$ "		40	MH. Closure	1582	1	
3101B	CRANK case lower cover reinforcement	1912-22			30	Clothes	4378-4379	1	
3102B	C. C. lower cover gasket	1912-22	Cork		10	Clotting	1586	1	
3103	C. C. lower cover screw	1912-22	$\frac{1}{8}$ " x $\frac{1}{8}$ "		03	Cloudlet	4328	14	
3110	Cylinder valve cover	1912-22	3 $\frac{3}{4}$ " x 8"		15	MH. Clovate	656A	2	
3110B	Cylinder valve cover	1921-22			20	MH. Clown	656B	1	
3111B	Cyl. valve cover gasket	1912-22	Cork		05	Cloven	660A	2	
3111C	Cyl. valve cover gasket	1921-22	Cork		10	Cloyme	660B	1	
3112	Cyl. valve cover screw	1912-22	$\frac{3}{8}$ " x 2 $\frac{3}{8}$ "		02	Compone	654	2	
3114	C. C. arm with rivets	1909-22			30	Cloth	815B	2	
3115	CRANK case arm rivet	1909-22	doz.		05	Clothier	312		

†When ordered to replace old style C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664, 1-3810 and 2-753 cotter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts




Plate No. 4

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Req.
COMMUTATOR								
3162	Com. case support bolt	1912-19	3/8" x 2 1/4" x 24 thds.	\$ 0 05		Connote.	4441	1
3162B	Com. case support bolt	1919-22	Starter type	05		Constrict	1756	1
3163	Com. case spring	1912-22	3 1/4" C. to C.	05		Conold	689	1
3165	Com. brush only	1912-22		30		Conquest	4481	1
3176C	Com. oiler	1919-22		05		Cooke	480C	1
3177	Com. felt ring	1912-22	Felt	02		Coombox	5930	1
3206	Com. brush cap	1909-22	3/8" dia.	02		Convert	468B	1
3207	Com. brush cap pin	1909-22	3/8" x 1 1/8"	01		Convict	446	1
3210	Com. contact point nut	1910-22	1/8" hex.	02		Cooper	472B	8
3220	Com. lock nut	1909-22	1/8" x 18 thds.	05		Crater	471	1
3221	Com. case with fibre	1912-22		60		Crato	5908	1
3222	Com. shield	1912-22		02		Crash	5923	1

MAGNETO

3250D	Magneto coil assembly	1915-22	Used with 3/4" magnets.	6 00		Craft	5941B	1
3252	Magneto spool support screw	1909-22	Order 3371					
3254	Magnet bolt	1909-22	3/8" x 1 1/2"	03		Corbell	537B	16
3255	Magnet bolt washer	1911-22	1/4" hole, 3/8" dia.	01		Corupt	624	16
3257	Magnet brass support	1909-22	3/8" x 3/4" brass.	05		Cordial	535C	16
3260	Magneto contact assy.	1909-22	On trans. cover	20	MH	Cormus	1545	1
3261B	Magneto contact nut	1909-22		01		Cornute	1508	2
3261C	Magneto contact screw washer	1909-22		01		Cornel	1565	1
3262	Magneto contact spring	1909-22	Coil spring	05		Cornise	1509	1
3262B	Magneto contact screw and spring assb.	1919-22		10		Corsage	4350	1
3266	Mag. contact fibre screw	1909-22	1/2" long.	01		Cortile	1505	8
3267	Magneto primary insulating block	1915-22		05		Crumple	4382	1
3267B	Magneto contact insulator	1919-22		05		Crush	1503B	1
3267C	Magneto contact insulator shell	1919-22		03		Crutch	8611	1
3268	Fly wheel ring gear	1919-22	For starter	1 25	MH	Cousin	1885	1
3269C	Fly wheel	1911-19		6 00	MH	Coamic	701B	1
3269G	Fly wheel only	1919-22	Starter type	5 00	MH	Cozy	701C	1
3269H	Fly wheel with ring gear and magnets assmbld.	1919-22	Starter type	15 00	MH	Cranch	5946B	1
3270	Fly wheel cap screw	1909-22	1/4" x 1 1/8"	10		Cossack	721	4
3271	Fly wheel dowel pin	1909-22	1/8" x 1 1/8"	05		Costard	722	2
3272	Magneto coil support shim	1909-22	Sheet steel	05		Costrel	584	1
3276B	Magnet, per set (16)	1915-22	1/8" x 1 1/2" set	5 00		Court	5933	16
3277	Magnet clamp	1911-22		03		Cotland	623	16
3277B	Magnet clamp	1913-14		10		Cotta	4499	16
3278	Magnet clamp screw	1911-22	2 1/8" x 24 thds.	03		Cottage	625	16
3279	Magneto-contact washer	1909-22	On trans. cover—cork	01		Cough	560	1

TRANSMISSION

3300B	Transmission assembly	1919-22	Less gear and magnets	35 00	MH	Daclam	744C	1
3301	Trans. reverse plate assy.	1909-22		2 75	MH	Dacol	747	1
3304	Trans. reverse gear bushing	1909-22	2 1/8" ream	50		Daddy	705	1
3305	Trans. rev. & S. S. rivet	1909-22	1/8" x 1 1/8"	05	doz.	Dado	708	8
3306	Trans. slow speed plate assembly	1909-22		2 50	MH	Dagger	748	1
3309	Trans. slow speed gear bushing	1909-22	1 1/8" ream	35		Dairy	745	1
3310	Trans. brake drum rivet	1909-22	1/8" x 1 1/8"	05	doz.	Daisy	711	8
3311	Trans. brake drum assy.	1909-22		2 70	MH	Dakir	750	1
3313	Trans. triple gear assy.	1909-22		1 50	MH	Dallop	751B	3
3314 1/2	Trans. triple gear flanged bushing	1911-22	1 1/8" dia. x 1 1/8"	25		Dairiad	716B	3
3315	Trans. triple gear shaft	1909-22	1 1/8" dia x 2 1/2"	15		Dairlotz	715	3
3316	Trans. triple gear riveting pin	1909-22	1/8" x 1 1/8"	05	doz.	Damar	720	24
3317	Trans. driven gear	1909-22	27 teeth	80	MH	Damask	713	1
3318	Trans. driven gear key	1909-22		03		Dampen	714	2
3320C	Trans. driven gear sleeve bushing	1909-22	1 1/2" long	20		Dark	712	2
3320D	Driven gear sleeve washer	1909-22		05		Darken	776	3
3321	Trans. driving plate assy.	1909-22		3 00	MH	Darnock	749	1
3323	Trans. driving plate screw	1909-22	Order 3371					
3325	Trans. driving plate rivet	1909-22	1/8" x 3/8"	05	doz.	Darner	736	8
††3327B	Trans. driving plate bushing	1909-22	1 1/8" x 1 1/4"	15		Darls	772	1
3328	Trans. clutch disc-small	1909-22	6" dia.	10	MH	Dauphin	727	12
3329	Trans. clutch disc-large	1909-22	8 1/4" dia.	10	MH	Davine	728	13
3331	Trans. gear shaft	1909-22	1" dia. x 7 1/2" over all.	1 50	MH	Decurt	723B	1

††When using short bushings in making repairs remove driving plate key.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
TRANSMISSION—Continued									
3332	Trans. clutch disc drum	1909-22	4 1/4" dia.	\$ 1 25	MH	Deeply	725B	1	
3333	Trans. clutch disc drum key	1909-22		05		Defalk	726B	1	
3334	Trans. clutch disc drum set screw	1909-22	3/8" x 3/4"	05		Defeat	752	1	
3336	Trans. clutch push ring	1909-22	6 1/4" O. D.	35	MH	Defile	770	1	
3337	Trans. clutch finger	1909-22		15		Define	732B	3	
3337 1/2	Trans. clutch finger screw	1909-22	3/8" x 3/4" x 24 thds.	05		Deflour	756	3	
3337B	Trans. clutch finger and screw	1909-22		20		Defix	765	3	
3338	Trans. clutch finger pin	1909-22	1 1/4" x 1 5/8"	01		Deform	735	3	
3340	Trans. clutch spring	1909-22	2 5/8" dia. x 2 3/4" long	35		Defouze	737	1	
3341	Trans. clutch spring support	1909-22		15	MH	Delator	738	1	
3342	Trans. clutch spring thrust ring pin	1909-22	1 1/4" x 2 3/8"	05		Delete	739	1	
3344	Trans. clutch shift	1909-22		50	MH	Delight	733	1	
TRANSMISSION COVER									
3362	Trans. cover bolt	1909-22		05		Era	79		
3362B	Trans. cover bolt nut	1909-22	Order 2515						
3363	Trans. cover gasket (front)	1909-22	1 1/4" x 1 1/2" x 15 1/2" felt	05		Defy	872B	1	
3363B	Trans. cover gasket—short	1909-22	1 1/4" x 1 1/2" x 13" felt	03		Defiant	4358	1	
3367	Trans. cover door screw	1909-22	1/4" x 1/2"	02		Demain	430	1	
3368	Universal ball cap (rear)	1909-22	5 3/4" x 1/2"	30	MH	Demarch	818	6	
3369	Universal ball cap (front)	1909-22	Bearing included	80	MH	Demarga	819D	1	
3371	Universal ball cap screw	1909-22	3/8" x 1 1/4"	03		Demise	731	2	
3372	Universal ball cap bolt and nut	1909-22	Order 3362 & 2515						
3375	Trans. cover screw	1909-22	Order 3072						
3376B	TRANS. COVER	1919-22	Starter type	6 50	MH	Den	826E	1	
3377B	Trans. cover gasket	1909-22	Cork	15		Dennet	885B	1	
3378	Trans. cover door	1911-22	9 1/4" long	15	MH	Dental	1546D	1	
3379B	Trans. cover door gasket	1911-22	Cork	05		Denude	1547C	1	
3380	Bendix cover gasket	1919-22		20	MH	Tendon	1763	1	
3381	Bendix cover	1919-22		03		Thigh	1764	1	
3382	Trans. cover rear plate	1919-22		05	MH	Deputy	1761	1	
3383	Trans. cover front plate	1919-22		10	MH	Descry	1758	1	
TRANSMISSION CONTROL									
3400	Trans. clutch release ring	1909-22	3 1/4" long	20		Detail	741	1	
3402D	Clutch lever and shaft	1913-22		35		Disdain	1548		
3403	Clutch lever screw	1909-22	Order 3973						
3403B	Clutch lever screw nut	1909-22	Order 3066B						
3405	Clutch lever pin	1909-22	3/4" x 1 1/4"	02		Detour	1553	1	
3406B	Clutch release fork—right or left	1913-22		15		Deuce	4345	2	
3406C	Clutch release fork pin	1913-22	Order 3405						
3408	Clutch release fork key	1909-14		05		Dilate	836	2	
3409	Clutch release fork clamp screw	1909-14	3/8" x 1 1/4"	10		Dlpper	835	2	
3411	Clutch lever clevis pin	1909-22	Order 2564						
3413	TRANSMISSION BAND ASSEMBLY	1909-22		60	MH	Disblame	838B	3	
(Bands will be exchanged by dealers at 45c each.)									
3415	Trans. band washer	1909-22	1 1/4" hole x 1/8" dia.	03		Discure	840	2	
3416	Trans. band lining	1909-22		15	MH	Disedge	1562A1	3	
3416B	Trans. band lining—set of 3, inc. rivets—in carton	1909-22		65		Disenroll	1654	1	
3419	Trans. band adj. screw	1909-22	3/4" x 3 3/8"	10		Disfriar	1533	1	
3420	Trans. band adj. screw nut	1909-22	3/4" x 16 thds.	05		Dislimb	1532	1	
3421B	Trans. band ear iron rivet	1909-22	1/4" x 3/8"	05		Dismal	843	12	
3422B	Trans. band brass rivet	1909-17	1/4" x 1/2"	05		Dismast	844B	6	
3423B	Trans. band brass rivet	1909-22	1/4" x 1/4"	05		Dismaw	845B	24	
3425	Trans. band spring	1909-22	Coil	05		Dispark	841B	3	
3426	Trans. band adj. nut	1909-22	1/2" x 20 thds.	05		Displat	851	2	
3427	Slow speed shaft	1909-22	3/8" x 9 3/8"	15		Disputz	848B	1	
3428	Slow speed notch	1909-22		30		Distrand	4327	17	
3429	Slow speed notch pin	1909-22	1/4" x 1 1/8"	02		Disrobe	1560	1	
3432	Speed lever	1909-22		10		Distaff	862B	1	
3434	Reverse pedal	1909-22		60	MH	Disting	4324	1	
3435	Brake and rev. pedal shaft	1909-22	3/8" dia. x 7 1/4"	15		Distrite	849B	2	
3436	Brake and rev. pedal support	1909-22		20		Distune	4325	2	
3437	Brake and rev. support bolt	1909-22	3/8" x 1 1/2"	05		Ditcher	1534	2	
3437B	Brake and rev. support bolt nut	1909-22	Order 2515						

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.


Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Reg. No.	per Car
TRANSMISSION CONTROL—Continued									
3439	Brake pedal	1909-22		\$ 0 60	MH	Dittost	4323		1
3440	Clutch pedal	1909-22		60	MH	Ditty	854B		1
3441	Pedal pin	1909-22	Order 3405						
3442	Clutch pedal support	1909-22		20		Dookad	4326		1
3443	Clutch pedal support bolt	1909-22	$\frac{3}{8}$ " x 2"	05		Doorga	1536		1
3443B	Clutch pedal support bolt nut	1909-22	Order 2515						
3445	Slow speed connection	1909-22		05		Doree	1540		1
3446	Slow speed con. lock nut	1909-22	Order 2503F						
3447	Slow speed con. clevis	1909-22		10		Dormer	802		1
3448	Controller quadrant	1909-22	On frame	20		Dormouse	309B		1
3449	Controller shaft with speed lever	1909-22		70	MH	Doron	1557		1
3450	Controller shaft bracket	1909-22	On frame	15		Dorrer	311		2
3452	Controller shaft bracket bolt	1909-22		03		Fog	315		4
3452B	Controller shaft bracket bolt nut	1909-22		02		Frolch	316		4
3455	Hand brake lever assy	1909-22		1 00	MH	Dotant	1550		1
3456B	Hand brake lever pin	1909-22	Order 2574						
3457	Hand brake lever key	1909-17		05		Doublet	874		1
3458	Hand brake lever pawl	1909-22		10		Doucet	875		1
3459	Hand brake lever pawl pin	1909-22	$\frac{1}{16}$ " x $\frac{11}{16}$ "	02		Doura	876		1
3460	Hand brake lever pawl rod	1909-22		10		Dovecote	877		1
3462	Hand brake lever pawl lift assembly	1909-22	Handle and spring	10		Dovekle	4363		1
3463	Hand brake lever pawl lift spring	1909-22		02		Dawcet	888		1
3465	Hub brake lever	1909-22		20		Dawdy	864		1
3466	Hub brake lever pin	1909-22	Order 3405						
3467	Hub brake lever clevis	1909-22	Order 3447						
3468	Hub brake pull rod—R.	1909-22	54 $\frac{1}{8}$ " long	40	MH	Drongo	891B		1
3469	Hub brake pull rod—L.	1909-22	54 $\frac{1}{8}$ " long	40	MH	Dropax	1513B		1
3470	Brake rod support—R.	1909-22		10		Dropsy	1367C		1
3471	Brake rod support—L.	1909-22		10		Druggier	1398C		1
3472	Brake rod support bolt	1909-22	$\frac{1}{2}$ " x 1 $\frac{1}{8}$ "	03		Methol	1308		2
3472B	Brake rod support bolt nut	1909-22	Order 3088E						
STEERING GEAR									
3500C	Steering gear assembly	1911-22	51" long	10 00	MH	Estopped	5044		1
3501C	Steering gear rim	1920-22	16"	75		Estuary	901C		1
3502	Steering gear rim screw	1909-22	No. 9, $\frac{7}{8}$ "	01		Eblis	6849		4
3503D	Steering gear spider	1920-22	16"	50		Etagero	902C		1
3503E	St. gear spider and rim	1909-22	16"	1 25	MH	Eulogic	995A2		1
3504	St. gear cover	1909-22	2 $\frac{11}{16}$ " x 18 thds.	35		Echole	5039		1
3505	St. gear cover screw	1909-22	No. 6, 32 x $\frac{1}{4}$ "	01		Eccope	910		1
3506	St. gear cover bushing	1909-22	1" long steel	15		Echo	914		1
3506B	St. gear driving pinion washer	1909-22	Steel	02		Elf	5026		1
3507	St. gear internal gear case and bushing	1909-22		1 00		Egg	5036		1
3509	St. gear quadrant	1909-22		15		Ectype	906B		1
3511	St. gear wheel nut	1909-22	$\frac{3}{8}$ " x 16 thds.	10		Edict	913		1
3512C	St. gear tubing assy.	1912-22		4 00		Ethlcer	5016		1
3513C	St. tubing flange screw	1913-22	$\frac{1}{4}$ " x 1 $\frac{1}{4}$ "	03		Platter	5018		3
3514	St. tubing flange screw nut	1913-22		02		Harrow	926		
3516C	St. gear post	1912-22		1 75		Estricked	5043		1
3516D	Steering gear post	1922		1 75		Esturle	5043B		1
3517	St. gear pinion	1909-22	12 teeth	03		Egad	916		3
3518	St. gear pinion pin—short	1909-22	$\frac{3}{8}$ " x 1 $\frac{1}{8}$ "	15		Egest	917		2
3518B	St. gear pinion pin—long	1921-22		03		Egolism	918		1
3519	St. gear drive pinion	1909-22	12 teeth	30		Egger	911		1
3520	St. gear drive pinion gear	1909-22	$\frac{1}{8}$ " sq. x $\frac{11}{16}$ "	03		Egma	909		1
3523	St. gear post castle nut	1909-22	Order 2551B						
3524E	Throttle rod	1912-22	47 $\frac{11}{16}$ "	30		Euter	5038		1
3525E	Lead rod	1912-22	51 $\frac{11}{16}$ "	30		Evans	5037		1
3527	Lead & throttle rod spring	1909-22		02		Elite	935		2
3528	Lead & throttle rod collar	1909-22	$\frac{1}{8}$ " bore x $\frac{1}{8}$ "	02		Elope	936		2
3529	Lead & throttle rod pin	1909-22	$\frac{1}{8}$ " x $\frac{1}{8}$ "	01		Elvan	937		5
3530	Lead rod lever	1909-22		10		Embank	946		1
3531	Throttle rod lever	1909-22		10		Ember	947		1
3532	Lead & throttle rod guide	1909-22	$\frac{3}{4}$ " bore	05		Emblem	938		1
3534B	Commutator pull rod	1912-22		10		Embrace	2082		1
3535	Carburetor pull rod	1909-22	14 $\frac{1}{8}$ " long	10		Emboss	1329		1
3536	Ball and socket joint	1909-22		10		Embrald	1326		1
3537	Ball & socket joint nut	1909-22	$\frac{1}{2}$ " x 32 thds.	02		Embrat	1327		1
3539B	St. brkt. with bushing	1911-22	Touring	75		Eupon	996		1
3539C	St. brkt. with bushing	1918-22	Truck	75		Dream	TT996		1
3540	St. brkt. bolt & nut—long	1909-22	Order 3073 & 2515						
3541	St. brkt. bolt & nut—short	1911-22	Order 3074 & 2515						

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts



Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Req. per Car
STEERING GEAR—Continued								
3544	St. brkt. felt washer	1909-22		\$ 03		Endow	943	1
3545	St. brkt. bushing	1909-22	3/4" bore, brass, 2 pieces	20		Envault	944-5027	1
3546	St. brkt. block	1909-22	Wood	10		Empact	945	1
3546B	St. brkt. block	1918-22	Truck	05		Drift	TT945	1
3547	St. gear ball arm	1909-22		40		Eparch	929B	1
3548	St. gear ball arm key	1909-22		05		Ephod	930	1
3549	St. brkt. dust cap	1918-22	Truck	05		Drum	TT5044	1
BODY PARTS								
3601B	Body bracket on body	1910-22	Center	10		Fabric	1624	2
3601C	Body bracket—front—R	1921-22	T. C., Rbt. & Coupe	20		Fabulist	7267B	1
3601D	Body bracket—front—L	1921-22	T. C., Rbt. & Coupe	20		Fabulize	7268B	1
3601E	Body bracket—rear	1913-22	Rbt. and Coupe	05		Facetial	5650	2
3601F	Body bracket—rear—R	1921-22	T. C.	15		Facial	7137C	1
3601G	Body bracket—rear—L	1921-22	T. C.	15		Facient	8001B	1
3602E	Body bracket con. bolt	1916-22	1/4" x 1 1/4"	03		Pilgrim	2431	6
3602F	Body brkt. con. bolt nut	1916-22	Order 2719					
3624E	Front floor rubber mat	1915-22	28 1/4" x 29 1/8" Tr. & Rbt.	1 00		Faith	7299	1
3626C	Floor board with plate (first)	1915-22		45		Farrago	4200	1
3627C	Floor board with plate (second)	1915-22		45		Fascia	4201	1
3628B	Floor board with plate (third)	1915-22		65		Fascine	7104	1
3630	Floor board forward plate for pedals	1909-22	2 1/8" x 3 1/8"	10		Fateful	1400C	1
3632	Floor board rear plate for pedals	1909-22	2 1/8" x 4 1/8"	10		Father	1095C	1
3633	Floor board plate for side lever	1909-22	2 3/8" x 8 3/4"	05		Fathom	1094B	1
3634E	Dash	1915-16		5 00		Fleet	7462	1
3634C	Dash	1917-22		2 50		Fringe	8754	1
3638B	Dash shield	1919-22		10		Faubage	5432B	1
3639	Dash weatherstrip—side	1917-22		05		Flicker	8747	2
3639B	Dash weatherstrip—top	1917-22		20		Floren	8752	1
3640C	Dash bracket—left	1917-22		15		Foal	8722	1
3641C	Dash bracket—right	1917-22		15		Fowl	8721	1
3642B	Dash brkt. to dash bolt	1917-22		03		Rodent	8740	4
3642C	Dash bracket to dash bolt nut	1917-22	Order 3514					
3653B	Dash to body brkt. bolt	1915-22	Touring car	03		Planet	4248	2
3653C	Dash to body brkt. bolt nut	1915-22	Order 4805C					
3654	Dash to body gasket	1918-22		05		Feaze	8769	1
3660C	Tail lamp and license bracket assembly	1915-22	Touring car, Sedan	25		Flour	7506	1
3660D	Tail lamp and license bracket assembly	1915-22	Runabout and 1916-17 Coupelet	25		Flute	7505	1
3662	Front license bracket—R	1920		10		Fluffy	287	1
3663	Front license bracket—L	1920		10		Fluently	288	1
3664	Front license bracket	1921-22		15		Fluxion	493	1
3667E	Front seat cushion	1909-21		6 00	MH	Farce	8076A	1
3667F	Front seat cushion	1921-22		6 00	MH	Farical	8076B	1
3670D	Rear seat cushion	1909-21		6 50	MH	Forum	7032A	1
3670E	Rear seat cushion	1921-22		6 50	MH	Forthy	7032B	1
3676B	Rear floor mat	1911-21	30" x 28" wool	1 25		Flatus	1606B	1
3676C	Rear floor mat	1911-22		1 00		Flaunt	1606C	1

SPRINGS

3800	Front spring	1909-22		2 50	MH	Gadan	332	1
3801	First leaf (main leaf)	1909-22		80		Golf	2943	1
3802B	Second leaf	1909-22		50		Goose	2935	1
3803B	Third leaf	1916-22		40		Gopher	2936	1
3804B	Fourth leaf	1916-22		30		Gosling	2937	1
3805B	Fifth leaf	1916-22		25		Gossip	2938	1
3806B	Sixth leaf	1916-22		20		Gothic	2939	1
3807B	Seventh leaf	1916-22		15		Gaily	2947	1
3808	Front spring clip	1909-22		20		Galena	325C	2
3809	Front spring clip nut	1909-22	Order 2551B					
3810	Front spring clip bar	1921-22		25		Gallate	342	1
3811	Front spring tie bolt	1909-22	1/4" x 2 1/4"	04		Galley	1362	1
3811B	Front spring tie bolt nut	1909-22		02		Galleon	1363	1
3813	Front spring hanger	1909-22	(Each piece)	15		Gambit	246B	4
3815	Spring hanger nut	1909-22	Order 2719					
3818	Front spring perch—right	1909-19		60	MH	Gamut	274A	1
3818B	Front spring perch—right	1919-22		60	MH	Garret	274B	1
3819	Front spring perch—left	1909-19		60	MH	Gander	275A	1
3819B	Front spring perch—left	1919-22		60	MH	Gastar	275B	1
3820	Front spring perch bushing	1909-22		05		Gangue	230	4
3821	Front spring perch nut	1909-22	Order 2828					

††When used on 1911-16 cars redrill frame.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
SPRINGS—Continued									
3821B.	Front spring perch nut.	1921-22.		\$ 0 05		Garble.	240	1	
3823.	Front spring leather.	1909-22.	1 1/2" x 5 3/4"	10		Gannet.	262	1	
3824.	REAR SPRING.	1909-22.	8 leaf	7 00	MH	Ganoid.	333	1	
3824B.	REAR SPRING.	1922.	9 leaf—Sedan.	7 25		Ganoine.	388	1	
3825.	First leaf (main leaf).	1909-19.	Tapered ends.	1 50		Gantiope.	361A.	1	
3825B.	First leaf (main leaf).	1918-22.		1 50		Gallop.	355	1	
3825C.	First leaf (main leaf).	1922.	9 leaf spring—Sedan.	1 50		Gantry.	389.	1	
3826.	Second leaf.	1909-19.	Tapered ends.	1 25		Gantois.	362A.	1	
3826B.	Second leaf.	1918-22.	Square ends.	1 25		Galore.	362B.	1	
3826C.	Second leaf.	1922.	9 leaf spring—Sedan.	1 25		Gancine.	391.	1	
3827.	Third leaf.	1909-19.	Tapered ends.	1 10		Ganza.	363A.	1	
3827B.	Third leaf.	1918-22.	Square ends.	1 10		Garnish.	363B.	1	
3827C.	Third leaf.	1922.	9 leaf spring—Sedan.	1 10		Garget.	392.	1	
3828.	Fourth leaf.	1909-19.	Tapered ends.	95		Gaphare.	364A.	1	
3828B.	Fourth leaf.	1918-22.	Square ends.	95		Gender.	364B.	1	
3828C.	Fourth leaf.	1922.	9 leaf spring—Sedan.	95		Genera.	393.	1	
3829.	Fifth leaf.	1909-19.	Tapered ends.	80		Garden.	365A.	1	
3829B.	Fifth leaf.	1918-22.	Square ends.	80		Genus.	365B.	1	
3829C.	Fifth leaf.	1922.	9 leaf spring—Sedan.	80		Genet.	394.	1	
3830.	Sixth leaf.	1909-19.	Tapered ends.	65		Garland.	366A.	1	
3830B.	Sixth leaf.	1918-22.	Square ends.	65		Ghoul.	366B.	1	
3830C.	Sixth leaf.	1922.	9 leaf spring—Sedan.	65		Ghaut.	395.	1	
3831.	Seventh leaf.	1909-19.	Tapered ends.	55		Garlic.	367A.	1	
3831B.	Seventh leaf.	1918-22.	Square ends.	55		Giant.	367B.	1	
3831C.	Seventh leaf.	1922.	9 leaf spring—Sedan.	55		Giaour.	396.	1	
3832B.	Eighth leaf.	1909-22.	Square ends.	45		Gimlet.	368B.	1	
3832C.	Eighth leaf.	1922.	9 leaf spring—Sedan.	50		Gimnal.	397.	1	
3932D.	Ninth leaf.	1922.	9 leaf spring—Sedan.	45		Gingival.	398.	1	
3833.	Rear spring clip.	1909-22.		20		Game.	326.	1	
3833B.	Rear spring clip.	1922.	9 leaf spring—Sedan.	20		Gelder.	1737.	2	
3834.	Rear spring clip nut.	1909-22.	Order 2548						
3835.	Rear spring clip bar.	1909-22.	3/8" x 1 1/4" x 4" x 1/8"	10		Gascon.	329.	2	
3837.	Rear spring tie bolt.	1909-22.	3/8" x 2 1/8"	04		Gastric.	1352.	1	
3837B.	Rear spring tie bolt nut.	1909-22.		02		Gauffer.	1353.	1	
3838.	Rear spring tie bolt.	1922.	9 leaf spring—Sedan.	04		Gaudil.	1355.	1	
3840.	Rear spring hanger.	1909-22.	(Each piece)	15		Gaulus.	91 1/2 B.	4	
3842.	Rear spring leather pad.	1909-18.		05		Gavel.	94.	1	
3843.	Rear spring perch.	1909-22.		40	MH	Gavot.	2804.	2	
3844.	Rear sp. perch bushing.	1909-22.	1/2" bore x 3/4" dia. x 2"	05		Gawky.	172.	4	
3845.	Rear spring perch nut.	1909-22.	1 1/2" x 16 thds.	05		Gazara.	174.	2	
3846.	Spring perch ooler.	1917-22.		05		Bilge.	2944.	4	
3847.	Front spr'g clamp assembly with bolt and nut.	1909-16.		10		Gazzam.	374.	2	
3847B.	Front spr'g clamp assembly with bolt and nut.	1916-22.	(for 6 leaf spring)	10		Gown.	2953.	2	
3848.	Rear spr'g clamp assembly with bolt and nut.	1909-17.		10		Gecko.	376.	2	
3848B.	Rear spr'g clamp assembly with bolt and nut.	1918-22.		10		Gemmy.	378.	2	

STARTING CRANK

3900.	Starting crank only.	1909-22.		50		Hernia.	519B.	1	
3901.	Starting crank handle.	1909-22.		20		Heron.	520.	1	
3902.	St. crank handle bolt.	1909-22.	1/2" x 4 3/8"	10		Herpes.	521.	1	
3903.	St. crank sleeve.	1909-22.	1 1/2" bore x 1 1/2" x 2 3/4"	10		Hesper.	523.	1	
3905.	St. crank ratchet pin.	1909-22.	1 3/8"	05		Hestern.	4491.	1	
3906.	St. crank ratchet.	1909-22.		20		Hetman.	528B.	1	
3908.	St. crank spring.	1909-22.		05		Hilding.	626.	1	
3909.	St. crank handle spring.	1915-22.		02		Hitter.	5911.	1	
3910.	St. crank assy.	1909-22.		50	MH	Hiren.	5931.	1	

RADIATOR—THERMO-SYPHON

3925.	Radiator.	1909-16.		17 00	MH	Hominy.	1100C.	1	
3925B.	Radiator.	1917-22.		17 00	MH	Honey.	8700B.	1	
3925C.	Radiator less shell.	1917-22.		15 75	MH	Hop.	8736B.	1	
3926.	Radiator cap.	1909-22.		15	MH	Hothir.	8714.	1	
3928.	Radiator pad.	1909-19.	Leather.	05		Hovel.	1105.	2	
3929.	Radiator stud.	1909-19.	3/8" x 2 1/8"	05		Hoxy.	1162A.	2	
3929B.	Radiator stud.	1919-22.		05		Hoax.	1162B.	2	
3929C.	Radiator stud nut.	1909-22.		03		Hive.	1154.	2	
3930.	Radiator stud spring.	1909-22.	Order No. 2742						
3931 1/2.	Rad. stud washer nut.	1909-22.	3/8" x 24 thds.	03		Huffish.	1161.	2	
3932.	Radiator rod.	1909-22.	20 3/4" l.c.B.	15	MH	Huller.	1111B.	1	
3934.	Radiator rod nut.	1909-22.	Order 30713						
3939.	Outlet connection pipe.	1909-22.	1 3/4" x 1 1/2"	30		Humic.	1121.	1	
3940.	Outlet connection cock.	1909-22.	Order 30						
3944.	Outlet connection hose.	1909-22.	1 3/4" x 2 3/4"	10		Hungry.	507B.	2	
3945.	Outlet conn. hose clip.	1909-22.	2 1/8" dia.	05		Hunter.	554B.	4	
3947B.	Radiator shell.	1917-22.		1 25	MH	Hymnal.	8737B.	1	
3975.	Radiator stud spring upper thimble.	1919-22.		02		Hump.	1115.	1	
3976.	Radiator stud spring lower thimble.	1919-22.		03		Hurst.	1114.	2	

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Req. per Car
RADIATOR FAN								
3960	Fan and pulley assembly	1909-20		\$ 1 25	MH	Hutten	619	1
3961	Fan blade	1909-20		10		Hyades	611	4
3961B	Fan blade rivet	1909-22	doz.	05		Hyad	1566	16
3961C	Fan blade assy.	1920-21		25		Iambe	620	1
3962B	Dr. fan pulley with bush	1920-22		70		Iaon	618B	1
3963	Fan drive pulley	1909-20	Steel, lower	25		Hydrant	602A	1
3963B	Fan drive pulley	1920-22		30		Hydromel	602B	1
3964	Fan belt	1909-16	23" long, fabric	30		Hydrate	609A	1
3964C	Fan belt	1917-20	26" long, fabric	30		Impel	609B	1
3964D	Fan belt	1920-22	Fabric	40		Idiom	609C1	1
3964E	Fan belt	1920-22	Rubber	40		Idolish	609C2	1
3966	Fan shaft	1909-20	1" x 4 1/4"	20		Hyper	606A	1
3966B	Fan shaft	1920-22		20		Iasius	606B	1
3967	Fan bracket	1909-16		40		Hypo	604A	1
3967B	Fan bracket	1917-22		30		Idyl	604B	1
3968	Fan bracket bolt	1909-22	1/2" x 2 3/8"	10		Hypere	605	1
3970	Fan grease cup	1909-22		10		Hyppish	601	1
3973	Fan adjusting screw	1909-22	3/8" x 1 1/4"	02		Groats	645	1
3973B	Fan adj. screw nut	1909-22	Order 3066B					
3974	Fan driven pulley bush	1917-20		15		Knag	8757A	1
3974B	Fan driven pulley bush	1920-22		15		Ibhar	8757B	2
3980	Fan pulley plug	1920-22		03		Ibidem	633	1
3981	Fan pulley gasket	1920-22		02		Icarian	634	1
3982	Fan shaft cap	1920-22		02		Icllius	635	1
3983	Fan shaft felt washer	1920-22		02		Iconism	637	1
3984	Fan blade screw	1920-22		01		Ictus	652	4
3985	Fan blade screw washer	1920-22	Order 3261C					4
3986	Fan shaft nut	1920-22	Order 2719					1

MUFFLER

4025	Muffler assembly	1909-20		2 00	MH	Jobal	1200BR	1
4025B	Muffler assembly	1921-22	Includes 3061 & 4037C	2 25	MH	Jocasta	1200C	1
4026B	Muffler head—front	1917-20		45		Julap	1202C	1
4026C	Muffler head—front	1921-22	Pressed steel	15		Julian	1202D	1
4027	Muffler shell—outer	1909-22	5" dia. x 12"	25		Jabin	1203	1
4028	Muffler shell—middle	1909-22	3 1/2" dia. x 13"	20		Jackal	1204	1
4029	Muffler shell—inner	1909-20	2" dia. x 14"	15		Jaday	1205	1
4030B	Muffler rod	1917-20		10		Jocose	1206B	1
4032	Muffler head retainer	1921-22		02		Jole	1210	1
4033	Muffler head retainer bolt and nut	1911-22	Order 4819B and 3514					
4035	Muffler head bolt washer	1921-22	doz.	05		Jovy	925	1
4037B	Long exhaust pipe	1909-20		1 50		Jaunty	1214A	1
4037C	Long exhaust pipe	1920-22		1 50	MH	Jazerant	1214B	1
4040B	Muffler head—rear	1917-22		45		Jesuit	1201D	1
4040C	Muffler head—rear	1921-22	Pressed steel	20		Jeush	1201E	1
4041	Muffler head to frame bolt and nut	1917-20	Order 3362 & 3066B					
4041B	Muffler head to frame bolt and nut	1921-22	Order 3074 & 2515					

HOOD

4050	Hood	1909-16	22" long	7 50		Jibsam	1300	1
4050B	Hood	1917-22		6 00	MH	Jilt	8726	1
4051	Hood handle	1909-22	5 1/2" long	05		Jingal	1314	2
4052B	Hood clip	1917-22		05		Jowl	8731	4
4053B	Hood clip spring	1917-22		02		Juice	8734	4
4056	Hood board—left	1909-16	22 3/4" long	25		Johim	1339	1
4056B	Hood board—left	1917-22		20		Kilt	8742	1
4057	Hood board—right	1909-16	22 3/4" long	25		Jorum	1340	1
4057B	Hood board—right	1917-22		20		Kine	8741	1
4060C	Hood pad (on dash)	1917-22		08	MH	Kite	8711	2
4060D	Hood pad (on rad. shell)	1917-22		15	MH	Kid	8710	1
4061B	Hood clasp (on dash)	1917-22		05		Kit	8720	1
4061C	Hood clasp (on dash) screw	1917-22		02		Knee	8763	2
4061D	Hood clasp (on dash)	1920-22		05		Kitten	8720B	1
4073	Hood block support—front right	1917-22		05		Knot	8743	1
4074	Hood block support—front left	1917-22		05		Kiln	8744	1
4075	Hood block support—rear right	1917-22		05		King	8745	1
4076	Hood block support—rear left	1917-22		05		Kirk	8746	1

FORD CARBURETOR PARTS (MODEL "G")

4451A	Float with lever	1914-21		40		Muzzle	6333AR	1
4452A	Spray needle assembly	1914-21		20		Myrtle	6335AR	1
4453A	Gasoline inlet needle	1914-21		20		Mystic	6324A	1
6041	Mix chamber	1914-20		2 50		Maadiah	6340AR	1
6042	Mix chamber top	1912-14-20		40		Maarath	4801R	1
6043	Mix chamber top screw	1912-20		02		Maaziah	4808R	1
6044	Mix chamber top gasket	1914-20		01		Mabadis	6317R	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts



Part No.	Name of Part	Year	Specifications	Price	Tax Code Status	Fac. No. Word	No. per Car	Req.
FORD CARBURETOR PARTS (MODEL "G")—Continued								
6044B.	Mix chamber bottom gasket	1916-20		\$ 0 03		Macacore	.6367AR	
6045	Mix chamber nut	1912-20		07		Macarize	.4810AR	
6046	Float chamber and bush assembly	1914-20		50		Macerate	.6318AR	
6047	Float lever pin	1914-20		03		Macetoe	.6320AR	
6048	Float valve seat	1914-20		10		Macigno	.6321AR	
6049	Float valve seat gasket	1914-19	Fibre	01		Madeira	.6322A	
6051	Spray needle clamp nut	1912-20		05		Maglph	.4812AR	
6052	Spray needle	1914-20		30		Maglify	.6341AR	
6053	Spray nozzle gasket	1912-14-20	Fibre	01		Maihem	.4820AR	
6055	Gas inlet elbow	1913-20		15		Manacle	.4859	
6057	Low speed tube with nut	1915-20		20		Manudbi	.6360R	
6058	Low speed tube retaining screw	1912-14-20		03		Manilus	.4814R	
6060	Low speed boss score	1912-14-20		03		Mannish	.4816R	
6061	Strangling tube	1912-14-20		15		Mappery	.4817R	
6062	Strangling tube retainer	1912-14-20		02		Marabou	.4818R	
6064	Throttle lever stop screw	1911-21		02		Margaric	.4520A	
6065	Throttle lever clamp screw	1911-19		02		Marcaron	.4521AR	
6068	Throttle plate	1912-14-20		10		Marikina	.4517AR	
6070	Throttle lever	1912-14-20		20		Maritime	.4836B	
6070B.	Throttle lever—oversize	1912-14-20		20		Markable	.4836AR	
6071	Throttle lever adj. lock nut	1911-20		02		Martinet	.4528R	
6074	Aux. throttle plate	1915-20		03		Masora	.6337AR	
6076	Aux. throttle lever spring	1914-20		02		Manther	.6342A	
4494	Aux. throttle lever spring	1910-14		05		Maxilla	.6342BR	
6077	Aux. throttle lever assy.	1914-21		15		Mazurka	.6327A	
4463	Float lever holding screw nut	1912-19		02		Mazarine	.4805AR	
4464	Float lever holding screw	1913-19		03		Mazime	.4853AR	
6081A.	Drain valve plug and handle		Order T6216					

Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.

KINGSTON CARBURETOR PARTS (MODEL "L-2")

6101A.	Carburetor float assy.	1917-21		75		Moslem	.6333FR	1
6101	Float with lever	1915-16		60		Marsh	.6333ER	1
6102	Throttle lever	1913-20		30		MJasma	.4836CR	
6103A.	Constant air supply lever	1913-20		30		Mlcheal	.6327CR	
6104	Gas valve cap	1910-16		15		Microdon	3005	
6105A.	Air valve cap	1915-16		30		Millola	.6357AR	
6105B.	Air valve cap	1917-20		30		Milltant	.6357BR	
6106	Float chamber	1915-16		2 25		Military	.4802CR	
6106A.	Float chamber	1917-20		1 00		Milltate	.4802DR	
6107	Mix chamber	1915-16		2 75		Milkly	.6340ER	
6107A.	Mix chamber	1917-20		2 50		Miltonic	.6340FR	
6108	Mix chamber gasket	1913-16		15		Milvine	.6367CR	
6108A.	Mix chamber gasket	1917-20		03		Mimesis	.6367DR	
6109	Throttle gate		Use 6068					
6110	Constant air supply gate	1913-14		05		Mimical	.6337BR	
6110A.	Constant air supply gate	1915-20		10		Mimosa	.6337CR	
6111	Mix chamber nut	1913-20		10		Mimulus	.4810BR	
6114	Gas valve retainer nut	1910-16		10		Minaret	.3027	
6115	Spray needle assembly	1910-21		40		Medal	.6335D	1
6118	Float to lever and throttle gate screw	1910-16		02		Minding	.3014	
6118A.	Float to lever screw	1917-20		03		Minnerva	.4853B	
6120	Throttle lever adjusting screw	1913-20		03		Mingler	.4520B	
6121	Throttle lever clamp screw	1910-20		03		Minikin	.4521BR	
6122	Gas valve operating lever shaft	1913-16		15		Minious	.6320DR	
6123	Air valve shaft	1915-20		20		Miniver	.6381AR	
6124A.	Spray needle sleeve		Order 6165					
6125	Constant air supply spring	1913-20		03		Minum	.6342C	
6126	Float valve seat	1915-16		15		Minutia	.6321CR	
6126A.	Float valve seat	1917-20		20		Miphka	.6321DR	
6127	Gas valve	1910-16		30		Mirific	.6324BR	
6127A.	Gasoline valve	1917-21		35		Moral	.6324CR	1
6128	Air valve	1915-20		30		Misartor	.6355AR	
6129	Float valve seat gasket	1915-16	Fibre	03		Miscall	.6322DR	
6129A.	Float valve seat gasket	1917-20	Fibre	03		Miscast	.6322ER	

Parts for 1909-16 Carburetors supplied by Byrne Kingston Co., Kokomo, Ind.

KINGSTON CARBURETOR (MODEL "L-4")

6150	Carburetor complete	1921-22		5 00		Mason	.553A1	1
6151	Drain valve body	1921-22		15		Mockish	.6328C	
6152	Float chamber	1921-22		50		Modish	.4802E	

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	Req. per Car
KINGSTON CARBURETOR (MODEL "L-4")—Continued								
6153	Mixing chamber	1921-22		\$ 2 50		Moellon	6340G	
6154	Carburetor Inlet elbow		Order 6055					
6155	Float with lever	1921-22		50		Medicate	6333B	1
6156	Float chamber gasket	1921-22		05		Mohock	555D	
6157	Mixing chamber gasket	1921-22		03		Monish	6367E	
6158	Float valve seat gasket	1921-22		03		Monitory	6322F	1
6159	Constant air supply lever assembly	1921-22		30		Moholl	6327D	
6160	Throttle lever assembly	1921-22		30		Mohsite	4836D	
6161	Spray needle assembly	1921-22	Order 6115					
6162	Drain valve body clamp nut	1921-22		05		Moldore	6395	
6163	Mixing chamber nut	1921-22		10		Moley	4810C	
6164	Constant air supply spring		Order 6125					
6165	Spray needle sleeve	1915-21		20		Molary	4812C	
6166	Float lever pin	1915-21		02		Mollah	6320C	
6167	Constant air supply plate	1921-22	Order 6068					
6168	Throttle plate	1921-22	Order 6209					
6169	Drain valve plug assy.	1915-21		10		Monest	6329B	
6170	Throttle lever adj. screw		Order 6120					
6171	Air valve stop assembly	1921-22		10		Moolah	6397	
6172	Float valve seat	1921-22		20		Morana	6321E	
6173	Air valve shaft assembly	1921-22		20		Morbose	6381B	
6174	Air valve	1921-22		30		Mordant	6355B	
6175	Gasoline valve	1921-22		35		Mediety	6324D	1

FORD CARBURETOR (MODEL "NH")

6200B	Carburetor	1920-22		5 00		Meconate	553A4	1
6201	Float with lever	1920-22		40		Mutage	6333B	1
6202B	Float chamber and bushing assembly	1920-22		50		Meander	6318B	
6203	Gasket—float chamber	1920-22		03		Meazling	555B	
6204	Gasket—spray nozzle	1920-22		01		Megalia	4820B	
6205	Gasket—mixer chamber	1920-22		03		Mehelah	6327B	
6206	Lever—throttle		Order 6070					
6206B	Lever—aux. throttle		Order 6077					
6207B	Mixer chamber	1920-22		2 50		Melange	6343R	
6208	Adj. needle clamp nut	1920-22		05		Melanic	4812B	
6209	Throttle plate	1920-22		05		Mellor	4517B	
6210	Float lever pin	1920-22		01		Melissa	6320B	
6211	Float chamber screw	1920-22		10		Meniver	6284	
6212	Float valve seat	1920-22		10		Mercify	6321B	
6213	Spray needle assembly	1920-22		10		Mutiny	6335B	1
6214B	Spray needle	1920-22		25		Mercury	6341C	
6215	Air passage vent plug	1920-22		05		Merils	6273R	
6216	Drain valve plug and handle	1916-22		10		Merops	6329	
6217	Throttle lever stop screw		Order 6064					
6218	Aux. throttle lever spring		Order 6076					
6219	Float valve seat gasket—fibre	1920-22		01		Mesapia	6322C	
6220	Gasoline inlet needle	1920-22	Order 4453A					

CARBURETOR ATTACHMENTS

4127A	Carb. adj. rod brkt	1909-22	On dash	05		Lastage	1357	1
4129A	Carb. adjusting rod	1909-22		15		Latten	7920	1
4130	Carb. flange bolt	1909-22	Order 3072					
4130B	Carb. flange bolt nut	1909-22	Order 3066B					
4134	Carb. flange gasket	1909-22		05	MH	Lecturn	1380B	1
4431	Carb. priming rod	1909-22		05		Loach	2000	1
4582	Carb. hot air pipe	1912-22		20		Monkey	686	1
4583	Priming bell crank	1919-22	Starter type	10		Tenet	7691	1
4585	Priming rod plate	1919-20	Coupe starter type	10		Thrum	7664	1
4586	Priming rod plate	1919-20	Sedan starter type	10		Thruse	7665	1
4587B	Priming rod	1919-22	Sedan starter type	15		Thule	6628	1
4588B	Priming rod	1919-22	Coupe, T. C. & Rbt. starter type	15		Thumb	6627	1
4588C	Priming rod	1922	Four-door Sedan	15		Thuyya	6630	1
4589	Priming rod	1919-22	Starter type	05		Thunder	8797B	1
4589B	Priming rod	1922		05		Thuja	8797A	1

FENDERS—56 INCH TREAD

4800B	Front fender—right	1917-22		4 00	MH	Nook	7976	1
4801B	Front fender—left	1917-22		4 00	MH	Noose	7977	1
4802F	Rear fender—right	1917-22		3 50	MH	Norse	8850	1
4802C	Rear fender—right	1922	Four-door Sedan	3 50	MH	Nosle	7730	1
4804F	Rear fender—left	1917-22		3 50	MH	Nougat	8851	1
4803C	Rear fender—left	1922	Four-door Sedan	3 50	MH	Nousel	7731	1
4804D	Rear fender iron—R & L	1913-22	Touring car	15		Smile	5405	2

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Specifications	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
FENDERS—56 INCH TREAD—Continued									
4804E	Rear fender iron—right	1913-22	Torpedo & Coupelet	\$ 0 50		Shire	5563	1	
4804F	Rear fender iron—left	1913-22	Torpedo & Coupelet	50		Shrub	5390	1	
4804C	Rear fender iron—R & L	1916-17	Sedan	25		Nubble	8154A	2	
4804K	Fender iron—R & L	1918-22	Sedan	15		Shoggle	8154B	2	
4804L	Rear fender iron	1921-22	Touring	10		Shophan	7395	2	
4805B	Rear fender iron bolt	1915-22	Touring, $\frac{1}{8}$ " x $\frac{3}{4}$ "	03		Shorage	7171	6	
4805C	Rear fender iron bolt nut	1915-22	$\frac{1}{8}$ " x $1\frac{1}{4}$ " x 18 thds	02		Gram	341		
4806B	Fender eye bolt	1909-22		05		Perpsin	1942	4	
4806C	Fender eye bolt washer	1909-22		01		Perish	1943	4	
4806D	Fender eye bolt nut	1909-22	Order 2825B						
4808	Front fender iron bolt (side)	1910-22	$\frac{3}{8}$ " x $\frac{3}{4}$ "	03		Module	1323	2	
4808B	Front fender iron bolt (bottom)	1910-22	$\frac{3}{8}$ " x $1\frac{1}{4}$ "	03		Griffin	347	2	
4808D	Front fender iron bolt nut	1910-22	Order 2515						
4808C	Front fender apron to frame bolt	1915-22	$\frac{1}{4}$ " x $\frac{5}{8}$ "	03		Placld	4088	4	
4808E	Front fender apron to frame bolt nut	1915-22	Order 3088E						
4809	Front fender iron—R&L	1909-22		60		Sistom	343	2	
4850	Front fender apron brkt.—R	1917-22		05		Sritch	8854	1	
4851	Front fender apron brkt.—L	1917-22		05		Sirius	8855	1	
4852	Front fender iron brkt.—R	1915-22		15		Sirrah	7984	1	
4853	Front fender iron brkt.—L	1915-22		15		Siskln	7998	1	
4854	Rear fender iron brkt.	1915-22		15		Sistine	7482	2	
4855	Rear fender to R. B. shield brkt.	1915-22		05		Sivan	7994	2	

RUNNING BOARDS AND SHIELDS—56 INCH TREAD


4812	Running board—R	1909-22	44 $\frac{1}{8}$ " long	1 50	MH	Shrew	5418	1	
4813	Running board—L	1909-22		1 50	MH	Shrilly	5480	1	
4814C	R. B. shield—R	1917-22		2 40	MH	Shrine	7986	1	
4814D	R. B. shield—L	1922	Four-door Sedan	2 40	MH	Shuhite	7747	1	
4815C	R. B. shield—L	1917-22		2 40	MH	Shroud	7987	1	
4815D	R. B. shield—L	1922	Four-door Sedan	2 40	MH	Shunites	7748	1	
4816	R. B. truss rod—front with nuts	1909-22		40	MH	Skybird	5804	1	
4817	R. B. truss rod—rear with nuts	1909-22		40	MH	Skyman	5805	1	
4817B	Truss rod nut	1909-22		03		Skyward	339	4	
4818	Running board bracket	1909-22		80		Skyhawk	336	4	
4818B	R. B. bracket assy			1 10		Skyish	2926	2	
4819	R. B. to rear fender bolt	1909-20		03		Musty	1344B	4	
4819B	R. B. to rear fender bolt	1921-22	$\frac{3}{8}$ " x $1\frac{3}{8}$ "	03		Rascal	8161	4	
4819C	R. B. to rear fender nut	1909-22	Order 3088E						
4819D	R. B. to rear fender nut	1909-22	Order 3514						
4820	R. B. to front fender bolt and nut	1909-20	Order 4808C and 3088E						
4820C	R. B. to front fender bolt	1921-22	Order 4805B						
4821	R. B. to shield clamp			05		Skulk	5478		

RUNNING BOARD—TRUCK

4830	Running board—R. or L.	1918-22		50	MH	Gull	TT-5418	2	
4831	Running board bracket	1918-22		35		Heck	TT-2926	4	
4832	R. B. bracket brace	1918-22		15		Hedge	TT-2927	2	
4833	R. B. bracket brace	1918-22		30		Hedging	TT-2929	1	
4834	R. B. bracket—rear	1918-22		35		Hecale	TT-2925		
4835	R. B. bracket and brace assy.—frt	1918-22		50		Hedonic	TT-2928		
4836	R. B. bracket and brace assy.—rear	1918-22		1 10		Hehmin	TT-2930		

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts




Part No.	Name of Part	Year	Price	Tax Status	Code Word	Fac. No.	Req. per Car
FORD SPARK COIL							
5000	Coil (includes switch)	1909-22	\$ 9 50	MH	Negus	1383	1
5001	Coil (starter type)—less switch	1909-22	8 75		Neil	1383B	1
5002	Coil box with cover (includes switch)	1914-22	2 50	MH	Nenia	5858	1
5003	Coil box with cover—less switch	1919-22	1 75	MH	Nepeta	5858B	1
5004	Coil box cover	1915-22	30		Neptune	7910	1
5005B	Switch cover	1918-22	10		Nonage	5835B	1
5006	Switch plug	1914-22	05		Nopal	5815A	1
5007	Coil units, 3 1/2" x 2 1/4" x 5"	1914-22	1 75	MH	Noggin	5845	4
5008	Vibrator with tungsten point	1914-22	10		Nonce	6797	4
5009	Vibrator bridge with tungsten point	1914-22	10		Novia	6702	4
SWITCH							
5010	Switch assembly (on coil)	1914-22	75		Nidor	5873	1
5012	Switch (ignition) (on instr. board)	1919-22	1 10		Tolad	7675E	1
5013B	Keys (switch)—give serial number	1919-22	10		Thrall	5815C	1
5014	Starting switch (on floor board)	1919-22	65	MH	Topaz	8792	1
5014B	Starting switch bracket bolt—long	1920-22	30		Toparch	8760	1
5014C	Starting switch bracket assembly	1922	30		Tophet	8696	1
5014E	Starting switch cover and plunger assy.	1922	35		Topical	8698	1
5015	Extension (starting switch plunger)	1919-22	10		Tetric	8793	1
AMMETER							
5016	Ammeter	1919-22	90		Tassel	7680	1
5017	Ammeter lens and rim	1919-22	20		Tensor	8105	1
5017B	Ammeter lens	1919-22	05		Tensure	8121	1
BENDIX DRIVE							
5018	Bendix	1919-22	5 00		Tattler	1883	1
5019	Head (Bendix)	1919-22	50		Thine	2007	1
5020	Key (Bendix)	1919-22	02		Tholl	1751	1
5021	Shaft and gear (Bendix)	1919-22	4 50		Thurl	2026	1
5022	Spring (Bendix)	1919-22	20		Tinge	2006	1
5023	Screw (Bendix shaft spring)	1919-22	10		Tinsel	1983	1
5024	Screw (Bendix head spring)	1919-22	05		Tipple	1781	1
5025	Washer (Bendix spring screw lock)	1919-22	03		Tipsy	1782	2
WIRING							
5026	Spark plug wire 15" No. 1 cyl.	1909-22	10	MH	Nohob	1365	1
5027	Spark plug wire (also magneto to coil) 11 1/2" No. 2 cyl.	1909-22	10	MH	Nachor	1366	1
5028	Spark plug wire, 8" No. 3 and 4 cyls.	1909-22	10	MH	Nalad	1376	2
5030	COMMUTATOR WIRE (non starter type)	1909-22	70	MH	Nandu	7502	1
*5030B	Commutator wire	1922	1 00	MH	Nantes	7502C	1
5031	Commutator wire (starter type)	1919-22	1 00	MH	Trifle	7502B	1
5033	Com. wire loom support	1909-22	03		Napple	1390	2
5033B	Commutator wire terminal retainer	1921-22	01		Nappy	2124	2
5033C	Wire on dash clip	1919-22	02		Naptha	7688	7
5034	Wire (ammeter to cut-out) Sedan 33"	1919	15	MH	Topic	7683A	1
5035	Wire (ammeter to cut-out) Sedan 51"	1919-22	20	MH	Topmast	7683B	1
5036	Wire (ammeter to cut-out) Coupe 23"	1919	15	MH	Torch	7684A	1
5037	Wire (ammeter to cut-out) Coupe 46"	1919-22	20	MH	Rabid	7684B	1
5038	Wire (ammeter to ignition switch) 5 3/4"	1919-22	10	MH	Torpid	7681	1
5039	Wire (generator to cut-out) 23"	1919	15	MH	Trash	7687	1
5040	Wire (terminal block to switch) 35"	1919-22	05	MH	Trench	8894B	1
5041	Wire (lighting)	1919-22	90	MH	Tromp	7682B	1
5041B	Lighting wire—truck	1921-22	1 00	MH	Tronage	TT7682	1
*5041C	Lighting wire	1922	55	MH	Tronco	7661	1
5042	Wire (switch) Sedan	1919-22	70	MH	Troth	7685B	1
5043	Wire (switch)	1919-22	70	MH	Truce	7686B	1
*5043B	Switch wire	1922	50	MH	Trudge	7660	1
5044	Block (terminal)	1919-22	05		Teller	1950	1
5045	Screw (terminal block to dash)	1919-22	01		Tocsin	2073	2
5046	Cable (battery to switch) 28 7/8"	1919-22	80	MH	Tepor	1889B	1
5046C	Battery to switch cable—truck 24 1/2"	1921-22	80	MH	Teraph	TT1889	1
5047	Cable (battery to switch) 33 1/4"	1920	85	MH	Pantry	1889C	1
5047B	Battery to switch cable support—truck	1920-22	10		Teredo	2116	1
5047C	Battery to switch cable support	1920-22	10		Terete	2112	1
5047D	Battery to switch cable support bush	1920-22	05		Tereus	2113	1
5047E	Battery to switch cable sleeve	1921-22	05		Tergum	2120	1
5048	Cable (ground) 20"	1919	70	MH	Terse	1890A	1
5049	Cable (ground) 9 1/2"	1919-22	50	MH	Testa	1890B	1
5050	Cable (ground) 11 1/2"	1920	60	MH	Parish	1890C	1
5051	Cable (switch to motor) 27 1/2"	1919-22	60	MH	Tether	1891	1
5051B	Switch to motor cable sleeve	1921-22	30		Tetlish	2119	1
5052	Bolt (battery cable terminal)	1919-22	04		Pelvis	1937	2
5052B	Nut (battery cable term. bolt)	1919-22	03		Pennon	1938	2
CUT-OUTS							
5054	Cut-out (electric) dash type	1919	1 10	MH	Tenant	7677AR	1
5055	Cut-out (electric)	1919-22	1 00	MH	Tendril	7677B	1

*Used on cars without starter with switch on instrument panel.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts



Part No.	Name of Part	Year	Price	Tax Status	Code Word No.	Fac. No.	Req. per Car
STARTER PARTS							
5056	Gasket (motor mounting)	1919-22	\$ 0	02	Theme	1768	
5057	Gasket (gen. head)	1919-22	02		Thane	1774	
5058	Screw (gen. mounting, short)	1919-22	03		Thrack	1755	
5059	Screw (Bendix cover)	1919-22	01		Thrave	1765	
5060	Screw (term. block to wire)	1919-22	01		Thwack	2015	
5061	Screw (ammeter to plate)	1919-22	01		Thwart	5819	
5062	Screw (motor mounting)	1919-22	02		Thymet	5510	
STARTING MOTOR AND PARTS							
5099	Motor (starting)	1919-22	15 00	MH	Tidbit	1877	
5100	Armature	1919-22	5 00		Tabid	1940	
5101	Band (cover)	1919-22	10		Tallage	1801C	
5102	Bracket (brush end)	1919-22	30		Talmen	1868	
5103	Bracket assem. (mounting)	1919-22	1 30		Tawny	2037	
5104	Brush	1919-22	30		Tanvat	1806	
5105	Bushing (shaft, rear)	1919-22	30		Tapnet	1759	
5106	Bushing (shaft, front)	1919-22	10		Tapster	1789	
5107	Coil assembly (field)	1919-22	2 00		Targum	1871	
5108	Holder assem. (brush)	1919-22	60		Talpa	1864B	
5109	Insulator (terminal, outer)	1919-22	03		Talus	1795	
5110	Insulator (terminal, inner)	1919-22	02		Tambac	1794	
5112	Nut (terminal)	1919-22	03		Tambour	1791	
5113	Screw (field)	1919-22	02		Tamis	1788	
5114	Screw (brush end bracket to yoke)	1919-22	05doz.		Tamkin	1808	
5115	Spring (brush tension)	1919-22	05		Tampon	1809	
5116	Washer (terminal)	1919-22	01		Tarras	1792	
5117	Washer (terminal, inner, steel)	1919-22	02		Tarsic	1798	
5118	Yoke (motor) assembly	1919-22	3 50		Tartly	1852	
GENERATOR AND PARTS							
5119	Generator	1919-22	15 00	MH	Tetter	1879	
5120	Armature (less bearings)	1919-22	5 00		Tanling	1925	
5121	Bearing (small)	1919-22	1 20		Tannic	1838	
5122	Bearing (large)	1919-22	1 45		Tantrum	1841	
5123	Bolt (terminal)	1919-22	03		Tegmen	1836	
5124	Bracket (brush end)	1919-22	30		Telary	1894	
5125	Brush (large)	1919-22	20		Tempean	1844	
5126	Brush (small)	1919-22	20		Tempter	1845	
5127	Disc (large bearing)	1919-22	03		Tendry	1847	
5128	Felt (small bearing)	1919-22	02		Tenter	2033	
5130	Head	1919-22	50		Tercel	2044	
5131B.	Holder (small brush)	1919-22	15		Terrom	1821	
5132B.	Ring (brush holder)	1919-22	05		Terrapin	1996	
5132C.	Holder assem. (brush)	1919-22	60		Ternary	1865	
5132D.	Holder assem. (brush) less small brush holder	1919-22	45		Ternate	1920	
5133	Insulator (terminal, outer)	1919-22	03		Tersh	1827	
5134	Nut (terminal)	1919-22	03		Tiling	1818	
5134B.	Nut (small brush holder stud)	1919-22	01		Tilmus	6754	
5135	Oiler	1919-22	10		Testern	1837	
5136	Pin (pinion to shaft)	1919-22	05doz.		Testudo	1750	
5137	Pinion	1919-22	40		Throng	1752	
5138	Retainer (small bearing felt)	1919-22	02		Theban	1832	
5139	Spring (large brush)	1919-22	05		Theist	1967	
5140	Spring (small brush)	1919-22	05		Themis	1988	
5141	Stud (small brush holder)	1919-20	05		Theon	1823B	
5141B.	Stud (small brush holder)	1919-22	02		Theoric	1823C	
5142	Washer (terminal)	1919-22	02		Thermal	1831	
5142B.	Washer (small brush holder stud)	1919-22	05doz.		Phrase	2058	
5143	Winding assembly (field)	1919-22	1 50		Tholus	1978	
5144	Wire (brush to terminal)	1919-22	06		Thorp	1851	
5145	Yoke (generator) assembly	1919-22	3 00		Thorite	1887	
BATTERY BRACKET AND PARTS							
5150	Bracket assem.	1919-22	90		Tattoo	8841	
5151	Bolt (clamp)	1919-22	03		Rusric	8846	
5151B.	Nut (clamp bolt) Order 2825B	1919-22					
5152	Clamp	1919-22	05		Tetrad	8844	
5152B.	Battery clamp—truck	1921-22	05		Thecal	8844B	2
5153	Battery support angle—truck	1921-22	10		TheineTT8816	1	
5154	Battery box support—truck	1921-22	20		TheanalTT8817	2	
5155	Battery clamp support—R—truck	1921-22	10		TheodasTT8818	1	
5156	Battery clamp support—L—truck	1921-22	10		TheorboTT8819	1	
5158	Battery box—less cover	1921-22	75		Twaite	7671	1
5159	Battery box cover assembly	1921-22	75		Twangle	5491	1
5160	Battery box cover door	1921-22	15		Tobline	5493	
BATTERY (FORD)							
5175	Battery	1919-22	20 00	MH	Twain	7670	1
5176	Battery case assembly	1919-22	1 25		Tocher	5434	
5177	Cell connector	1919-22	15		Tockast	5435	

†Also for generator.

‡Armature may be exchanged with dealer at \$4.00.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Price	Tax Status	Code Word	Fac. No.	Req. per Car
BATTERY (FORD)—Continued							
5178	Cell cover	1919-22	\$ 0 45		Toddler	5436A	AR...
5178B	Cell cover	1921-22	45		Tofus	5436B	...
5179	Terminal post gasket	1919-22	01		Tolasa	5437A	AR...
5179B	Terminal post gasket	1921-22	01		Tomatus	5437B	...
5180	Rubber jar	1919-22	1 25		Tolerant	5438	...
5181	Terminal post nut	1919-22	04		Tollage	5439A	AR...
5181B	Terminal post nut	1921-22	04		Tompson	5439B	...
5182	Negative group assembly	1919-22	2 25		Tolsey	5440A	AR...
5182B	Negative group assembly	1921-22	2 25		Tonsure	5440B	...
5183	Positive group assembly	1919-22	2 25		Toman	5441A	AR...
5183B	Positive group assembly	1921-22	2 25		Toom	5441B	...
5184	Filler plug with gasket	1919-22	15		Tombac	5444A	AR...
5184B	Filler plug with gasket	1921-22	15		Torment	5444B	...
5185	Plate separator	1919-22	05		Tomrig	5445	...
5186	Positive plate	1919-22	30		Tomyris	5427A	AR...
5186B	Positive plate	1921-22	30		Tormina	5427B	...
5187	Negative plate	1919-22	30		Tonguy	5428A	AR...
5187B	Negative plate	1921-22	30		Torose	5428B	...
5188	Negative terminal post	1919-22	25		Torpent	5425A	AR...
5188B	Negative terminal post	1921-22	25		Torpify	5425B	...
5189	Positive terminal post	1919-22	25		Torsel	5426A	AR...
5189B	Positive terminal post	1921-22	25		Tortive	5426B	...

SPARK PLUGS

5200	Spark plug (Bethlehem)	1909-22	60		Tirrit	1386A2	4 4
5201	Spark plug "Ford" (Champion)	1909-22	60		Tirzah	1386A3	4 4
5202	Spark plug porcelain (Bethlehem)	1909-22	35		Titia	3761	4 4
5203	Spark plug porcelain (Champion)	1909-22	30		Tliting	3760A	4 4
5203B	Spark plug porcelain "Ford" (Champion)	1909-22	30		Titrate	3760C	4 4

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Price	Tax Status	Code Word	Fac. No.	No. per Car	Req.
REPAIR TOOLS								
1349	Hub cap wrench	Regular equipment	\$ 0 15		Pacal	1349		
1387	Adjustable wrench	Regular equipment	40		Pacos	1387		
1903	Pliers	Regular equipment	25		Paddy	1903		
1917	Double end wrench	Regular equipment	20		Pagan	1917		
2335	Spark plug & cyl. head bolt wrench	Regular equipment	50		Pavid	5893		
2336	Tool roll	Regular equipment	30		Pawky	1979		
2337	Oil can	Regular equipment	25		Paxos	1384		
2338	Tire pump	Regular equipment	1 50	MH	Payser	1368		
2340	Tire irons, each	Regular equipment	15		Pelage	4069		
2343	Jack	Regular equipment	1 50		Poser	3389		
TT4069X	Tire iron (large). Old No. 5Z-322		45		Pathos			
3Z-698	Cylinder water outlet connecting screw brace wrench		each 40		Pusil			
	Brake shoe support bolt brace wrench							
	D/S bearing housing screw brace wrench							
3Z-775	3/4" socket wrench		30		Pallan			
5Z-152	Rear axle housing bolt nut wrench. Old No. 3Z-616		40		Parvis			
5Z-153	Socket wrench for crank shaft bearing bolt nut. Old No. 3Z-644		60		Passim			
5Z-154	Body bracket connecting bolt R.&L. wrench. Old No. 3Z-719		30		Proverb			
5Z-155	3/8" L. socket wrench. Old No. 3Z-645 and 3Z-775		45		Pastel			
5Z-156	Crank shaft bearing bolt wrench. Old No. 3Z-782		50		Poloy			
5Z-157	Connecting rod cap bolt nut wrench (Cylinder No. 4). Old No. 3Z-2010		40		Quack			
5Z-158	Drive shaft housing stud nut wrench for 3/4" nut. Old No. 3Z-620		50		Parent			
5Z-159	Connecting rod T wrench. Old No. 3Z-783		55		Pygmy			
5Z-160	3/8" T socket wrench. Old No. 3Z-643		75		Parfit			
5Z-161	Body bracket connecting bolt T wrench front and center. Old No. 3Z-673		55		Prater			
5Z-162	Large cam gear lock nut wrench. Old No. 3Z-655		55		Pavan			
5Z-163	Generator third brush adjusting wrench. Old No. 3Z-4137		20		Quaver			
5Z-165	Drive shaft pinion wrench. Old No. 3Z-790		65		Puzzle			
5Z-193	Spline cone adjusting open end wrench. Old No. 3Z-699		25		Profile			
5Z-195	3/8" open end wrench. Old No. 3Z-646		25		Pastor			
5Z-196	Rear axle entering wrench. Old No. 3Z-627		30		Potlon			
5Z-204	Exhaust pack nut open end wrench. Old No. 3Z-624		1 00		Potash			
5Z-206	Rear axle nut open end wrench. Old No. 3Z-675		65		Porite			
5Z-209	Connecting rod clamp screw wrench. Old No. 3Z-647		45		Parrott			
5Z-210	Fly wheel cap screw wrench. Old No. 3Z-1179		75		Paimy			
5Z-212	Body bracket connecting bolt holding open end wrench. Old No. 3Z-686		25		Preen			
5Z-232	Spline gear bushing driver. Old No. 3Z-1956		30		Quinsky			
5Z-249	Generator third brush adjusting wrench. New Style		70		Quatch			
5Z-280	Valve grinder. Old No. 3Z-604		25		Palster			
5Z-285	4 1/2" hex. brace wrench. Old No. 3Z-786		75		Prince			
5Z-286	Rear axle nut and housing plug brace wrench. Old No. 3Z-751		80		Pulpit			
5Z-287	Rear wheel puller assembly. Old No. 3Z-612		1 00		Panary			
5Z-289	3 1/2" brace socket wrench. Old No. 3Z-1173 and 3Z-1223B		75		Parsee			
5Z-290	Piston ring squeezer. Old No. 3Z-652		30		Pattle			
5Z-314	Transmission clutch disc drum puller. Old No. 3Z-614		75		Papaw			
5Z-319	Valve spring lifter. Old No. 3Z-4730		30		Palpus			
5Z-323	Bendix shaft head puller. Old No. 3Z-4712		1 00		Queach			
5Z-324	Trans. band ratchet wrench. Old No. 3Z-2034		50		Poplin			
5Z-325	Connecting rod cap bolt nut brace wrench with universal joint for No. 4 connecting rod. Old No. 3Z-2304		2 50		Quadra			
5Z-326	Small time gear and trans. driven gear puller. Old No. 3Z-611		1 50		Pantile			
5Z-361	Large time gear puller. Old No. 16Z-4992		9 00		Queasy			
5Z-362	Cam gear puller (3-spoke design)		6 50		Pantler			
5Z-457	Valve seat reamer. Old No. 20Z-340		2 50		Papula			
20Z-340-1	Valve seat reamer cutter. Old No. 3Z-617-2		1 50		Papur			
21Z-356	Valve seat reamer handle. Old No. 3Z-617-3		1 00		Pasha			

REPAIR TOOLS—TRUCK

5Z-288	Rear wheel puller assembly, Old No. 3Z-2257	Code	Price
3389X	Jack	Hock	\$ 1 20
		Hog	2 50

COTTER PINS


	Fac. No.		Fac. No.
3/32" x 1" cotter pins	421	3/32" x 1 1/2" cotter pins	66
1/4" x 3/4" cotter pins	753	1/4" x 1 1/2" cotter pins	544
1/8" x 1" cotter pins	82	3/32" x 5/8" cotter pins	88
Price, per dozen			05
Price, per gross			25
Price, per thousand			75

ELECTRIC HORN


6432BX	Electric horn complete	Ulcer	2 50
6432CX	Electric horn complete (battery type)	Ulema	2 50
7915X	Electric horn terminal wire 9'	Una	05 MH
7917BX	Electric horn to switch wire 35 1/2'	Ultra	15 MH
8028X	Horn switch assembly	Vallant	30 MH

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.


Insist upon genuine Ford Parts




6511-EX



6594-BX



6594-HX




6511-HX



6576-BX



6592-X



6585-X



6574-X




6576-HX




6572-X




8028-X




6578-X




7487-AX




7489-X



6586-X



7490-X




6460-X



8892-X




6599-X



6561-X




6956-X




6957-X



6484-BX



7669-X



6568-X

Part No.	Name of Part	Year	Code	Price	Tax Status
ELECTRIC HEAD LAMPS (STANDARD 1915-22)					
6511CX	Head lamp assembly—two bulb type—per pair		Unport.	\$ 5 00	
6511HX	Head lamp assembly—per pair		Unction	6 00	
6511KX	Head lamp assembly—per pair		Unicorn	6 00	
6594AX	Head lamp door assembly—used with 6511DX		Union	60	
6594HX	Head lamp door assembly—with refracting lens		Unition	70	
6589X	Head lamp switch assembly—with screws		Ural	35	MH
8650X	Head lamp and horn switch assembly		Urith	40	MH
*8892AX	Dimmer resistance coil with wires		Urbox	60	MH
*8892BX	Dimmer assembly		Ureter	50	MH
*8890X	Dimmer cover		Uretic	10	
6572AX	Head lamp bulb—9-volt, 18 c. p., double contact, used with magneto without dimmer	1915-18	Urban	40	
6572BX	Head lamp bulb—6-8-volt, 16 c. p., double contact, used with dimmer T8892X without starter or with dimmer T7320X with starter and T6576X or T6576BX lens				
6572CX	Head lamp bulb—6-8-volt, 16 c. p., single contact, used with storage battery and T6576X or T6576BX lens	1918-20	Uraca	40	
6572EX	Head lamp bulb—6-8-volt, bright 18 c. p., dim 2 3/4 c. p., dble contact, dble filament, used with T6576BX lens	1921	Urlea	45	
6572HX	Head lamp bulb—6-8-volt, bright 21 c. p., dim 1 1/2 c. p., dble contact, dble filament, used with T6576HX lens	1922	Urlonte	45	
6572KX	Head lamp bulb—6-8-volt, 21 c. p., double contact, used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens	1922	Urites	40	
6578X	Head lamp door lens gasket		Urchin	05	
6576X	Head lamp door lens—8 1/2" used with 6511DX		Urn	20	
6576BX	Head lamp door lens—8 1/2" —with green visor		Uredo	30	
6576HX	Head lamp lens—refracting, per pair in carton	1922	Uretic	60	
6592X	Head lamp plug—with thimble		Urus	15	
6585AX	Head lamp reflector		Urva	75	
6585BX	Head lamp reflector (dimmer type)		Urbox	90	
6580X	Head lamp focusing screw		Utas	03	
6591X	Head lamp focusing spring screw		Ute	02	
6574X	Head lamp bulb socket		Vagrant	15	
6574BX	Head lamp plug socket		Vaisya	15	
6586X	Head lamp reflector spring		Vail	05	
7487X	Switch to terminal wire—11 3/4" long		Valise	05	MH
7489X	Lamp to lamp wire—40" long		Vallum	10	MH
7490X	Lamp to ground wire—10 3/4" long		Vamp	05	MH
2122X	Head lamp wire bushing		Valvate	03	
4082X	Head lamp and tail lamp wire bushing		Valvule	01	

SIDE OIL AND TAIL LAMPS—1915-22

6561X	Side oil lamp, per pair		Van	4 50	
6568X	Tail lamp		Vandal	2 50	
7669X	Electric tail lamp assembly		Vanquish	1 00	
6484AX	Tail lamp red lens	1915-22	Vault	15	
6484BX	Electric tail lamp red lens		Vales	15	
6520X	Tail lamp and head lamp dimmer bulb—6-8-volt—2 1/4 c. p., single contact		Valhalla	25	
6495X	Electric tail lamp bulb socket		Valguis	20	
2107X	Tail lamp wire clip		Vanesa	01	
2108X	Tail lamp wire spring		Vanfoss	03	
6409X	Tail lamp wire bushing assembly		Vanglo	03	
6410X	Tail lamp wire bushing support		Vanilla	01	
TT8821X	Tail lamp to ground wire assembly		Vanity	15	MH
6599X	Side oil and tail lamp fount		Vane	50	
6956X	Side oil lamp door		Vanish	50	
6957X	Tail lamp door		Vapid	50	
6460X	Lamp burner		Varix	25	
6483X	Side oil lamp door lens		Vat	15	
6392X	Lamp wick		Vega	05	

TOURING CAR AND TORPEDO WINDSHIELDS—1915-22

†7840AX	Windshield assembly, less brackets, bolts, nuts and washers		Vender	13 50	MH
7818BX	Windshield hinge assembly—right	1917-22	Vent	30	
7819BX	Windshield hinge assembly—left	1917-22	Verb	30	
7820BX	Windshield frame assembly—upper	1917-22	Vermin	1 50	
7822BX	Windshield upper half assembly	1917-22	Verst	6 50	MH
7823ARX	Windshield lower half assembly	1915-22	Vertex	7 00	MH
7802ARX	Windshield lower frame only	1915-22	Venge	1 00	
7803ARX	Windshield lower frame filler block	1915-22	Verve	15	
7888ARX	Windshield block (frame filler)—upper	1917-22	Vesper	15	
7845ARX	Windshield bracket—right	1915-22	Vestal	50	
7845BX	Windshield bracket—right	1919-22	Vestado	50	
7846ARX	Windshield bracket—left	1915-22	Vestry	50	
7846BX	Windshield bracket—left	1919-22	Vexil	50	
7824ARX	Windshield glass clamp	1915-22	Veto	02	
7887X	Windshield frame—upper	1917-22	Vicar	75	
3827X	Windshield top snap loop	1915-22	Vine	05	

*Used on cars without starter with switch on instrument panel.

†Order 7845X-7846X extra for 1915-16 cars.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Code	Price	Tax Status
TOURING CAR AND TORPEDO WINDSHIELDS—1915-22—Continued					
1154X	Windshield hinge bolt nut (Order 3929C)				
2449BX	Windshield glass clamp screw	1915-22	Viol	\$ 0 01	
2257BX	Windshield hinge to frame screw	1915-22	Virent	02	
292X	Windshield hinge spring (Order 2742)				
7851ARX	Windshield upper glass stop—nickel	1915-22	Vise	25	
7852ARX	Windshield lower glass stop—nickel	1915-22	Vitals	25	
7808X	Windshield hinge thimble	1915-22	Vitex	03	
TOURING CAR AND ROADSTER WINDSHIELDS—1922					
T-7836X	Anti-rattler (windshield)	1922	Veadar	15	
6455X	Bolt (windshield bracket to instrument panel)	1922	Veclius	03	
7837X	Bracket (windshield) assembly—R. H.	1922	Vector	1 50	
7938X	Bracket (windshield) assembly—L. H.	1922	Vedette	1 50	
†7891X	Bracket (side oil lamp)	1922	Vedlos	35	
9066X	Channel (windshield)—center	1922	Vegete	35	
7802BX	Frame (windshield) assembly—lower	1922	Vehmic	1 00	
7887CX	Frame (windshield) assembly—upper	1922	Vejovis	1 00	
7888BX	Filler (windshield upper frame)—lower	1922	Velina	10	
7847X	Filler (windshield upper frame)—upper	1922	Velites	10	
7803BX	Filler (windshield lower frame)	1922	Vellito	15	
7825X	Nut (windshield clamp stud wing)	1922	Vendue	15	
7842X	Nut (windshield cone lock)	1922	Venedi	02	
1307X	Nut (windshield brkt. to instrument panel bolt) lower	1922	Venene	05	
7851BX	Retainer (windshield glass)—upper	1922	Venew	20	
7852BX	Retainer (windshield glass)—lower	1922	Ventose	20	
7826X	Stud (windshield frame clamping)	1922	Ventore	03	
7833X	Washer (windshield clamp stud nut)	1922	Vepicos	02	
7840BX	Windshield assembly	1922	Veragri	15 50	MH
7822CX	Windshield (upper half) assembly	1922	Verbose	6 50	MH
7823BX	Windshield (lower half)	1922	Verity	6 00	MH
†7811X	Windshield brkt. to body bolt	1922	Veritas	02	
TOURING CAR TOPS—1915-22					
*7940ARX	Touring car top complete	1915-22	Warm		MH
6882ARX	Touring car storm curtain (R. H.)	1915-22	Warp	2 00	MH
6883ARX	Touring car storm curtain (L. H.)	1915-22	Warren	2 00	MH
4966BRX	Touring car side curtain (R. H.)	1915-22	Wart	2 50	MH
4967BRX	Touring car side curtain (L. H.)	1915-22	Wash	2 50	MH
6894ARX	Touring car center deck complete	1915-22	Wasp	7 00	MH
6886ARX	Touring car center deck only, 91 1/2" x 50"	1915-22	Waste	4 00	
8913ARX	Touring car side quarter (R. H.)	1915-22	Watch	1 50	
8914ARX	Touring car side quarter (L. H.)	1915-22	Water	1 50	
6815ARX	Touring car side quarter pad	1915-22	Watt	1 00	
6940ARX	Touring car back stay and curtain assembly	1915-22	Wax	3 00	MH
8973ARX	Touring car front and rear extension rib	1918-22	Yawn	40	
8974ARX	Touring car front and rear upright rib	1918-22	Yell	40	
6832ARX	Touring car bow separator	1918-22	Whelp	05	
6860BRX	Touring car front extension rib socket (R. H.)	1918-22	Wealth	1 00	
6861BRX	Touring car front extension rib socket (L. H.)	1918-22	Weary	1 00	
3884BRX	Touring car rear extension rib socket (R. H.)	1918-22	Wedding	1 00	
3885BRX	Touring car rear extension rib socket (L. H.)	1918-22	Welt	1 00	
6862BRX	Touring car front upright rib socket (R. H.)	1918-22	Whig	1 00	
6863BRX	Touring car front upright rib socket (L. H.)	1918-22	Whilk	1 00	
3882BRX	Touring car rear upright rib socket (R. H.)	1918-22	Yauk	1 00	
3883BRX	Touring car rear upright rib socket (L. H.)	1918-22	Yawl	1 00	
7831ARX	Curtain to windshield hook	1915-22	Whame	02	
7832X	Curtain to body hook	1915-22	Whaul	02	
6837X	Touring car key strap assembly	1913-18	Whale	05	
8992X	Rib socket cotter	1918-22	Wheeze	05	
3924RX	Touring car top to windshield strap assembly	1915-22	Wharf	25	
3629ARX	Touring car rear stay strap assembly complete	1913-21	Whea	40	
3629BRX	Touring car rear stay strap assembly complete	1921-22	Whiffet	40	
6925X	Touring car curtain to windshield strap assembly	1915-19	Whine	10	
6926X	Touring car curtain lamp bracket strap assembly	1915-19	Whip	10	
3754X	Touring car curtain glove fastener assembly	1913-22	Whist	05	
6829BX	Touring car extension support—upper	1918-22	Yelk	10	
6830BX	Touring car extension support—lower	1918-22	Yeoman	05	
8937X	Touring car top snap fastener—single	1917-22	Whig	05	
8938X	Touring car top snap fastener—double	1917-22	Willow	05	
3314ARX	Touring car top prop rest with strap	1913-22	Wind	60	
3858X	Touring car top prop rest arm	1913-21	Wine	25	
3624X	Touring car bow socket to seat iron japanned nut	1913-22	Wing	05	
6682X	Curtain celluloid 20" x 50"—.015 thick	1913-22	Wink	2 20	
6682X	Curtain celluloid 10" x 18"—.015 thick	1913-22	Winter	40	
4981ARX	Touring car top visor	1920-22	Wizen	50	
8940X	Curtain fastener eyelet	1917-22	Wrack	01	
8943X	Curtain fastener eyelet washer	1917-22	Wrasse	01	
TOURING CAR TOPS—1922					
3573X	Brace (top extension)—R. H.	1922	Viable	35	
3574X	Brace (top extension)—L. H.	1922	Viaca	35	
**3588X	Top clamping bracket assembly	1922	Vladrus	30	
**6902X	Glove fastener button	1922	Vizler	02	
††6940BRX	Curtain (rear) assembly	1922	Viaeduct	2 50	MH
6940CX	Curtain (rear) assembly	1922	Viallis	2 50	MH
††4966CRX	Curtain (rear side) assembly—R. H.	1922	Viage	2 00	MH
4966DX	Curtain (rear side) assembly—L. H.	1922	Viabro	2 00	MH
††4967CRX	Curtain (rear side) assembly—L. H.	1922	Viatric	2 00	MH

*Inquire of Branch or Dealer for price. **Also used on 1922 Roadster top.

†Used on cars without starter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Code	Price	Tax Status
TOURING CAR TOPS—1922—Continued					
4967DX	Curtain (rear side) assembly—L. H.	1922	Viabran	\$ 2 00	MH
6882BX	Curtain (front side) assembly—R. H.	1922	Vibidia	2 00	MH
6883BX	Curtain (front side) assembly—L. H.	1922	Vibus	2 00	MH
6886BX	Deck (top) only	1922	Vidame	3 50	
††6894BRX	Deck (top) assembly	1922	Vidette	6 00	MH
**6894CX	Deck (top) assembly	1922	Viduall	6 00	MH
**6903X	Eyelet (side curtain rear glove fastener)	1922	Vidonia	02	
**6904X	Fastener (rear curtain glove)	1922	Vielle	02	
**7831BX	Hook (curtain to windshield)	1922	Venal	02	
6815BX	Pad (top side quarter) assembly	1922	Viewer	1 00	
††8913BRX	Quarter (side) and reinforcement assembly—R. H.	1922	Viking	1 25	
8913CX	Quarter (side) and reinforcement assembly—R. H.	1922	Vikif	1 25	
††8914BRX	Quarter (side) and reinforcement assembly—L. H.	1922	Vilty	1 25	
**8914CX	Quarter (side) and reinforcement assembly—L. H.	1922	Viliten	1 25	
**3314BX	Rest (prop) and strap assembly	1922	Vindil	45	
8975X	Rib (top) —center and rear	1922	Vinery	40	
8973BX	Rib (top) —front	1922	Viola	40	
8974BX	Rib (top) —center ext.	1922	Violet	40	
**3548X	Screw (front socket fastener)	1922	Vireton	05doz.	
6860CX	Socket (top rib) —front—R. H.	1922	Virger	1 00	
6861CX	Socket (top rib) —front—L. H.	1922	Virid	1 00	
3882CX	Socket (top rib) —center—R. H.	1922	Viscid	1 25	
3883CX	Socket (top rib) —center—L. H.	1922	Viscum	1 25	
††3884CRX	Socket (top rib) —rear—R. H.	1922	Vishnu	1 25	
3884DX	Socket (top rib) —rear—R. H.	1922	Vishnet	1 25	
††3885CRX	Socket (top rib) —rear—L. H.	1922	Visive	1 25	
3885DX	Socket (top rib) —rear—L. H.	1922	Visiad	1 25	
6862CX	Socket (top rib) —center ext.—R. H.	1922	Vissal	1 00	
6863CX	Socket (top rib) —center ext.—L. H.	1922	Vitalize	1 00	
6844BX	Top center strainer	1922	Vitaly	40	
6845	Top quarter strainer	1922	Vivify	40	
**3629CX	Strap (top stay)	1922	Vitfy	40	
**3542X	Strip (rear curtain finishing)	1922	Vitfil	15	
**6901X	Stud (rear curtain glove fastener)	1922	Vitta	02	
3551X	Center support on rear socket	1922	Virite	10	
3553X	Center ext. support on center socket	1922	Viscous	05	
3564X	Center ext. support on center socket	1922	Vistula	10	
3572X	Center ext. to brace support	1922	Vitrify	05	
*7940BX	Top assembly	1922	Vivace		MH
**4981BX	Visor (top) assembly	1922	Vivary	75	
**6905X	Washer (side curtain rear glove fastener)	1922	Vivers	02	
TORPEDO TOP PARTS—1915-22					
*7941X	Torpedo top complete	1915-22	Wisdom		MH
8772X	Rib—upright	1918-22	Wenny	40	
8988X	Rib—from extension	1918-22	Wept	40	
8989X	Rib—rear extension	1918-22	Westing	40	
6870BX	Torpedo top rib socket—upright—(R. H.)	1918-22	Whalling	1 00	
6871BX	Torpedo top rib socket—upright—(L. H.)	1918-22	Whedle	1 00	
6872BX	Torpedo top rib socket—front extension—(R. H.)	1918-22	Whelm	1 00	
6873BX	Torpedo top rib socket—front extension—(L. H.)	1918-22	Wherry	1 00	
4907BX	Torpedo top rib socket—rear extension—(R. H.)	1918-22	Whestit	1 00	
4908BX	Torpedo top rib socket—rear extension—(L. H.)	1918-22	Whewer	1 00	
6937X	Torpedo top side curtain—rear—(R. H.)	1915-22	Wood	1 50	MH
6938X	Torpedo top side curtain—rear—(L. H.)	1915-22	Word	1 50	MH
6935X	Torpedo top side curtain—front—(R. H.)	1915-22	Work	2 00	MH
6936X	Torpedo top side curtain—front—(L. H.)	1915-22	World	2 00	MH
6950X	Torpedo top back curtain assembly	1915-22	Worm	2 50	MH
6965X	Torpedo top center deck complete	1915-22	Worry	4 50	MH
6964X	Torpedo top deck only	1915-22	Wrap	2 50	
6962X	Torpedo top side quarter—(R. H.)	1915-22	Wreck	1 00	
6963X	Torpedo top side quarter—(L. H.)	1915-22	Wren	1 00	
6806X	Torpedo top side quarter pad	1914-22	Wrist	60	
3877X	Torpedo top prop rest with strap	1913-22	Yam	60	
4955X	Torpedo top visor	1920-22	Yamper	50	
†ROADSTER TOPS—1922					
6935BX	Curtain (front side) assembly—R. H.	1922	Vocle	2 00	MH
6936BX	Curtain (front side) assembly—L. H.	1922	Vogle	2 00	MH
6937BX	Curtain (rear side) assembly—R. H.	1922	Voglite	1 50	MH
6938BX	Curtain (rear side) assembly—L. H.	1922	Vogue	1 50	MH
6950BX	Rear curtain assembly	1922	Volanna	2 50	MH
6964BX	Top deck only	1922	Volary	2 50	
6965BX	Top deck assembly	1922	Volens	4 50	MH
6806BX	Top side quarter pad assembly	1922	Voleus	60	
6962BX	Side quarter and reinforcement assembly—R. H.	1922	Voltaic	1 00	
6963BX	Side quarter and reinforcement assembly—L. H.	1922	Volti	1 00	
8988BX	Top rib—front	1922	Volupia	40	
8989BX	Top rib—center and rear	1922	Volumna	40	
4907CX	Top rib socket assembly—rear—R. H.	1922	Volupty	1 00	
4908CX	Top rib socket assembly—rear—L. H.	1922	Volute	1 00	
6872CX	Top rib socket assembly—front	1922	Volvox	1 00	
6870CX	Top rib socket assembly—center—R. H.	1922	Vomer	1 00	
6871CX	Top rib socket assembly—center—L. H.	1922	Votary	1 00	
6874CX	Top rib socket assembly—R. H.	1922	Vosegus	3 00	
6875CX	Top rib socket assembly—L. H.	1922	Vortve	3 00	
*7941BX	Top assembly	1922	Voturif		MH
4981BX	Visor assembly	1922	Voyag	75	

*Inquire of Branch or Dealer for price. **Also used on 1922 Roadster top.

†For additional 1922 Roadster top parts see 1922 Touring Car top parts marked with a double asterisk.

††Used on tops with straight side quarters.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.




Plate No. 10

Price List of Parts for Model T One-Ton Truck

Part No.	Name of Part	Year	Price	Tax Code		Fac.No.Req.		
				Status	Word	Model No.	per Car	
REAR AXLE								
1000	Rear axle assembly	1918-22	\$150 00	MH	Abed.	TT	95	1
1001	Axle housing—right	1918-22	16 00	MH	Abyss	TT	4	1
1002	Axle housing—left	1918-22	16 00	MH	Acme	TT	5	1
1003	Axle housing bolt	1918-22	03		Avail.	TT	52	13
1003B.	Axle housing bolt nut. Order 2719	1918-22						
1004	Axle housing cap	1918-22	50	MH	Actor	TT	133	1
1005	Axle housing cap gasket	1918-22	02		Acute	TT	134	1
1006	Axle housing cap screw	1918-22	05		Adder	TT	72	4
1007	Axle housing cap screw lock wire	1918-22	01		Addle	TT	140	1
1008	Axle housing gasket—upper	1918-22	02		Agate	TT	138	1
1009	Axle housing gasket—lower	1918-22	05		Agast	TT	139	1
1010	Axle brake housing plate—right	1918-22	35	MH	Agille	TT	147	1
1011	Axle brake housing plate—left	1918-22	35	MH	Akin	TT	148	1
1012	Axle housing drain plug	1918-22	05		Alder	TT	136	2
1013	Axle shaft	1918-22	5 00	MH	Alex.	TT	48	2
1014	Axle shaft cotter	1918-22	dz.05		Alms	TT	165	2
1015	Axle shaft nut	1918-22	10		Aloe	TT	166	2
1016	Axle shaft washer	1918-22	03		Aloft	TT	135	2
1017	Axle shaft dust cap	1918-22	03		Alpha	TT	56	2
1018	Axle shaft inner ball bearing assembly	1918-22	5 00		Alpine	TT	125	2
1019	Axle shaft outer roller bearing	1918-22	1 25		Archer	TT	253	2
1020	Axle shaft outer roller bearing sleeve	1918-22	45		Arena	TT	170	2
1021	Axle shaft bearing felt	1918-22	15		Argue	TT	143	4
1022	Axle shaft bearing retainer	1918-22	10		Ark	TT	20	2
1023	Axle shaft bearing retainer washer	1918-22	03		Arson	TT	23	2
1024	Axle shaft felt retainer assembly	1918-22	10		Astral	TT	144	2
1025	Axle shaft felt retainer cup	1918-22	03		Atwist	TT	145	2
1026	Axle shaft felt retainer plate	1918-22	03		Attle	TT	146	2
1027	Diff. gear	1918-22	1 30	MH	Aura	TT	13	2
1028	Diff. gear case R. or L. half	1918-22	2 00	MH	Author	TT	11	2
1029	Diff. gear case bolt. Order 1003							
1031	Diff. gear lock ring	1918-22	02		Avoke	TT	118	2
1032	Diff. pinion	1918-22	60	MH	Awake	TT	14	2
1033	Diff. pinion shaft	1918-22	20		Awry	TT	15	1
1034	Drive shaft	1918-22	7 00	MH	Bait	TT	87	1
1036	D. S. tube assembly	1918-22	12 00	MH	Balm	TT	153	1
1037	D. S. tube flange gasket	1918-22	02		Bandit	TT	194	1
1038	D. S. tube flange screw. Order 1006							
1039	D. S. felt	1918-22	10		Basil	TT	109	1
1040	D. S. felt container	1918-22	03		Beaver	TT	110	1
1041	D. S. to worm coupling	1918-19	1 00		Behind	TT	85A.	1
1041B.	D. S. to worm coupling	1920-22	80		Bhang	TT	85B.	1
1042	D. S. to worm coupling pin	1918-22	01		Behold	TT	86	2
1043	Worm—7 1/4 to 1	1918-22	7 50	MH	Berg.	TT	16A.	1
1043B.	Worm—5 1/6 to 1	1918-22	7 50	MH	Bernese.	TT	16B.	1
1044	Worm gear—7 1/4 to 1	1918-22	10 00	MH	Bible	TT	12A.	1
1044B.	Worm gear—5 1/6 to 1	1918-22	10 00	MH	Bifilar.	TT	12B.	1
1045	Worm cotter. Order 1014	1918-22						
1046	Worm roller bearing	1918-22	1 00		Bight	TT	108	2
1047	Worm roller bearing retainer	1918-22	02		Bigot	TT	106	1
1048	Worm roller bearing sleeve	1918-22	1 50		Bilog	TT	107	2
1049	Worm roller bearing housing screw	1918-22	03		Birch	TT	101	2
1050	Worm thrust bearing collar	1918-22	90		Bird	TT	114	2
1051	Worm thrust ball and separator assembly	1918-22	85		Blitzer	TT	123	1
1052	Worm thrust bearing plate	1918-22	15		Blaze	TT	22	1
1053	Worm thrust bearing retainer	1918-22	15		Bleach	TT	111	1
1054	Worm thrust bearing retainer nut Order 1015	1918-22						
1055	Worm thrust bearing retainer pin	1918-22	01		Blend	TT	112	1
1056	Brake shoe	1918-22	2 00	MH	Blind	TT	2814	2
1057	Brake shoe lining, each	1918-22	30	MH	Blink	TT	58	4
1058	Brake shoe lining rivet	1918-22	dz.10		Blue	TT	68	40
1059	Brake shoe spring	1918-22	05		Blunt	TT	67	2
1060	Brake shoe bolt	1918-22	10		Scion	TT	59	2
1060B.	Brake shoe bolt nut. Order 2828	1918-22						
1061	Brake expander	1918-22	40		Bodkin	TT	61	2
1062	Brake expander lever	1918-22	15		Booth	TT	62	2
1064	Brake expander adjustment collar	1918-22	20		Brig	TT	175	2
1065	Brake expander bushing	1918-22	10		Bronze	TT	173	2
1066	Brake expander pin	1918-22	01		Brook	TT	7	2
1067	Brake expander link	1918-22	08		Broom	TT	176	4
1068	Brake expander link pin	1918-22	03		Brow	TT	177	8
1069	Brake rod	1918-22	30	MH	Brush	TT	119	2
1070	Brake rod support—right	1918-22	10		Buck	TT	120	1
1071	Brake rod support—left	1918-22	10		Bug	TT	121	1
1072	Brake rod support bolt	1918-22	02		Serene	TT	121	2
1072B.	Brake rod support bolt nut. Order 3088E	1918-22						
1073	Rear radius rod	1918-22	3 50		Burn	TT	152	2
1074	Rear radius rod bolt—front	1918-22	10		Acclaim	TT	84	1
1075	Rear radius rod bolt—rear	1918-22	10		Absclnd.	TT	83	4
1075B.	Rear radius rod bolt nut. Order 2828	1918-22						
1076	Universal joint bushing	1918-22	40		Crape	TT	69	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

Part No.	Name of Part	Year	Price	Tax Status	Code Word	Fac. No.	Mo. Req. per Car
SPRING							
1077	Rear spring—right or left, each	1918-22	\$ 4 50	MH	Cream	TT	333 2
1078	Spring leaf No. 1	1918-22	1 00		Creed	TT	334 2
1079	Spring leaf No. 2	1918-22	60		Crew	TT	362 2
1080	Spring leaf No. 3	1918-22	55		Crib	TT	363 2
1081	Spring leaf No. 4	1918-22	45		Crisp	TT	364 2
1082	Spring leaf No. 5	1918-22	40		Croak	TT	365 2
1083	Spring leaf No. 6	1918-22	35		Crop	TT	366 2
1084	Spring leaf No. 7	1918-22	30		Croup	TT	367 2
1085	Spring leaf No. 8	1918-22	25		Crow	TT	368 2
1086	Spring leaf No. 9	1918-22	20		Crowd	TT	331 2
1087	Spring bushing	1918-22	20		Crumb	TT	332 2
1088	Spring clip	1918-22	45		Crusher	TT	326 2
1089	Spring clip nut	1918-22	10		Cry	TT	327 4
1091	Spring clip plate	1918-22	20		Cuff	TT	329 2
1092	Spring tie bolt	1918-22	20		Cuit	TT	330 2
1093	Spring tie bolt nut, Order 1089	1918-22					
1094	Spring tie bolt cotter	1918-22	dz.05		Cure	TT	328 2
1095	Spring clamp	1918-22	10		Curl	TT	375 2
1096	Spring clamp bolt	1918-22	04		Curse	TT	376 2
1096B	Spring clamp bolt nut, Order 3514	1918-22					
1097	Spring perch	1918-22	80	MH	Dale	TT	2804 2
1098	Spring perch nut, Order 1015	1918-22					
1099	Spring perch cotter, Order 1014	1918-22					
1100	Spring perch bushing	1918-22	25		Demon	TT	172 2
1101	Spring perch bushing spacer	1918-22	05		Dean	TT	169 4
1102	Spring hanger assembly	1918-22	30		Dike	TT	91 4

WHEELS

1105B	Rear wheel complete—dem.—Kelsey	1919-22	19 50		Duelist	TT	7698 2
1105C	Rear wheel complete—dem.—Hayes	1919-22	19 50		Dulcant	TT	7698B 2
1105D	Rear wheel—dem.—less rim & hub—Kelsey	1919-22	9 00		Duramen	TT	2817AR 2
1105E	Rear wheel—dem.—less rim & hub—Hayes	1919-22	9 00		Durance	TT	2817BR 2
1106B	Dem. rim only—Kelsey	1919-22	4 00		Duke	TT	8774A 2
1106C	Dem. rim only—Hayes	1919-22	4 00		Dumal	TT	8774B 2
1106D	Dem. rim only—Kelsey	1922	4 00		Dunny	TT	8774C 2
1106E	Dem. rim retainer ring—Kelsey	1922	45		Dupion	TT	178 2
1107B	Clamp and nut assembly—Kelsey	1918-22	15		Duledge	TT	8807 12
1108B	Clamp bolt	1919-22	10		Dullish	TT	8832 12
1109	Rear wheel complete, less tire	1918-20	18 00		Duel	TT	99 2
1110	Rear wheel complete, with solid tire	1919-20		MH	Drone	TT	7645 2
1111	Rear hub	1918-22	2 75		Dumb	TT	40 2
1112	Rear hub flange	1918-22	40		Dusk	TT	149 2
1113	Rear hub brake drum	1918-22	1 25		Dutch	TT	3 2
1114	Rear hub bolt	1918-22	05		Dwarf	TT	28 12
1114B	Rear hub bolt nut	1918-22	02		Durify	TT	29 12
1116	Rear hub cap	1918-22	30		Dyke	TT	150 2
1117	Rear hub key	1918-22	03		Ear	TT	26 2
1118	Rear hub felt	1918-22	05		East	TT	162 2

FRAME

1119	Frame assembly	1918-22	30 00	MH	Eat	TT	300 1
1120	Side member—right	1918-22	10 00		Ebb	TT	301 1
1121	Side member—left	1918-22	10 00		Fish	TT	302 1
1122	Front cross member	1918-22	1 00		Flirt	TT	303 1
1123	Rear cross member	1918-22	4 00		Flock	TT	304 1
1124	Front corner bracket—right	1918-22	15		Frost	TT	305 1
1125	Front corner bracket—left	1918-22	15		Froth	TT	306 1
1125B	Front end spacer—right	1918-22	15		Fruitage	TT	319 1
1125C	Front end spacer—left	1918-22	15		Fruitful	TT	318 1
1126	Rear cross member gusset plate	1918-22	25		Ghost	TT	307 2
1127	Rear cross member reinforcement	1918-22	35		Fruition	TT	325 2

TRANSMISSION CONTROL

1133	Speed lever	1918-22	10		Hoe	TT	862 1
1134	Controller shaft with speed lever	1918-22	75	MH	Hod	TT	1557 1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 20/21 represents the price of the goods and 1/21 represents excise tax.

Insist upon genuine Ford Parts

