

Ford

THE UNIVERSAL CAR

WHOLESALE

PRICE LIST OF PARTS

MODEL T

Effective August 1, 1923

1923
6⁰⁰

Ford Motor Company
Detroit, Michigan

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*

Ford Factory, Ford, Ontario, Canada

Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Buffalo	Columbus	Houston	Louisville	Omaha	San Francisco
Cambridge	Dallas	Indianapolis	Memphis	Philadelphia	Seattle
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Washington
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	
Cincinnati	Detroit	Kearny, N. J.	New Orleans	St. Louis	

Instructions for Ordering Parts

- 1—Order all parts through the Authorized Ford Dealer.
- 2—Parts may be ordered in wholesale quantities at a discount of 33 $\frac{1}{3}$ % f. o. b. the nearest Ford Branch providing the net amount of the order exceeds \$50.00. When delivery is taken from Dealer's Stock a discount of 25% will apply regardless of quantity ordered.
- 3—Always give Catalog Number and Name of each part ordered.
- 4—Specify whether shipments are to be made by freight or express.
- 5—Remittance by Draft or Money Order must accompany all parts orders placed for shipment from the Ford Branch.

Telegraph Code

We list below a brief General Code covering miscellaneous instructions relative to the shipment of parts.

Toperig—Ship to me (us) by express.

Toperkleur—Ship by express to —

Topersteen—Ship to me (us) by freight.

Toper—Ship to me (us) by parcel post.

Topfton—When and how did you ship parts called for in my (our) telegram of —

Topflutch—When and how will you ship parts called for in my (our) telegram of —

Topwasser—When and how will you ship parts called for in my (our) letter of —

WHOLESALE PRICE LIST OF PARTS

FORD MODEL T 1909-1923

EFFECTIVE AUGUST 1, 1923

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
REAR AXLE									
2500	Rear axle assembly	1909-23	2				\$60 00. MH	95E	1
2501	Axle housing—right	1915-23	2				8 00. MH	7635C	1
2502	Axle housing—left	1915-23	2				8 00. MH	7636C	1
2503E	Axle housing bolt	1913-23	100		\$1 00	\$6 00	03	2854	7
2503F	Axle housing bolt nut	1909-23	100		1 00	6 00	02	44	7
2504	Rear axle case gasket	1919-23	20	\$0 30	1 25		03	139	1
2505	Axle shaft	1912-23	6				1 40. MH	2818	2
2506	Axle shaft washer	1909-23	20	25	75		02	39	1
2508	Axle shaft R. B.	1909-23	6				90	253	4
2509	Axle shaft R. B. sleeve—R	1909-23	6				15	170	2
2509B	Axle shaft R. B. sleeve—L	1909-23	6				15	161	2
2510	Axle housing cap	1909-19	20	50	2 00		05	56A	2
2510 1/2	Axle housing cap	1919-23	20	40	1 80		05	56B	2
2510A	Axle outer roller bearing steel washer	1909-23	20	25	1 00		02	199B	2
2510B	Axle outer roller bearing felt washer	1909-23	20	80	3 50	27 50	05	54	2
2512C	Diff. case—left	1914-23	4				1 40. MH	84	1
2513C	Diff. case—right	1914-23	4				90. MH	81	1
2514B	Diff. case stud	1915-23	20	70	3 00		05	52B	3
2514C	Diff. case bolt	1922-23	20	70	3 00		05	52C	3
2515	Diff. case stud nut	1909-23	100		1 50	10 00	03	8	3
2518	Diff. drive gear	1909-23	6				2 75. MH	12B	1
2519	Diff. drive gear screw	1909-23	100		2 00	15 00	03	103	10
2519A	Diff. gear lock ring	1909-23	6	30	1 00		02	118	2
2520B	Diff. gear	1909-23	6				90. MH	13B	2
2521B	Diff. gear key	1915-23	10		4 00		35	137	2
2524C	Diff. pinion	1909-23	6				75. MH	14D	3
2526B	Diff. spider	1909-23	6				75. MH	15D	1
2528	Diff. thrust washer	1909-23	10				15	30	2
2529	Diff. thrust plate	1909-23	10		10 00		15	31	4
2530	Diff. thrust plate pin	1909-16	20		1 50		03	17	4
2531B	Diff. thrust plate pin	1917-23	20	20	75		02	37	2
2532B	Diff. housing oil plug	1909-23	6				05	7640	6
2545	Rear axle grease cup	1909-23	20	1 25	6 00		15	817	1
2547B	Rear radius rod—right	1909-23	2				1 25. MH	152	1
2547B	Rear radius rod—left	1909-23	2				1 25. MH	158	1
2549	Radius rod nut	1909-23	100		3 50	25 00	05	77	2
2550	Radius rod lock nut	1909-23	10		3 00		05	78	2
2550	Radius rod lock washer	1909-23	100		1 00		05	2823	2
2551	Radius rod bolt	1909-23	20	70	3 00		02	83	4
2551B	Radius rod nut	1909-23	100		2 50	18 00	05	60	4
2557	Hub cam shaft—right	1909-23	6				15. MH	92B	1
2558	Hub cam shaft—left	1909-23	6				15. MH	91B	1
2559	Hub cam shaft bushing	1909-23	10				05	173	2
2562	Cam shaft lever	1909-23	6				10. MH	62	2
2563	Cam shaft lever pin	1909-23	100		50		02	7	4
2564	Lever clevis pin	1909-23	100		1 25		03	65	4
2566	Hub brake shoe	1909-23	10				40. MH	2814	2
2567	Brake shoe support bolt	1909-23	20	70	3 00		05	59	2
2568	Brake shoe support nut	1909-23	20						
2570B	Brake shoe coil spring	1913-23	20	35	1 50		03	2862	4
2571	Universal joint assembly	1909-23	6				1 50	151B	1
2572	Joint knuckle (male)	1909-23	2				60	45B	1
2573	Joint knuckle (female)	1909-23	2				60	46B	1
2574	Joint knuckle pin	1909-23	20	20	75		02	6	1
2575	Joint ring, complete	1909-23	3				50	49B	1
2576	Joint ring rivets (per set 4)	1909-23	20	12	50		05	50	4
2577B	Univ. joint housing	1914-23	2				1 00	7609	1
2578	Joint housing plug	1909-23	20	60	2 50		05	195	2
2579	Ball joint grease cup	1909-23	10	2 40	10 00		15	195	1
2580	Ball cap gasket	1909-23	20	80	3 50	25 00	05	1518	1
2581	Drive shaft housing front bushing	1909-23	6				30	69	1
2582	D. S. tubing	1911-23	2				7 00. MH	153B	1
2583B	D. S. bearing housing	1920-23	2				1 40. MH	191C	1
2584B	D. S. R. B. cap screw	1912-23	20		3 00		05	183B	6
2584C	D. S. R. B. stud nut	1912-23	20	50	2 00		05	184R	6
2584D	D. S. R. B. cap screw lock washer	1912-23	100				doz. 05	157	6
2586	D. S. R. B. housing set screw	1911-23	20	90	4 00		05	101R	1
2587	D. S. roller bearing	1911-23	6				1 00	108	1

††When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Tax	Fac. Status	No. Req. per Car	
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
REAR AXLE—Continued										
2588	A. D. S. R. B. distance plate	1911-21	20	\$ 0 25	\$ 1 00		\$ 0 05	MH	106R	1
2589	A. D. S. ball race	1911-21	6				25		186R	1
2589B	K. D. S. ball bearing assy.	1911-21	6				90		185AR	1
2590	A. D. S. ball retainer	1911-21	20	40	1 75		03		190AR	1
2591	A. D. S. ball thrust collar	1911-23	10				25		188	2
2591B	A. D. S. thrust ball and retainer assembly	1920-23	10				25		162	1
2592	A. D. S. ball bearing	1911-21	10							
2593	A. D. S. R. B. sleeve	1911-21	6							
2595B	A. D. S. only	1911-23	3				3 00	MH	87D	1
2596	A. D. S. sleeve	1911-23	10				70		163B	1
2597B	K. D. S. pinion	1911-23	10				1 00	MH	16C	1
2597C	A. D. S. pinion	1911-23	2				1 00	MH	16D	1
2598	A. D. S. castle nut	1911-23	10				05		124	1
2598B	A. D. S. pinion key	1911-23	20	80	3 50		05		57B	1
REAR AXLE—60 INCH TREAD										
2600C	Rear axle housing—right	1915-16	2				12 00	MH	2728C	1
2601C	Rear axle housing—left	1915-16	2				12 00	MH	2729C	1
2602B	Rear axle shaft—tapered	1911-16	2				3 00	MH	2725	2
2604	Rear radius rod	1909-16	2				2 00		1726	2
FRONT AXLE										
2691	Front axle only	1909-23	2				9 00	MH	202B	1
2694B	Spindle body—right	1911-23	2				1 50	MH	280	1
2695B	Spindle body—left	1911-23	2				1 50	MH	281	1
2696	Spindle arm—right or lf.	1911-19	4				50	MH	7716	2
2696C	Spindle arm—right	1919-23	4				45	MH	7715B	1
2696D	Spindle arm—left	1919-23	4				45	MH	7716B	1
2697	Spindle arm nut	1911-23	4							
2704	Stationary cone	1909-23	24				15		205A	2
2705	Adj. cone—right thread	1909-23	24				15		206A	1
2706	Adj. cone—left thread	1909-23	24				15		207A	1
2707	Spindle nut—right thread	1909-23	20				05		209B	1
2708	Spindle nut—left thread	1909-23	20				05		208B	1
2709	Spindle washer	1909-23	20	25	1 00	\$ 6 00	02		210	2
2710	Spindle bolt with oiler	1910-23	20	3 50	16 00		20		7708	2
2711	Spindle bolt nut	1909-23	20							
2713	Spindle body bush, (pair)	1909-23	20	3 80	17 00		20		223	2
2714	Spindle arm bushing	1909-23	20	30	1 25	9 00	05		225	2
2715D	Spindle oiler	1919-23	2							
2717	Spindle con. rod	1909-23	2				1 75	MH	264	1
2718	Spindle con. rod bolt with oiler	1909-23	20		12 00		15		7706	1
2719	Spindle con. rod bolt nut	1909-23	100		2 50	15 00	03		220	2
2721B	Spindle con. rod yoke ball	1919-23	2				20	MH	226	1
2721C	Spindle con. rod yoke	1919-23	2				40	MH	248B	1
2725B	Steering gear con. rod	1909-23	2				80	MH	289	1
2728	Ball socket cap	1909-23	6				10		254B	2
2729B	Ball socket bolt and nut	1909-23	3				2 00	MH	263A	1
2733	Front radius rod	1909-19	3				1 50	MH	263B	1
2733B	Front radius rod	1919-23	3				12		217	1
2736	Front radius rod ball cap	1909-23	12							
2737	Front radius rod ball socket	1911-23	2				20		809B	1
2741	Radius rod ball cap stud	1911-23	20	55	2 50		03		4365	2
2741B	Radius rod ball cap stud nut	1911-23	20							
2742	Radius rod ball cap spr'g	1911-23	20	40	1 50	10 00	03		292	2
2760	Front axle only—60"	1911-16	2				10 00	MH	1720B	1
2761	Spindle con. rod—60"	1909-16	2				3 00	MH	1725	1
2762	Steer. gear con. rod—60"	1909-16	2				1 25	MH	2739	1
WHEELS										
2800	Front wheel—clincher	1909-23	2				6 50		291B	2
2800B	Front wheel—dem. less rim and brgs.—Kelsey	1919-23	2				7 25		291D	2
2800C	Front wheel—dem. less rim and brgs.—Hayes	1919-23	2				7 25		291E	2
2800D	Front wheel—clincher—less hub	1909-23	2				4 50		295AR	2
2800E	F. and rear wheel—dem. less rim & hub—Kelsey	1919-23	2				4 75		293AR	4
2800F	F. and rear wheel—dem. less rim & hub—Hayes	1919-23	2				4 75		293BR	4
2800G	Front wheel—dem.—less rim and brgs.—Ford	1919-23	2				7 25	MH	291G	2
2800H	Frt. and rear wheel—dem. less rim & hub—Ford	1919-23	2				4 75	MH	293CR	4
2801	Front wheel complete R. or L.—dem.—Kelsey	1919-23	2				9 75		7697A	2
2801B	Front wheel complete R. or L.—dem.—Hayes	1919-23	2				9 75		7697B	2
2801C	Front wheel complete R. or L.—dem.—Ford	1919-23	2				9 75	MH	7697C	2

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Minimum Wholesale Quan.	Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
WHEELS—Continued									
2803	Front hub assy.	1909-23	4				\$1 60	200	2
2803B	Front hub with R B cups	1909-23	2				2 00	219	2
2804	Outer race	1909-23	12		\$ 8 00		10	234	2
2805	Inner race	1909-23	12		12 00		15	235	2
2806	Outer ball retainer	1909-23	20	\$ 0 25	1 00		02	236	2
2807	Inner ball retainer	1909-23	20	40	1 50		03	237	2
2808	Dust ring	1909-23	20	80	3 00		05	238	2
2809	Front & rear hub felt washer	1909-23	20	90	4 00	\$ 30 00	05	239	4
2810	Large balls	1909-23	100		3 00	25 00	04	241	24
2811	Small balls	1909-23	100		1 25	10 00	03	249	22
2814C	Rear wheel—clincher	1912-23	2				7 25	2815	2
2814D	Rear wheel—clincher—less hub	1909-23	2				5 00	2816	2
2814E	Rear wheel complete—dem.—Kelsey	1919-23	2				9 50	7698A	2
2814F	Rear wheel complete—dem.—Hayes	1919-23	2				9 50	7698B	2
2814G	Rear wheel—dem. less rim—Kelsey	1919-23	2				7 00	2815B	2
2814H	Rear wheel—dem. less rim—Hayes	1919-23	2				7 00	2815C	2
2814J	Rear wheel—complete—dem.—Ford	1919-23	2				9 50	MH. 7698C	2
2814K	Rear wheel—dem.—less rim—Ford	1919-23	2				7 00	MH. 2815E	2
2815C	REAR HUB	1912-23	4				1 25	MH. 2819	2
2816B	Rear hub key	1912-23	20	35	1 50	12 00	03	2863	2
2818	Rear hub brake drum	1909-23	4				40	3B	2
2819	Hub cap	1909-23	20	2 80	12 50		15	7727	4
2825	Rear hub bolt	1911-23	100		1 50	8 00	03	28B	12
2825B	Hub bolt nut	1911-23	100		1 00	6 00	03	29	24
2826	Front hub bolt	1911-23	100		1 50	8 00	03	27	12
2827	Hub flange	1911-23	3				20	233B	4
2828	Rear hub lock nut	1912-23	20	90	4 00		05	242	2
2833	Front hub bear. cup inner	1919-23	6				50	2955	2
2834	Inside cone and rollerassy	1919-23	6				1 10	205B	2
2836	Front hub bearing cup—outer	1919-23	6				40	2956	2
2837	Outside cone and roller assy.—right thread	1919-23	6				75	206B	1
2838	Outside cone and roller assy.—left thread	1919-23	6				75	207B	1
2841	Front hub dust cap assy.	1919-23	12		8 00		10	350	2
2845	Demountable rim only—Kelsey	1919-23	2				1 75	8774A	4
2845B	Demountable rim only—Hayes	1919-23	2				1 75	8774B	4
2845C	Demountable rim only—Ford	1922-23	2				1 75	8774C	4
2846B	Demountable rim clamp—Kelsey	1919-23	20	1 70	5 00		10	8831B	16
2846C	Dem. rim clamp and nut assy.—Ford	1922-23	20				15	8807	16
2847	Demountable rim bolt	1919-23	24		4 50		05	8832A	16
2848	Dem. rim nut—Hayes	1919-23	24		4 00		05	8834B	16
2848B	Dem. rim nut—Kelsey	1919-23	24		4 00		05	8834A	16
2849	Spare rim carrier	1919-23	2				2 00	MH. 8848C	1
2849C	Spare rim carrier clamp support and bolt assy.	1921-23	4				15	MH. 7511	1
2849D	Spare rim carrier assy.	1921-23	4				05	7312C	1
2870	Spare rim carrier brkt—R	1919-22	2				50	8824AR	1
2870B	Spare rim carrier brkt—L	1922-23	2				50	8824B	1
2871	Spare rim carrier brkt—L	1919-22	2				50	8825AR	1
2871B	Spare rim carrier brkt—L	1922-23	2				50	8825B	1
FRAME									
2850	Frame assembly	1909-23	2				13 00	MH. 2916	1
2851B	Side member—right	1914-23	2				4 00	2914	1
2852B	Side member—left	1914-23	2				4 00	2915	1
2853	Front cross member	1909-23	6				90	303	1
2854B	Rear cross member	1914-23	3				1 20	2913	1
2855	Front corner bracket—R	1909-23	6				15	305	1
2856	Front corner bracket—L	1909-23	6				15	306	1
2857	Rear corner bracket—R	1909-23	6				15	307	1
2858	Rear corner bracket—L	1909-23	6				15	308	1
2859	Front end spacer—L	1909-23	6				10	318B	1
2860	Front end spacer—R	1909-23	6				10	319B	1
2863	Body bracket	1909-23	6				15	344	4
GASOLINE TANK									
2900B	Gas tank—Sedan	1916-23	2				6 00	MH. 7950	1
2900C	Gasoline tank	1909-23	2				4 00	MH. 1303B	1
2901	Filling plug	1909-23	20	1 80	\$ 8 00		10	1317	1
2902B	Sediment bulb	1909-23	6				90	2088	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum			LIST PRICE			Tax	Fac.	No. Req. per Car
			Whole-sale Quan.	Lots of 20	Lots of 100	Lots of 1000	Each	Status			
GASOLINE TANK—Continued											
2908	✓ Pet cock.....	1909-23		Order 3079							
2909	✓ Feed pipe—40 3/4.....	1909-23	4				\$ 20	1364	1		
2909B	✓ Feed pipe—51 1/2.....	1916-23	4				25	7965	1		
2909C	✓ Feed pipe—66 1/2.....	1918-19	4				40	9775R	1		
2909D	✓ Feed pipe—56 1/4.....	1919-23	4				30	8690	1		
2909E	✓ Feed pipe—39 1/2.....	1918-23	2				20	TT1364	1		
2910	✓ Feed pipe pack nut.....	1909-23	20	90	4 00		05	1374	2		
2911	✓ Feed pipe—78".....	1915	4				70	1394R	1		
2913	✓ Feed pipe gasket.....	1909-23	20		1 50		02	5892	1		
2914	✓ Gas tank support—R.....	1917-20	2				25	2132	1		
2914B	✓ Gas tank support—R.....	1920-23	2				20	2132B	1		
2915	✓ Gas tank support—L.....	1917-20	2				20	2133	1		
2915B	✓ Gas tank support—L.....	1920-23	2				20	2133B	1		
2916	✓ Feed pipe clamp.....	1921-23	20				01	2118	1		
MOTOR											
*2990	Motor assy.....	1909-23						MH	532C	1	
††2991	Cylinder assy.....	1909-23						MH	449	1	
x3000C	Cylinder.....	1909-23	2				25 00	MH	400D	1	
x3000B	Cylinder (bore 1/2" oversize).....	1909-23	2				15 00	MH	400E	1	
3001	Cylinder head.....	1909-23	2				6 00	MH	401C	1	
3002	Cyl. head gasket.....	1909-23	20	5 60	27 00		30	MH	402B	1	
3003	Cyl. head cap screw.....	1909-17	20	70	3 00		05		483B	15	
3003B	Cyl. head cap screw.....	1918-23	20	70	3 00		05		483C	1	
3004	Cyl. head outlet con.....	1909-16	6				35	MH	446C	1	
3004B	✓ Cyl. head outlet con.....	1917-23	6				30	MH	8719	1	
3005	Cyl. head out. con gasket.....	1909-23	20	60	2 50		05	MH	445B	1	
3006	✓ Cyl. head outlet hose.....	1909-23	20				15		448B	1	
3007	✓ Cyl. head outlet hose clip.....	1909-23	20	80	3 50		05		607B	2	
3008	✓ Cyl. head out. con. screw.....	1909-23	20	50	2 00		05		550C	2	
3009B	Cyl. front cover.....	1909-19	2				1 00	MH	690B	1	
3009C	Cyl. front cover.....	1919-23	2				1 00	MH	690C	1	
3010	Cyl. cover bolt and nut.....	1909-23		Order 4808 and 2515							
3011	Cyl. cover cap screw.....	1909-23	20	40	1 75		03		432	3	
3012	✓ Cyl. cover felt.....	1909-23	20	80	3 00		05		504	1	
3013	Cyl. cover liner.....	1909-19	20	25	1 00		02		505B	1	
3013B	Cyl. cover liner.....	1919-23	20	25	1 00		03		505C	1	
3014	Cyl. cover and crank case bolt and nut.....	1909-23		Order 3362 and 2515							
3015	✓ Cyl. water inlet con.....	1909-23	6				30	MH	442B	1	
3016	Cyl. inlet con. screw.....	1909-23	20	50	2 00		05		597	2	
3017	✓ Time gear cover.....	1919-23	4				90	MH	1754B	1	
†3017B	Time gear cover.....	1919-21	4				80	MH	1754AR	1	
3017C	Time gear cover gasket.....	1919-23	100		60		01		175	1	
3017D	Time gear cover plate.....	1919-23	6				05	MH	1773	1	
3018	Cyl. water inlet gasket.....	1909-23	20	50	2 00		05	MH	596	1	
3019	Cyl. water jacket plug.....	1909-13	10				02		557	3	
3019B	Cyl. water jacket plug.....	1914-23	10		50		05		5919	3	
3020	PISTON COMPLETE.....	1909-23	10				1 70	MH	586C	4	
3020C	PISTON COMPLETE.....	1909-23	10				1 70	MH	586DR	4	
3020D	PISTON COMPLETE.....	1909-23	10				1 70	MH	586ER	4	
3020E	PISTON COMPLETE.....	1909-23	10				1 70	MH	586FR	4	
3020F	PISTON COMPLETE.....	1909-23	10				1 70	MH	586GR	4	
3021	Piston only.....	1909-23	10				1 00	MH	418C	4	
3021B	Piston only—.0025" O. S.....	1909-23	10				1 00	MH	418DR	4	
3021C	Piston only—.03125" O. S.....	1909-23	10				1 00	MH	418ER	4	
3021D	Piston only—.031" O. S.....	1909-23	6				1 00	MH	418FR	4	
3021E	Piston only—.005" O. S.....	1909-23	10				1 00	MH	418GR	4	
3022	Piston pin.....	1909-23	20				25		419B	4	
3022 1/2	Piston pin bushing (pair).....	1909-23	10		18 00		15		668	4	
3023	Piston ring.....	1909-23	20	2 70	10 00		20		422C	12	
3023B	Piston ring.....	1909-23	20	2 70	10 00		15		422ER	12	
3023C	Piston ring.....	1909-23	20	2 70	10 00		15		422DR	12	
3023D	Piston ring.....	1909-23	20	2 70	10 00		15		422FR	12	
††3024	CONNECTING ROD.....	1909-23	10				1 20	MH	641	4	
**3024B	Connecting rod.....	1909-23	8				1 20	MH	641AR	4	
3024C	Con. rod (heavy type).....	1919-20	4				1 20	MH	641	4	
3025	Con. rod cap bolt.....	1909-23	20	80	3 50	22 00	05		489B	8	
3026	Con. rod cap bolt nut.....	1909-23	20	60	2 50	15 00	05		490	8	
3029	Con. rod clamp screw.....	1909-23	20	70	3 00		05		578	4	
3030	CRANK SHAFT.....	1909-23	2				9 00	MH	498B	1	
3031	C. S. rear bearing cap.....	1909-23	6				50		405AR	1	
†3031B	C. S. rear bearing cap.....	1909-23	6				59		405AR	1	
3032	C. S. front bearing cap.....	1909-23	6				40		406B	1	
†3032B	C. S. front bearing cap.....	1909-23	6				40		406B	1	
3033	C. S. center bearing cap.....	1909-23	6				40		407B	1	
†3033B	C. S. center bearing cap.....	1909-22	6				40		407B	1	
3034	C. S. bearing bolt—center and front.....	1909-23	10				10		408	4	
3035	C. S. bearing bolt nut.....	1909-23		Order 2551B							

*Specify with or without starter—Inquire of Branch for price.

xWhen used on car not equipped with starter also order 3017B, 3017C, 3011, 3008 and 3016.

†Used with 3000C cylinder on cars not equipped with starter.

††Connecting rods requiring new bearings will be exchanged by dealers at 60c each.

**Special rod for crankshafts worn .025" undersize.

†††Inquire of Branch for price.

‡Rough babbitted.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax	Fac. No.	No. Req. per Car	
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
MOTOR—Continued										
3036	C. S. rear bearing bolt	1909-23	10				\$ 0 10	478	2	
3038	C. S. bearing liner—center and front	1909-23	100		\$ 0 40	\$ 2 00	01	502B	8	
3039	C. S. rear bearing liner	1909-23	100		40	2 00	01	503B	1	
3040	C. S. starting pin	1909-20	20	\$ 0 60	2 50		05	529B	1	
3040B	C. S. starting pin	1920-23	20	60	2 50		05	529C	1	
3041	CAM SHAFT	1909-23	2				2 50	MH	410	
3042	Cam shaft front bearing	1909-23	10				25	411	1	
3043	Cam shaft center bearing	1909-23	10				25	412B	1	
3044	Cam shaft rear bearing	1909-23	10				15	413	1	
3045	Cam shaft bearing ring	1909-23	20	25	1 00		03	534	2	
3046	Camshaft bearing set screw	1909-23	20	70	3 00		05	414	2	
3047B	Time gear—large	1909-23	6				90	MH	415B	
3048B	Time gear—small	1909-23	6				60	MH	416B	
3049	Cam shaft gear dowel pin	1909-23	20	30	1 25		02	417	2	
3050B	Cam shaft gear lock nut	1909-23	10				10	4453	1	
3051	Small time gear key	1909-23	20	50	2 00		05	477	1	
3052	Valve	1909-23	32		12 00		15	MH	424B	
3052B	Valve— $\frac{1}{4}$ " O. S. stem	1909-23	16		12 00		15	MH	424AR	
3053 $\frac{1}{2}$	Valve bushing	1909-23	10				30	428	8	
3054	Valve spring	1909-23	20		3 50		05	431	8	
3056	Valve spring seat	1909-23	100		40	3 00Set	(05	425	8	
3057	Valve spring seat pin	1909-23	100		40	2 00of8	(05	429	8	
3058	Push rod	1909-23	20	1 80	8 00		10	MH	426B	
3058B	Push rod— $\frac{1}{4}$ " O. S. stem	1909-23	20	1 80			10	MH	426AR	
3059 $\frac{1}{2}$	Push rod bushing	1909-23	6				25	427	8	
3060B	Exhaust manifold	1913-23	3				1 25	MH	4483	
3061	Exhaust pipe pack nut	1909-23	10				20	518	1	
3062	Inlet pipe	1909-23	3				1 00	MH	512B	
3063	Inlet and exh. pipe gasket	1909-23	100		1 50	10 00	02	MH	513	
3064	Inlet and exh. pipe gland	1909-23	100		75	6 00	01	514	6	
3065	Inlet and exh. pipe clamp	1909-23	10				10	MH	515	
3066	Inlet and exh. clamp stud	1909-23	20	60	2 50		05	516	4	
3066B	Inlet and exh. clamp stud nut	1909-23	100		1 25	8 00	03	517	4	
3068	Breather pipe	1909-23	10		6 00		10	MH	4468	
3069B	C. C. front end support	1911-17	2		6 00		1 00	801C	1	
3069C	C. C. front end support	1917-23	2				50	801D	1	
3070B	C. C. & cyl. gasket—L	1909-23	20	70	3 00		05	886	1	
3071B	C. C. & cyl. gasket—R	1909-23	20	70	3 00		05	887	1	
3072	C. C. & cyl. cover cap screw	1909-23	20	50	1 80		03	1388	2	
3073	C. C. arm bolt—side	1909-23	20	60	2 50		05	479	2	
3074	C. C. arm bolt—top	1909-23	20	50	2 00		05	940	2	
3074B	C. C. arm bolt nut	1909-23	Order 2515							
3075B	C. C. frt. bearing & spring clip assy	1921-23	2				80	2921B	1	
3076B	C. C. front bearing and spring clip	1921-23	6				60	320C	1	
3076C	C. C. front bearing and spring clip nut	1921-23	Order 2548							
3077	C. S. front bearing cap	1909-23	6				10	321	1	
3078	C. C. front bearing screw	1909-21	20	60	2 50		05	322	2	
3078B	C. C. front bearing screw	1921-23	Order 3008							
3078C	C. C. front bearing lock washer	1921-23	20		50		01	5636	2	
3079	C. C. oil cock	1909-23	10		12 00		15	1515	2	
3080	C. C. drain cup plug	1909-23	Order 2532							
3080B	C. C. drain cup plug gasket	1909-23	20	40	1 75		03	MH	4339	
3081	C. C. oil tube	1909-23	6				20	543B	11	
3083	C. C. arm block	1909-23	6				05	890	2	
3084	Engine pan—right	1909-23	6				30	MH	1330	
3085	Engine pan—left	1909-23	6				30	MH	1331B	
3088B	Engine pan and hood board bolt	1909-23	100		1 50		03	4074	2	
3088C	Engine pan and hood board bolt	1909-23	100	35	1 50		03	4073	2	
3088D	Engine pan and hood board bolt—Truck	1918-23	20		1 50		03	TT4073	2	
3088E	Engine pan and hood board bolt nut	1909-23	100		75	5 00	01	1309		
3100	CRANK CASE	1912-23	2				11	00	MH	1526E
3101	Crank case lower cover	1912-23	2				40	MH	1582	
3101B	Crank case lower cover reinforcement	1912-23	4				25	4378-4379	1	
3102B	C. C. lower cover gasket	1912-23	20	1 40	6 00		10	1586	1	
3103	C. C. lower cover screw	1912-23	20	25	1 00		03	4328	14	
3110	Cylinder valve cover	1912-23	4				15	MH	656A	
3110B	Cylinder valve cover	1921-23	4				20	MH	656B	
3111B	Cyl. valve cover gasket	1912-23	20	60	2 50		05	660A	2	
3111C	Cyl. valve cover gasket	1921-23	20	1 20	4 50		10	660B	1	
3112	Cyl. valve cover screw	1912-23	20	35	1 50		02	654	2	
3114	C. C. arm with rivets	1909-23	6				30	815B	2	
3115	C. C. arm rivet	1909-23	50				doz. 05	312		

†When ordered to replace old style C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664, 1-3810 and 2-753 cotter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Minimum Wholesale Quan.	Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
COMMUTATOR									
3162...	Com. case support bolt.	1912-19	10				\$ 0 05	4441	1
3162B...	Com. case support bolt.	1919-23	10				05	1756	1
3163...	Com. case spring	1912-23	10				05	689	1
3165...	Com. brush only	1912-23	20				20	4481	1
3176C...	Com. oiler	1919-23	20	\$ 0 80	\$ 3 50		05	480C	1
3177...	Com. felt ring	1912-23	20	30	1 25		02	5930	1
3206...	Com. brush cap	1909-23	20	25	1 00		02	468B	1
3207...	Com. brush cap pin	1909-23	100		50		01	466	1
3210...	Com. contact point nut	1910-23	100		50		02	472B	8
3220...	Com. lock nut	1909-23	20	50	2 00		05	471	1
3221...	Com. case with fibre	1912-23	20				50	5908	1
3222...	Com. shield	1912-23	20	35	1 50		02	5923	1
MAGNETO									
3250D...	Magneto coil assembly	1915-23	2				5 00	5941B	1
3252...	Magneto spool support screw	1909-23	20						
3254...	Magnet bolt	1909-23	20	50	2 00		03	537B	16
3255B...	Magnet bolt washer	1911-23	20		50		01	624	16
3257...	Magnet brass support	1909-23	20	80	3 00		05	535C	16
3260...	Magneto contact assy.	1909-23	10		15 00		20	MH 1545	1
3261B...	Magneto contact nut	1909-23	20		50		01	1508	2
3261C...	Magneto contact screw washer	1909-23	20		50		01	1565	
3262...	Magneto contact spring	1909-23	20	70	3 00		05	1509	1
3262B...	Magneto contact screw and spring assembly	1919-23	10		7 50		10	4350	
3266...	Magneto contact fibre screw	1909-23	20		50		01	1505	3
3267...	Magneto primary insulating block	1915-23	10				05	4382	
3267B...	Magneto contact insulator	1919-23	10				05	1503B	
3267C...	Magneto contact insulator shell	1919-23	10				03	8611	
3268...	Fly wheel ring gear	1919-23	2				1 00	MH 1885	1
3269C...	Fly wheel	1911-19	2				6 00	MH 701B	1
3269G...	Fly wheel	1919-23	2				5 00	MH 701C	1
3269H...	Fly wheel with ring gear and magnets assembled	1919-23	2				15 00	MH 5946B	1
3270...	Fly wheel cap screw	1909-23	20		8 00		10	721	4
3271...	Fly wheel dowel pin	1909-23	20	80	3 50		05	722	2
3272...	Magneto coil support shim	1909-23	10		3 50		05	584	1
3276B...	Magnet (16)	1915-23	2			set	4 00	5933	16
3277...	Magnet clamp	1911-23	20	50	2 00		03	623	16
3277B...	Magnet clamp	1913-14	20				10	4499	16
3278...	Magnet clamp screw	1911-23	20	50	1 60	15 00	02	625	16
3279...	Magneto contact washer	1909-23	20	16	75		01	560	1
TRANSMISSION									
3300B...	Transmission assy.	1919-23	2				35 00	MH 744C	
3301...	Trans. reverse plate assy.	1909-23	4				2 50	MH 747	1
3304...	Trans. reverse gear bushing	1909-23	6				40	705	1
3305...	Trans. rev. and S. S. rivet	1909-23	60				doz. 05	708	8
3306...	Trans. slow speed plate assy.	1909-23	4				2 40	MH 748	1
3309...	Trans. slow speed gear bushing	1909-23	6				35	745	1
3310...	Trans. brake drum rivet	1909-23	60				doz. 05	711	8
3311...	Trans. brake drum assy.	1909-23	4				2 50	MH 750	1
3313...	Trans. triple gear assy.	1909-23	3				1 50	MH 751B	3
3314 1/2...	Trans. triple gear flanged bushing	1911-23	12				25	716B	3
3315...	Trans. triple gear shaft	1909-23	6				15	MH 715	3
3316...	Trans. triple gear riveting pin	1909-23	36				doz. 05	720	24
3317...	Trans. driven gear	1909-23	3				70	MH 713	1
3318...	Trans. driven gear key	1909-23	12				03	714	2
3320C...	Trans. driven gear sleeve bushing	1909-23	6				\$0 20	712	2
3320D...	Driven gear sleeve washer	1909-23	12				05	776	3
3321...	Trans. driving plate assy.	1909-23	2				3 00	MH 749	1
3323...	Trans. driving plate screw	1909-23	60				doz. 05	736	8
3325...	Trans. driving plate rivet	1909-23	60				15	772	1
3327B...	Trans. driving plate bush	1909-23	6				10	MH 727	12
3328...	Trans. clutch disc—small	1909-23	16		8 00		10	MH 728	13
3329...	Trans. clutch disc—large	1909-23	16		8 00		10	MH 728	13
3331...	Trans. gear shaft	1909-23	3				1 50	MH 723B	1
3332...	Trans. clutch disc drum	1909-23	3				1 25	MH 725B	1
3333...	Trans. clutch disc drum key	1909-23	10		4 00		05	726B	1
3334...	Trans. clutch disc drum set screw	1909-23	10		4 00		05	752	1

††When using short bushing in making repairs remove driving plate key.
Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req' per Car	
			Minimum Whole-sale Quan.	Lots of 20 per lot	Lots of 100 per lot					Lots of 1000 per lot
TRANSMISSION—Continued										
3336	Trans. clutch push ring	1909-23	6				\$ 0 35	MH	770	1
3337	Trans. clutch finger	1909-23	6				15	MH	732B	3
3337 1/2	Trans. clutch finger screw	1909-23	6		\$ 3 00		05		756	
3337B	Trans. clutch finger and screw	1909-23	6				20	MH	765	3
3338	Trans. clutch finger pin	1909-23	10				01		735	3
3340	Trans. clutch spring	1909-23	6				25		737	1
3341	Trans. clutch spring support	1909-23	6				10	MH	738	1
3342	Trans. clutch spring thrust ring pin	1909-23	20	\$ 0 50	2 00		05		739	1
3344	Trans. clutch shift	1909-23	6				50	MH	733	1
TRANSMISSION COVER										
3362	Trans. cover bolt	1909-23	100		2 00	\$ 15 00	03		79	
3362B	Trans. cover bolt nut	1909-23	Order 2515							
3363	Trans. cover gasket (front)	1909-23	20	35	1 25		05		872B	1
3363B	Trans. cover gasket—short	1909-23	20		1 00		03		4358	1
3367	Trans. cover door screw	1909-23	20	25	1 00		02		430	6
3368	Universal ball cap (rear)	1909-23	4				30	MH	818	1
3369	Universal ball cap (front)	1909-23	4				80	MH	819D	1
3371	Universal ball cap screw	1909-23	20	50	2 00	14 00	03		731	2
3372	Universal ball cap bolt and nut	1909-23	Order 3362 and 2515							
3375	Trans. cover screw	1909-23	Order 3072							
†3376B	TRANS. COVER	1919-23	2				6 50	MH	826E	1
3377B	Trans. cover gasket	1909-23	20	1 80	8 00	pr	10		885B	1
3378	Trans. cover door	1911-23	4				15	MH	1546D	1
3379B	Trans. cover door gasket	1911-23	20	90	4 00		05		1547C	1
3380	Bendix cover	1919-23	4				15	MH	1763	1
3381	Bendix cover gasket	1919-23	20	50	2 00		03		1764	1
3382	Trans. cover rear plate	1919-23	4				05	MH	1761	1
3383	Trans. cover front plate	1919-23	4				05	MH	1758	1
TRANSMISSION CONTROL										
3400	Trans. clutch release ring	1909-23	4				20	MH	741	1
3402D	Clutch lever and shaft	1913-23	4				30	MH	1548	
3403	Clutch lever screw	1909-23	Order 3973							
3403B	Clutch lever screw nut	1909-23	Order 3066B							
3405	Clutch lever pin	1909-23	10		60		01		1553	1
3406B	Clutch release fork—RorL	1913-23	4				15	MH	4345	2
3406C	Clutch release fork pin	1913-23	Order 3405							
3408	Clutch release fork key	1909-14	10		3 00		05		836	2
3409	Clutch release fork clamp screw	1909-14	10				05		835	2
3411	Clutch lever clevis pin	1909-23	Order 2564							
3413	TRANSMISSION BAND ASSEMBLY	1909-23	6				60	MH	838B	3
(Bands will be exchanged by dealers at 45 cents each)										
3415	Trans. band washer	1909-23	20	40	1 75		03		840	2
3416	Trans. band lining	1909-23	24		16 50		20	MH	1562	3
3416B	Trans. band lining—set of 3 inc. rivets—in carton	1909-23	8			set	70		1564	1
3419	Trans. band adj. screw	1909-23	12		7 50		10		1533	1
3420	Trans. band adj. screw nut	1909-23	20	60	2 50		05		1532	1
3421B	Trans. band ear iron rivet	1909-23	100			2 00doz.	05		843	12
3422B	Trans. band brass rivet	1909-17	1000			3 60doz.	05		844B	6
3423B	Trans. band brass rivet	1909-23	1000			2 50doz.	03		845B	24
3425	Trans. band spring	1909-23	20	50	2 00		05		841B	3
3426	Trans. band adj. nut	1909-23	20	50	2 00		15		851	2
3427	Slow speed shaft	1909-23	6				05	MH	848B	1
3428	Slow speed notch	1909-23	6				25	MH	4327	1
3429	Slow speed notch pin	1909-23	10		60		01		1560	1
3432	Speed lever	1909-23	2				10	MH	862B	
3434	Reverse pedal	1909-22	2				50	MH	4324	1
3435	Brake and rev. pedal shaft	1909-23	10				15		849B	2
3436	Brake and rev. shaft support	1909-23	6				20		4325	2
3437	Brake and rev. support bolt	1909-23	20	\$ 0 50	2 00		05		1534	2
3437B	Brake and rev. support bolt nut	1909-23	Order 2515							
3439	Brake pedal	1909-23	2				50	MH	4323	1
3440	Clutch pedal	1909-23	2				50	MH	854B	1
3441	Pedal pin	1909-23	Order 3405							
3442	Clutch pedal support	1909-23	6				20		4326	1
3443	Clutch pedal support bolt	1909-23	20	50	2 00		05		1536	1
3443B	Clutch pedal support bolt nut	1909-23	Order 2515							

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
TRANSMISSION CONTROL—Continued									
3445	Slow speed connection	1909-23	6		\$3 50		05	1540	1
3446	Slow speed con. lock nut	1909-23	Order 2503F						
3447	Slow speed con. clevis	1909-23	6		7 00		10	802	1
3448	Controller quadrant	1909-23	3				20	309B	1
3449	Con. shaft with speed lever	1909-23	2				60	MH 1557	1
3450	Controller shaft bracket	1909-23	3				15	MH 311	2
3452	Controller shaft bracket bolt	1909-23	20	\$0 50	2 00	\$15 00	03		4
3452B	Controller shaft bracket bolt nut	1909-23	20	30	1 25	9 00	02	316	4
3455	Hand brake lever	1909-23	2				1 00	MH 1550	1
3456B	Hand brake lever pin	1909-23	Order 2574						
3457	Hand brake lever key	1909-17	6				05	874	1
3458	Hand brake lever pawl	1909-23	10				05	875	1
3459	Hand brake lever pawl pin	1909-23	100		50		01	876	1
3460	Hand brake lever pawl rod	1909-23	2				10	MH 877	1
3462	Hand brake lever pawl lift assembly	1909-23	4				10	4363	1
3463	Hand brake lever pawl lift spring	1909-23	10				02	888	1
3465	Hub brake lever	1909-23	6				15	MH 864	1
3466	Hub brake lever pin	1909-23	Order 3405						
3467	Hub brake lever clevis	1909-23	Order 3447						
3468	Hub brake pull rod—R	1909-23	6				30	MH 891B	1
3469	Hub brake pull rod—L	1909-23	6				30	MH 1513B	1
3470	Brake rod support—R	1909-23	6	1 20	5 00		10	1367C	1
3471	Brake rod support—L	1909-23	6	1 20	5 00		10	1398C	1
3472	Brake rod support bolt	1909-23	100		75	5 00	01	1308	2
3472B	Brake rod sup. bolt nut	1909-23	Order 3088E						
STEERING GEAR									
3500C	Steering gear assy	1911-23	2				10 00	MH 5044	1
3501C	St. gear rim	1920-23	2				70	901C	1
3502	St. gear rim screw	1909-23	24				01	6849	4
3503D	St. gear spider	1920-23	2				50	MH 902C	1
3503E	St. gear spider and rim	1909-23	2				1 20	MH 995A2	1
3504	St. gear cover	1909-23	2				35	MH 5039	1
3505	St. gear cover screw	1909-23	24				01	910	1
3506	St. gear cover bushing	1909-23	6				15	914	1
3506B	St. gr. driv. pinion washer	1909-23	10				02	5026	1
3507	St. gr. int. gear case and bushing	1909-23	2				1 00	MH 5036	1
3509	St. gear quadrant	1909-23	2				15	MH 906B	1
3510	St. gear quadrant rivet	1909-23	24		50		01	5041	2
3511	St. gear wheel nut	1909-23	12		7 50		10	913	1
3512C	St. gear tubing assy	1912-23	2				4 00	MH 5016	1
3513C	St. tubing flange screw	1913-23	20	25	1 00		03	5018	3
3514	St. tub. flange screw nut	1913-23	100		75	6 00	02	926	1
3516C	St. gear post	1912-21	2				1 75	MH 5043	1
3516D	St. gear post	1921-23					1 75	MH 5043B	1
3517	St. gear pinion	1909-23	10				15	MH 916	3
3518	St. gear pinion pin—short	1909-23	10				02	917	2
3518B	St. gear pinion pin—long	1921-23	6				02	918	1
3519	St. gear drive pinion	1909-23	3				30	MH 911	1
3520	St. gear drive pinion key	1909-23	10		1 50		03	909	1
3523	St. gear post castle nut	1909-23	Order 2551B						
3524E	Throttle rod	1912-23	2				30	MH 5038	1
3525E	Lead rod	1912-23	2				30	MH 5037	1
3527	Lead & throttle rod spring	1909-23	10				02	935	2
3528	Lead & throttle rod collar	1909-23	10		1 00		02	936	2
3529	Lead & throttle rod pin	1909-23	10		50		01	937	5
3530	Lead rod lever	1909-23	6		7 50		10	MH 946	1
3531	Throttle rod lever	1909-23	6		7 50		10	MH 947	1
3532	Lead & throttle rod guide	1909-23	6				05	938	1
3534B	Commutator pull rod	1912-23	6				10	MH 2082	1
3535	Carburetor pull rod	1909-23	6		6 00		10	MH 1329	1
3536	Ball and socket joint	1909-21	20	1 70	7 50		10	1326	1
3537	Ball and socket joint nut	1909-21	20	25	1 00		02	1327	1
3539B	St. brkt. with bushing	1911-23	3				75	MH 996	1
3539C	St. brkt. with bushing—truck	1918-23	2				75	MH TT996	1
3540	Brkt. bolt and nut—long	1909-23	Order 3073 and 2515						
3541	Brkt. bolt and nut—short	1911-23	Order 3074 and 2515						
3544	St. brkt. felt washer	1909-23	12				02	943	1
3545	St. brkt. bushing	1909-23	4				20	944-5027	1
3546	St. brkt. block	1909-23	6				05	945	1
3546B	St. brkt. block—Truck	1918-23	4				05	TT945	1
3547	St. gear ball arm	1909-23	6				40	MH 929B	1
3548	St. gear ball arm key	1909-23	20	50	2 00		05	930	1
3549	St. brkt. dust cap—Truck	1918-23	10				05	TT5044	1
BODY PARTS									
3601B	Body brkt. on body	1910-23	10				10	1624	6
3601C	Body brkt.—front—R	1921-23	10				20	7267B	1
3601D	Body brkt.—front—L	1921-23	10				20	7268B	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
BODY PARTS—Continued										
3601E	Body bracket—rear	1913-23	10				\$0 05	5650		2
3601F	Body bracket—rear—R	1921-23	10				25	7137C		1
3601G	Body bracket—rear—L	1921-23	10				25	8001B		1
3602E	Body brkt. con. bolt	1916-23	30				03	2431		6
3602F	Body brkt. con. bolt nut	1916-23								
3624E	Front floor rubber mat	1915-23								
3626C	Floor board with plate (first)	1915-23	2				90	7299		1
3627C	Floor board with plate (second)	1915-23	2				50	4200		
3628B	Floor board with plate (third)	1915-23	2				50	4201		
3630	Floor board forward plate for pedals	1909-23	2				10	MH. 1400C		1
3632	Floor board rear plate for pedals	1909-23	2				10	MH. 1095C		1
3633	Floor board plate for side lever	1909-23	2				05	MH. 1094B		1
3634D	Dash	1913-14	2				7 00	5336		1
3634E	Dash	1915-16	2				5 00	7462		1
3634G	Dash	1917-22	2				2 50	MH. 8754AR		1
3634H	Dash—(steel)	1923	2				2 00	MH. 8754B		1
3638B	Dash shield	1919-22	4				10	5432B		1
3639	Dash weatherstrip—side	1917-22	6				05	8747		2
3639B	Dash weatherstrip—top	1917-22	6				15	8752R		1
††3640C	Dash brkt.—left	1917-22	6				15	8722		1
*3640D	Dash brkt.—right	1923	6				15	8722B		1
††3641C	Dash brkt.—left	1917-22	6				15	8721		1
*3641D	Dash brkt.—right	1923	6				15	8721B		1
3642B	Dash brkt. to dash bolt	1917-22	20	\$0 50	\$2 00		03	8740		4
3642C	Dash brkt. to dash nut	1917-22								
3645	Dash brkt. to dash bolt	1909-16	30				03	2427		2
3645B	Dash brkt. to dash nut	1909-16								
3653B	Dash to body brkt. bolt	1915-23	20	25	1 00		03	4248		2
3653C	Dash to body brkt. nut	1915-23								
3654	Dash to body gasket	1918-23	12		3 50		05	8769		
3660C	Lamp & license brkt. assy	1915-23	4				25	MH. 7506AR		1
3660D	Lamp & license brkt. assy	1915-23	4				25	MH. 7505		1
†3660E	Lamp & license brkt. sup- port assy	1923	4				1 00	MH. 7506B		1
†3661	Lamp & license brkt. sup.	1923	4				30	MH. 8767B		1
*3661B	Lamp & license brkt. sup.	1923	4				20	MH. 8768B		1
3662	Front license brkt.—R	1920	4				10	MH. 287		1
3663	Front license brkt.—L	1920	4				10	MH. 288		1
3664	Front license bracket	1921-23	4				10	MH. 493		1
3667E	Front seat cushion	1909-21	2				6 00	MH. 8076A		1
3667F	Front seat cushion	1921-23	2				6 00	MH. 8076B		1
3670D	Rear seat cushion	1909-21	2				6 50	MH. 7032A		1
3670E	Rear seat cushion	1921-23	2				6 50	MH. 7032B		1
3676B	Rear floor mat	1911-21	2				1 25	1606B		1
3676C	Rear floor mat	1921-23	2				1 00	1606C		1
SPRINGS										
3800	Front spring	1909-23	4				2 50	MH. 332		1
3801	First leaf (main leaf)	1909-23	6				80	2943		1
3802B	Second leaf	1909-23	6				50	2935		1
3803	Third leaf	1909-16	2				50	356		1
3803B	Third leaf	1916-23	6				40	2936		1
3804	Fourth leaf	1909-16	2				40	357		1
3804B	Fourth leaf	1916-23	6				30	2937		1
3805	Fifth leaf	1909-16	2				35	358		1
3805B	Fifth leaf	1916-23	6				25	2938		1
3806	Sixth leaf	1909-16	2				30	359		1
3806B	Sixth leaf	1916-23	6				20	2939		1
3807	Seventh leaf	1909-16	2				25	360		1
3807B	Seventh leaf	1916-23	6				15	2947		1
3808	Front spring clip	1909-23	10				20	325C		2
3809	Front spring clip nut	1909-23								
3810	Front spring clip bar	1921-23	6				25	342		1
3811	Front spring tie bolt	1909-23	20	35	1 50		04	1362		1
3811B	Front spring tie bolt nut	1909-23	20	25	1 00		02	1363		1
3813	Front spring hanger	1909-23	12		12 00		15	246B		4
3813B	Front spring hanger	1923	12				25	246C		2
3814	Front spring hanger bar	1923	12				05	7648		2
3815	Spring hanger nut	1909-23								
3818	Front spring perch—right	1909-19	4				60	MH. 274A		1
3818B	Front spring perch—right	1909-23	6				60	MH. 274B		1
3819	Front spring perch—left	1909-19	4				60	MH. 275A		1
3819B	Front spring perch—left	1919-23	6				60	MH. 275B		1
3820	Front spring perch bush	1909-23	20	50	2 00		05	230		4
3821	Front spring perch nut	1909-21								

††When used on 1911-16 cars redrill frame.

*Used with steel dash.

†Used on Touring Cars and Roadster without starter and demountable rims.

‡Used on Touring Car with starter without demountable rims.

**Used on Roadster with starter without demountable rims.

††Substitute 3634H—steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
SPRINGS—Continued									
3821B.	Front spring perch nut	1921-23	12				\$0 05.	240	1
3823	Front spring pad	1909-23	20		\$4 00c.		05.	262	1
3824	REAR SPRING	1909-23	3				7 00. MH	333	1
*3824B.	REAR SPRING	1922-23	2				7 25. MH	388	1
3825	First leaf (main leaf)	1909-19	2				1 50.	361A.	1
3825B.	First leaf (main leaf)	1918-23	3				1 50.	355	1
*3825C.	First leaf (main leaf)	1922-23	2				1 50.	389	1
3826	Second leaf	1909-19	2				1 25.	362A.	1
3826B.	Second leaf	1918-23	3				1 25.	362B.	1
*3826C.	Second leaf	1922-23	2				1 25.	391	1
3827	Third leaf	1909-19	2				1 10.	363A.	1
3827B.	Third leaf	1918-23	3				1 10.	363B.	1
*3827C.	Third leaf	1922-23	2				1 10.	392	1
3828	Fourth leaf	1909-19	2				95.	364A.	1
3828B.	Fourth leaf	1918-23	3				95.	364B.	1
*3828C.	Fourth leaf	1922-23	2				95.	393	1
3829	Fifth leaf	1909-19	2				80.	365A.	1
3829B.	Fifth leaf	1918-23	4				80.	365B.	1
*3829C.	Fifth leaf	1922-23	2				80.	394	1
3830	Sixth leaf	1909-19	2				75.	366A.	1
3830B.	Sixth leaf	1918-23	4				65.	366B.	1
*3830C.	Sixth leaf	1922-23	2				65.	395	1
3831	Seventh leaf	1909-19	2				70.	367A.	1
3831B.	Seventh leaf	1918-23	4				55.	367B.	1
*3831C.	Seventh leaf	1922-23	2				55.	396	1
3832B.	Eighth leaf	1909-23	4				45.	368B.	1
*3832C.	Eighth leaf	1922-23	2				50.	397	1
*3832D.	Ninth leaf	1922-23	2				45.	398	1
3833	Rear spring clip	1909-23	10				20.	326	2
*3833B.	Rear spring clip	1922-23	5				20.	1737	2
3834	Rear spring clip nut	1909-23	10	Order 2548			05.	329	2
3835	Rear spring clip bar	1909-23	10				04.	1352	1
3837	Rear spring tie bolt	1909-23	20	35	1 50		02.	1353	1
3837B.	Rear spring tie bolt nut	1909-23	20	25	1 00		04.	1355	1
*3838	Rear spring tie bolt	1922-23	10				15.	91 1/2B.	4
3840	Rear spring hanger	1909-23	10		12 00		25.	91 1/2C.	2
3840B.	Rear spring hanger	1923	10				05.	7649	2
3841	Rear spring hanger bar	1923	10				05.	94	1
3842	Rear spring leather pad	1909-23	10				40. MH	2804	2
3843	Rear spring perch	1909-23	6				05.	172	4
3844	Rear spring perch bush	1909-23	20	70	3 00		05.	174	2
3845	Rear spring perch nut	1909-23	20		4 00		05.	2944	4
3846	Spring perch oiler	1917-23	20	70	3 00		10.	374	2
3847	Front spr'g clamp assembly with bolt and nut	1909-16	20	1 50	6 00		10.	2953	2
3847B.	Front spr'g clamp assembly with bolt and nut	1916-23	20	1 50	6 00		10.	376	2
3848	Rear spr'g clamp assembly with bolt and nut	1909-17	20	1 50	6 00		10.	378	2
3848B.	Rear spr'g clamp assembly with bolt and nut	1918-23	20	1 50	6 00				
REAR SPRING—60 INCH TREAD									
3850	Rear spring	1909-16	2				9 00. MH	1704	1
3851	Rear spring clip	1909-16	2	Order 3833B			10.	1738	1
3852	Rear spring tie bolt	1909-16	2						
3852B.	Rear spring tie bolt nut	1909-16	2	Order 3837B			1 80.	1739	1
3853	First leaf (main leaf)	1909-16	2				1 60.	1740	1
3854	Second leaf	1909-16	2				1 40.	1741	1
3855	Third leaf	1909-16	2				1 20.	1742	1
3856	Fourth leaf	1909-16	2				1 00.	1743	1
3857	Fifth leaf	1909-16	2				90.	1744	1
3858	Sixth leaf	1909-16	2				75.	1745	1
3859	Seventh leaf	1909-16	2				60.	1746	1
3860	Eighth leaf	1909-16	2						
STARTING CRANK									
3900	Starting crank only	1909-22	2				40. MH	519B.	1
3901	Starting crank handle	1909-22	5				20.	520	1
3902	Starting crk. handle bolt	1909-22	20	1 20	5 00		10.	521	1
3903	Starting crank sleeve	1909-22	6		6 00		10.	523	1
3905	Starting crk. ratchet pin	1909-23	20	50	2 00		05.	4491	1
3906	Starting crank ratchet	1909-23	6				20. MH	528B.	1
3908	Starting crank spring	1909-23	20	40	1 20		05.	626	1
3909	Starting crk handlespring	1915-22	20		1 50		02.	5911	1
3910	Starting crank assy.	1909-23	2				50. MH	5931	1
RADIATOR—THERMO SYPHON									
3925	Radiator	1909-16	2				20 00. MH	1100C.	1
3925B.	Radiator	1917-23	2				17 00. MH	8700B.	1
3925C.	Radiator less shell	1917-23	2				15 75. MH	8736B.	1
3926	Radiator cap	1909-23	10		12 00		15. MH	8714	1
3928	Radiator pad	1909-19	10				05.	1105	2
3929	Radiator stud	1909-19	10				05.	1162A.	2
3929B.	Radiator stud	1919-23	20		4 00		05.	1162B.	2

*Nine-leaf spring for Sedan.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
RADIATOR—THERMO SYPHON—Continued									
3929C.	Radiator stud nut.....	1909-23	20		\$2 00.....	\$0 03.....	1154.....	2	
3930	Radiator stud spring.....	1909-23	Order 2742						
3931 1/2	Radiator stud washer nut.....	1909-23	20		2 00.....	03.....	1161.....	2	
3932	Radiator rod.....	1909-23	6			15..MH..	1111B.....	1	
3934	Radiator rod nut.....	1909-23	Order 3066B						
3939	Outlet connection pipe.....	1909-23	6			25.....	1121.....	1	
3940	Outlet connection cock.....	1909-23	Order 3079						
3944	Outlet connection hose.....	1909-23	20	\$1 80	8 00.....	10.....	507B.....	2	
3945	Outlet con. hose clip.....	1909-23	20	80	3 50.....	05.....	554B.....	4	
3947B.	Radiator shell.....	1917-23	4			1 25..MH..	8737B.....	1	
3975	Rad. stud spring upper thimble.....	1919-23	20			02.....	1115.....	1	
3976	Rad. stud spring lower thimble.....	1919-23	20			03.....	1114.....	1	
RADIATOR FAN									
3960	Fan and pulley assembly.....	1909-20	4			1 25..MH..	619.....	1	
3961	Fan blade.....	1909-20	6			10.....	611.....	4	
3961B.	Fan blade rivets.....	1909-20	1000		\$1 50doz.	05.....	1566.....	16	
3961C.	Fan blade assembly.....	1920-23	4			25..MH..	620.....	1	
3962B.	Dr. fan pulley with bush.....	1920-23	4			70..MH..	618B.....	1	
3963	Fan drive pulley.....	1909-20	6			25..MH..	602A.....	1	
3963B.	Fan drive pulley.....	1920-23	4			30..MH..	602B.....	1	
3964	Fan belt—23" fabric.....	1909-16	6			35.....	609A.....	1	
3964C.	Fan belt—26" fabric.....	1917-20	12			35.....	609B.....	1	
3964D.	Fan belt—fabric.....	1920-23	12		30 00	270 00	35.....	609C1.....	1
3964E.	Fan belt—rubber.....	1920-23	20		30 00	270 00	35.....	609C2.....	1
3966	Fan shaft.....	1909-20	10			25..MH..	606A.....	1	
3966B.	Fan shaft.....	1920-23	10		15 00	20..MH..	606B.....	1	
3967	Fan bracket.....	1909-16	2			40..MH..	604A.....	1	
3967B.	Fan bracket.....	1917-23	4			30..MH..	604B.....	1	
3968	Fan bracket bolt.....	1909-23	20		8 00	10.....	605.....	1	
3970	Fan grease cup.....	1909-23	12		8 00	10.....	601.....	1	
3973	Fan adjusting screw.....	1909-23	20	30	1 25.....	02.....	645.....	1	
3973B.	Fan adjusting screw nut.....	1909-23	Order 3066B						
3974	Fan driven pulley bush.....	1917-20	4			15.....	8757A.....	1	
3974B.	Fan driven pulley bush.....	1920-23	6			15.....	8757B.....	2	
3980	Fan pulley plug.....	1920-23	20		2 00	03.....	633.....	1	
3981	Fan pulley gasket.....	1920-23	20		1 50	02.....	634.....	1	
3982	Fan shaft cap.....	1920-23	20		1 00	02.....	635.....	1	
3983	Fan shaft felt washer.....	1920-23	20		1 00	02.....	637.....	1	
3984	Fan blade screw.....	1920-23	20		75	01.....	652.....	4	
3985	Fan blade screw washer.....	1920-23	Order 3261C						
3986	Fan shaft nut.....	1920-23	Order 2719						
MUFFLER									
4025	Muffler assembly.....	1909-20	4			2 25..MH..	1200BR.....	1	
4025B.	Muffler assembly.....	1921-23	2			2 25..MH..	1200C.....	1	
4026B.	Muffler head—front.....	1917-20	2			35.....	1202C.....	1	
4026C.	Muffler head—front.....	1921-23	2			10.....	1202D.....	1	
4027	Muffler shell—outer.....	1909-23	6			25.....	1203.....	1	
4028	Muffler shell—middle.....	1909-23	6			20.....	1204.....	1	
4029	Muffler shell—inner.....	1909-23	6			15.....	1205.....	1	
4030	Muffler rod.....	1909-17	6			10.....	1206A.....	3	
4030B.	Muffler rod.....	1917-20	6			10.....	1206B.....	1	
4031	Muffler rod nut.....	1909-20	Order 2503F						
4032	Muffler head retainer.....	1921-23	10			02.....	1210.....	1	
4033	Muffler head retainer bolt and nut.....	1921-23	Order 4819B and 3514						
4035	Muffler head bolt washer.....	1921-23	20			doz. 05.....	925.....	1	
4037B.	Long exhaust pipe.....	1909-20	3			1 25.....	1214A.....	1	
4037C.	Long exhaust pipe.....	1920-23	2			1 40..MH..	1214B.....	1	
4040B.	Muffler head—rear.....	1917-21	2			35.....	1201D.....	1	
4040C.	Muffler head—rear.....	1921-23	2			20.....	1201E.....	1	
4041B.	Muffler head to frame bolt and nut.....	1921-23	Order 3074 and 2515						
HOOD									
4050	Hood.....	1909-16	4			8 00.....	1300.....	1	
4050B.	Hood.....	1917-23	4			6 00..MH..	8726.....	1	
4051	Hood handle.....	1909-23	6			05.....	1314.....	2	
4052	Hood clip.....	1909-16	6			10.....	1310.....	4	
4052B.	Hood clip.....	1917-23	6			05.....	8731.....	4	
4053	Hood clip spring.....	1909-16	20			02.....	1311.....	4	
4053B.	Hood clip spring.....	1917-23	20	30	1 25.....	02.....	8734.....	4	
4056	Hood board.....	1909-16	6			25.....	1339.....	1	
4056B.	Hood board—left.....	1917-23	6			20.....	8742.....	1	
4057	Hood board—right.....	1909-16	6			25.....	1340.....	1	
4057B.	Hood board—right.....	1917-23	6			20.....	8741.....	1	
4060B.	Hood support on dash.....	1915-16	6			1 50.....	7464.....	1	
4060C.	Hood pad (on dash).....	1917-23	6		6 00	08..MH..	8711AR.....	2	
4060D.	Hood pad (on rad. shell).....	1917-23	6		12 00	15..MH..	8710.....	1	
*4060E.	Hood pad (on dash).....	1923	6			08..MH..	8711B.....	1	
4061B.	Hood clasp (on dash).....	1917-23	6		2 50.....	05.....	8720AR.....	1	

†Substitute 4025B.
*Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax	Fac. No.	No. Req. per Car
				Lots of 20 per lot	of 100 per lot	of 1000 per lot			
HOOD—Continued									
4061C.	Hood clasp(on dash)screw	1917-23	20				\$0 02	8763	2
4061D.	Hood clasp (on dash)	1920-23	6				05	8720BR	1
*4061E.	Hood clasp (on dash)	1923	6		\$2 50		05	8720C.	1
4073.	Hood bl support—front	R1917-23	12		2 50		05	8743	1
4074.	Hood bl support—front	L1917-23	12				05	8744	1
4075.	Hood bl support—rear	R. 1917-23	12				05	8745	1
4076.	Hood bl support—rear	L. 1917-23	12				05	8746	1

FORD CARBURETOR PARTS (MODEL "G")

4451A.	Float with lever	1914-21	6				30	6333AR	1
4452A.	Spray needle assembly	1914-21	6				15	6335AR	1
4453A.	Gasoline inlet needle	1914-21	6				15	6324A.	1
6041.	Mix chamber	1914-20	4				2 50	6340AR	1
6042.	Mix chamber top	1912-14-20	4				40	4801R	1
6043.	Mix chamber top screw	1912-20	10				02	4808R	1
6044.	Mix chamber top gasket	1914-20	10				01	6317R	1
6044B.	Mix chamber bottom gasket	1912-20	10				03	6367AR	1
6045.	Mix chamber nut	1912-20	6				07	4810AR	1
6046.	Float chamber & bush	1914-20	4				50	6318AR	1
6047.	Float lever pin	1914-20	10				03	6320AR	1
6048.	Float valve seat	1914-20	6				10	6321AR	1
6049.	Float valve seat gasket	1914-20	10				01	6322A.	1
6051.	Spray needle clamp nut	1912-20	6				05	4812AR	1
6052.	Spray nozzle	1914-20	6				30	6341AR	1
6053.	Spray nozzle gasket	1912-14-20	10				01	4820AR	1
6055.	Gas inlet elbow	1913-20	6				15	4859	1
6057.	Low speed tube with nut	1915-20	4				15	6360R	1
6058.	Low speed tube retaining screw	1912-14-20	6				03	4814R	1
6060.	Low speed boss screw	1912-14-20	10				03	4816R	1
6061.	Strangling tube	1912-14-20	6				15	4817R	1
6062.	Strangling tube retainer	1912-14-20	10				02	4818R	1
6064.	Throttle lever stop screw	1911-21	10				02	4520A.	1
6065.	Throttle lever clamp scr	1911-21	10				02	4521AR	1
6068.	Throttle plate	1912-14-20	6				10	4517AR	1
6070.	Throttle lever	1912-14-20	6				20	4836B.	1
6070B.	Throttle lever—over-size	1912-14-20	6				20	4836AR	1
6071.	Throttle lev. adj. lock nut	1911-20	10				02	4528R	1
6074.	Aux. throttle plate	1915-20	10				03	6337AR	1
6076.	Aux. throttle lever spring	1914-20	10				02	6342A.	1
6077.	Aux. throttle lever assy.	1914-21	6				15	6327A.	1
4463.	Float lever holding screw nut	1912-19	10				02	4805AR	1
4464.	Float lever holding screw	1913-19	10				03	4853AR	1
6081A.	Drain valve plug assy.								

Order T-6216
Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.

KINGSTON CARBURETOR PARTS (MODEL "L-2")

6101A.	Carburetor float assy.	1917-21	6				75	6333FR	1
6101.	Float with lever	1915-16	6				60	6333ER	1
6102.	Throttle lever	1913-20	6				30	4836CR	1
6103A.	Constant air supply lever	1913-20	6				30	6327CR	1
6104.	Gas valve cap	1910-16	6				15	3005	1
6105A.	Air valve cap	1915-16	6				30	6357AR	1
6105B.	Air valve cap	1917-20	6				30	6357BR	1
6106A.	Float chamber	1917-20	4				1 00	4802DR	1
6107A.	Mix chamber	1917-20	2				2 50	6340FR	1
6108.	Mix chamber gasket	1913-16	6				15	6367CR	1
6108A.	Mix chamber gasket	1917-20	10				03	6367DR	1
6109.	Throttle gate			Use 6068					
6110.	Constant air supply gate	1913-14	6				05	6337BR	1
6110A.	Constant air supply gate	1915-20	6				10	6337CR	1
6111.	Mix chamber nut	1913-20	6				10	4810BR	1
6114.	Gas valve retainer nut	1910-16	6				10	3027	1
6115.	Spray needle assembly	1910-21	6				40	6335D.	1
6118.	Float to lever and throttle gate screw	1910-16	10				02	3014	1
6118A.	Float to lever screw	1917-20	10				03	4853B.	1
6120.	Throttle lever adj. screw	1913-20	10				03	4520B.	1
6121.	Throttle lev. clamp screw	1910-20	10				03	4521BR	1
6122.	Gas valve operating lever shaft	1913-16	6				15	6320DR	1
6123.	Air valve shaft	1915-20	6				20	6381AR	1
6124A.	Spray needle sleeve			Order 6165					
6125.	Constant air supply spring	1913-20	10				03	6342C.	1
6126.	Float valve seat	1915-16	6				15	6321CR	1
6126A.	Float valve seat	1917-20	6				20	6321DR	1
6127.	Gas valve	1910-16	6				30	6324BR	1
6127A.	Gasoline valve	1917-21	6				35	6324CR	1
6128.	Air valve	1915-20	6				30	6355AR	1
6129.	Float valve seat gasket	1915-16	10				03	6322DR	1
6129A.	Float valve seat gasket	1917-20		Order 6049					

Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
KINGSTON CARBURETOR (MODEL "L-4")										
6150	Carburetor	1921-23	4				\$ 4 50		5531A	1
6151	Drain valve body	1921-23	6				15		6328C	
6152	Float chamber	1921-23	4				50		4802E	
6153	Mixing chamber	1921-23	4				2 50		6340G	
6154	Carb. inlet elbow									
Order 6055										
6155	Float with lever	1921-23	6				50		6333G	1
6156	Float chamber gasket	1921-23	6				05		555D	
6157	Mix chamber gasket	1921-23	10				03		6367E	
6158	Float valve seat gasket	1921-23	10				03		6322F	
6159	Constant air supply lever assy.	1921-23	6				30		6327D	
6160	Throttle lever assy.	1921-23	6				30		4836D	
6161	Spray needle assembly	1921-23								
Order 6115										
6162	Drain valve body clamp nut	1921-23	6				05		6395	
6163	Mix. chamber nut	1921-23	6				10		4810C	
6164	Constant air supply spring									
Order 6125										
6165	Spray needle sleeve	1915-23	6				20		4812C	
6166	Float lever pin	1915-23	10				02		6320C	
6167	Constant air supply plate	1921-23								
Order 6068										
6168	Throttle plate	1921-23								
Order 6209										
6169	Drain valve plug assy.	1915-23	6				10		6329B	
6170	Throttle lever adj. screw									
Order 6120										
6171	Air valve stop assy.	1921-23	6				15		6397	
6172	Float valve seat	1921-23	6				20		6321E	
6173	Air valve shaft assy.	1921-23	6				20		6381B	
6174	Air valve	1921-23	6				30		6355B	
6175	Gasoline valve	1921-23	6				35		6324D	1
FORD CARBURETOR (MODEL "NH")										
6200B	Carburetor	1920-23	4				4 50	MH	553A4	
6201	Float with lever	1920-23	6				30		6333B	1
6202B	Float chamber and bush- ing assy.	1920-23	6				50		6318B	
†6202C	Float chamber	1923	6				50		4802F	
6203	Float chamber gasket	1920-23	10				03		555B	
6204	Spray nozzle gasket	1920-23	10				01		4820B	
6205	Mixer chamber gasket	1920-23	10				03		6367B	
6206	Throttle lever									
Order 6070										
6206B	Aux. throttle lever									
Order 6077										
6207B	Mixer chamber	1920-23	4				2 50		6343R	
6208	Adj. needle clamp nut	1920-23	6				05		4812B	
6209	Throttle plate	1920-23	6				02		4517B	
6210	Float lever pin	1920-23	10				01		6320B	
6211	Float chamber screw	1920-23	6				05		6284	
6212	Float valve seat	1920-23	6				05		6321B	
6213	Spray needle assembly	1920-23	6				15		6335B	1
6214B	Spray nozzle	1920-23	6				20		6341C	
6215	Air passage vent plug	1920-23	6				05		6273R	
6216	Drain valve plug assy.	1916-23	6				10		6329	
6217	Throttle lever stop screw									
Order 6064										
6218	Aux. throttle lever spring									
Order 6076										
6219	Float valve seat gasket	1920-23	10				01		6322C	
6220	Gasoline inlet needle	1920-23								
Order 4453A										
†6221	Drain valve body	1923	6				15		6328D	
CARBURETOR ATTACHMENTS										
4127A	Carburetor adj. rod brkt.	1909-23	6				05		1357R	1
4129A	Carb. adjusting rod	1909-23	6				10	MH	7920	1
4130	Carb. flange bolt	1909-23								
Order 3072										
4130B	Carb. flange bolt nut	1909-23								
Order 3066B										
4134	Carb. flange gasket	1909-23	20	\$0 50	\$2 00		05	MH	1380B	1
4431	Carb. priming rod	1909-23	12				05	MH	2000	1
4582	Carb. hot air pipe	1912-23	6				20	MH	686	1
4583	Priming bell crank	1919-23	6				05	MH	7691	1
4585	Priming rod plate—Coupe	1919-20	6				10		7664	1
4586	Priming rod plate—Sedan	1919-20	6				10		7665	1
4587B	Priming rod—17 1/8"	1919-22	6				15	MH	6629BR	1
4588B	Priming rod—13 1/8"	1919-22	6				15	MH	6627AR	1
*4588C	Priming rod—16 1/8"	1922	4				15	MH	6630AR	1
*4588D	Priming rod—13 1/8"	1923	6				15	MH	6627B	1
*4588E	Priming rod—17 1/8"	1923	6				15	MH	6629C	1
*4588F	Priming rod—16 1/8"	1923	6				15	MH	6630B	1
4589	Priming rod—20 1/2"	1919-23	6				05	MH	8797B	1
4589B	Priming rod—14 1/2"	1922-23					05	MH	8797A	1
FENDERS—56 INCH TREAD										
4800B	Front fender—right	1917-23	4				4 00	MH	7976	1
4801B	Front fender—left	1917-23	4				4 00	MH	7977	1
4802F	Rear fender—right	1917-23	4				3 50	MH	8850	1
*4802G	Rear fender—right	1922-23	2				3 50	MH	7730	1
4803F	Rear fender—left	1917-23	4				3 50	MH	8851	1
*4803G	Rear fender—left	1922-23	2				3 50	MH	7731	1
4804D	Rear fender iron—R. & L. —T. C.	1913-23	6				15		5405	2

†Used with mixing chamber having slots at bottom.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
FENDERS—56 INCH TREAD—Continued										
4804E...	Rear fender iron—right —Cp. & Rbt.	1913-23	2				\$0 50	5563	1	
4804F...	Rear fender iron—left— Cp. & Rbt.	1913-23	2				50	5390	1	
4804G...	Rear fender iron—R. or L.—Sedan	1916-17	2				25	8154A	2	
4804K...	Fender iron—R. or L.— Sedan	1918-23	2				15	8154B	2	
4804L...	Rear fender iron—T. C.	1921-23	2				10	7395	2	
4805B...	Rear fender iron bolt	1915-23	20	\$0 35	\$1 50		03	7171	6	
4805C...	Rear fender iron bolt nut	1915-23	100		1 00	\$6 00	02	341		
4806B...	Fender eye bolt	1909-23	20				05	1942	4	
4806C...	Fender eye bolt washer	1909-23	20		50	4 00	01	1943	4	
4806D...	Fender eye bolt nut	1909-23	Order 2825B							
4808...	Front fender iron bolt (side)	1910-23	20		2 50	15 00	03	1323	2	
4808B...	Front fender iron bolt (bottom)	1910-23	20		2 50	15 00	03	347	2	
4808D...	Front fender iron bolt nut	1910-23	Order 2515							
4808C...	Front fender apron to frame bolt	1915-23	20	30	1 25	8 00	03	4088	4	
4808E...	Front fender apron to frame bolt nut	1915-23	Order 3088E							
4809...	Front fender iron—R or L	1909-23	2				60	343	2	
4850...	Frt.fender apron brkt.—R	1917-23	2				10	8854	1	
4851...	Frt.fender apron brkt.—L	1917-23	2				10	8855	1	
4852...	Frt. fender iron brkt.—R	1915-23	2				15	7984	1	
4853...	Frt. fender iron brkt.—L	1915-23	2				15	7998	1	
4854...	Rear fender iron bracket	1915-23	4				15	7483	2	
4855...	Rear fdr to R.B.shield bkt	1915-23	4				05	7994	2	
RUNNING BOARD AND SHIELDS—56 INCH TREAD										
4812...	Running board—R.	1909-23	4				1 25	MH 5418	1	
4813...	Running board—L.	1909-23	4				1 25	MH 5480	1	
4814C...	R. B. shield—R.	1917-23	4				2 40	MH 7986	1	
*4814D...	R. B. shield—R.	1922-23	2				2 40	MH 7747	1	
4815C...	R. B. shield—L.	1917-23	4				2 40	MH 7987	1	
*4815D...	R. B. shield—L.	1922-23	2				2 40	MH 7748	1	
4816...	R. B. truss rod—front with nuts	1909-21	4				35	MH 5804	1	
4817...	R. B. truss rod—rear with nuts	1909-21	4				35	MH 5805	1	
4817B...	Truss rod nut	1909-21	100		2 00		03	339	4	
4818B...	R. B. bracket assy.	1909-21	4				1 10	2926	2	
4819...	R. B. to rear fender bolt.	1909-20	20	30	1 25		03	1344B	4	
4819B...	R. B. to rear fender bolt.	1921-23	20	35	1 50		03	8161	4	
4819C...	R. B. to rear fender nut.	1909-23	Order 3088E							
4819D...	R. B. to rear fender nut.	1909-23	Order 3514							
4820...	R. B. to front fender bolt and nut	1909-20	Order 4808C and 3088E							
4820C...	R. B. to front fender bolt	1921-23	Order 4805B							
4821...	R. B. to shield clamp	1915-23	6				05	5478		
RUNNING BOARD—TRUCK										
4830...	Running board—R. or L.	1918-23	2				50	MH TT5418	2	
4831...	R. B. bracket	1918-23	2				35	TT2926	4	
4832...	R. B. bracket brace	1918-23	2				15	TT2927	2	
4833...	R. B. bracket rear brace	1918-23	2				30	TT2929	1	
4834...	R. B. bracket—rear	1918-23	2				35	TT2925		
4835...	R. B. bracket and brace assy.—frt.	1918-23	2				50	TT2928		
4836...	R. B. bracket and brace assy.—rear	1918-23	2				1 10	TT2930		
FORD SPARK COIL										
5000...	Coil (includes switch)	1909-22	2				8 65	MH 1383	1	
5001...	Coil (less switch)	1909-23	2				7 90	1383B	1	
5002...	Coil box with cover	1914-22	2				2 25	MH 5858	1	
5003...	Coil box with cover	1919-23	2				1 50	MH 5858B	1	
5004...	Coil box cover	1915-23	2				30	7910	1	
5005B...	Switch cover	1918-22	4				10	5835B	1	
5006...	Switch plug	1914-22	20	50	2 00		05	5815A	1	
5007...	Coil unit	1914-23	6				1 60	MH 5845	4	
5008...	Vibrator	1914-23	20	1 20	5 00	40 00	10	6797	4	
5009...	Vibrator bridge	1914-23	20	1 60	7 00	60 00	10	6702	4	
SWITCH										
5010...	Switch assembly (on coil)	1914-22	6				75	5873	1	
5012...	Ignition switch (on in- strument board)	1919-23	6				1 00	7675E	1	
5013B...	Switch key—give serial number	1919-23	6	1 20			10	5815C	1	
5014...	Starting switch (on floor bd)	1919-23	6				65	MH 8792	1	

*For Four-door Sedan.

†Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
SWITCH—Continued										
5014B.	Starting switch bracket bolt—long	1920-23	10				\$ 03	8760	1	
5014C.	Starting switch brkt assy	1923	4				30	8696		
5014E.	Starting switch cover and plunger assy.	1923	2				25	8698		
5015.	Starting switch plunger extension.	1919-23	6				10	8793	1	
AMMETER										
5016.	Ammeter	1919-23	6				80	7680	1	
5017.	Ammeter lens & rim	1919-23	6				20	8105	1	
5017B.	Ammeter lens	1919-23	6				05	8121	1	
BENDIX DRIVE										
5018.	Bendix	1919-23	4				5 00	1883	1	
5019.	Bendix head	1919-23	4				50	2007	1	
5020.	Bendix key	1919-23	20		\$1 50		02	1751	1	
5021.	Bendix shaft & gear	1919-23	6				4 50	2026	1	
5022.	Bendix spring	1919-23	6				50	2006	1	
5023.	Bendix shaft spring screw	1919-23	20		1 00		03	1983	1	
5024.	Bendix head spring screw	1919-23	100		2 00		05	1781	1	
5025.	Bendix spring screw lock washer	1919-22	20		75		01	1782	2	
WIRING										
5026.	Spark plug wire 14 1/8"	1909-23	20	\$1 40	6 50		10	MH.	1365	1
5027.	Spark plug wire (also magneto to coil) 10 1/2"	1909-23	20	1 30	6 00		10	MH.	1366	1
5028.	Spark plug wire, 7"	1909-23	20	1 20	5 00		10	MH.	1376	2
5030.	Commutator wire	1909-23	10				70	MH.	7502	1
*5030B.	Commutator wire	1922-23	10				1 00	MH.	7502C.	1
5031.	Com. wire, (starter type)	1919-23	10				1 00	MH.	7502B.	1
5033.	Com. wire loom support	1909-23	10				03		1390	2
5033B.	Com wire term. retainer	1921-23	10				01		2124	2
5033C.	Wire on dash clip	1919-23	20				01		7688	7
5033D.	Com. wire term. retainer	1923	10				01		2124B.	2
5034.	Ammeter to cutout wire —Sedan 33"	1919	6				15	MH.	7683A.	1
5035.	Ammeter to cutout wire —Sedan 49"	1919-23	6				20	MH.	7683B.	1
5036.	Ammeter to cutout wire —Coupe 23"	1919	6				15	MH.	7684A.	1
5037.	Ammeter to cutout wire —Coupe 41"	1919-23	6				20	MH.	7684B.	1
5038.	Ammeter to ignition switch wire	1919-23	6				10	MH.	7681	1
5039.	Gen. to cutout wire	1919	6				15	MH.	7687	1
5040.	Terminal block to switch wire	1919-23	6				05	MH.	8894B.	1
5041.	Lighting wire	1919-23	6				90	MH.	7682B.	1
5041B.	Lighting wire—truck	1921-23	2				1 00	MH.	TT7682	1
*5041C.	Lighting wire	1922-23	6				55	MH.	7661	1
5042.	Switch wire—Sedan	1919-23	6				75	MH.	7685B.	1
5043.	Switch wire	1919-23	6				70	MH.	7686B.	1
*5043B.	Switch wire	1922-23	6				50	MH.	7660	1
5044.	Terminal block	1919-23	6				05		1950AR.	1
5044B.	Terminal block	1923	6				05		1950B.	1
*5044C.	Terminal block	1922	6				05		1951AR.	1
*5044D.	Terminal block	1923	6				05		1951B.	1
5045.	Terminal block to dash screw	1919-23	12				01		2073	2
5046.	Battery to switch cable —28 1/4"	1919-23	4				80	MH.	1889B.	1
5046C.	Battery to switch cable—truck	1921-23	2				80	MH.	TT1889	1
5047.	Battery to switch cable —34"	1920	4				85	MH.	1889C.	1
5047B.	Battery to switch cable support—truck	1920-23	2				10		2116	1
5047C.	Battery to switch cable support	1920-23	2				10		2112	1
5047D.	Battery to switch cable support bush	1920-23	2				05		2113	1
5047E.	Battery to switch cable sleeve	1921-23	2				05		2120	1
5048.	Ground cable—20"	1919	4				70	MH.	1890A.	1
5049.	Ground cable—9 1/4"	1919-23	4				50	MH.	1890B.	1
5050.	Ground cable—11 1/8"	1920	4				60	MH.	1890C.	1
5051.	Switch to motor cable	1919-23	4				60	MH.	1891	1
5051B.	Switch to motor cable sleeve	1921-23	2				30		2119	1
5052.	Battery cable terminal bolt	1919-23	10				02		1937	2
5052B.	Battery cable terminal bolt nut	1919-23	10				01		1938	2

*Used on cars without starter, with switch on instrument panel.

‡Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot				
CUT-OUTS										
5054	Cut-out (electric) on dash	1919	2				\$ 1 10	MH.	7677AR	1
5055	Cut-out (electric)	1919-23	12				1 00	MH.	7677B	1
STARTER PARTS										
5056	Motor mount'g gasket	1919-23	20	\$ 35	\$ 1 50			02		1768
5057	Gen. head gasket	1919-23	20	25	1 00			02		1774
5058	Gen. m'nt'g short screw	1919-23	24		1 50			03		1755
5059	Bendix cover screw	1919-23	24		50			01		1765
5060	Term. blk. to wire screw	1919-23	24		50			01		2015
5061	Ammeter to plate screw	1919-23	24		50			01		5815
5062	Motor mounting screw	1919-23	100		1 00			02		5510
STARTING MOTOR AND PARTS										
5099	Starting motor	1919-23	2				17 00	MH.		1877
†5100	Armature	1919-23	2				5 00			1940
†5101	Cover band	1919-23	4				10			1801C
5102	Brush end bracket	1919-23	6				40			1868
5103	Bracket assy. mounting	1919-23	4				1 30			2037
5104	Brush	1919-23	12				25			1806
5105	Shaft rear bushing	1919-23	6				25			1759
5106	Shaft front bushing	1919-23	6				10			1789
5107	Field coil assembly	1919-23	2				2 00			1871
5108	Brush holder assembly	1919-23	6				60			1864B
5109	Terminal outer insulator	1919-23	20		1 00		02			1795
†5110	Terminal inner insulator	1919-23	20		60		01			1794
5112	Terminal nut	1919-23	20	40	1 75		03			1791
†5113	Field screw	1919-23	24		1 00		02			1788
†5114	Brush end bracket to yoke screw	1919-23	24				doz. 05			1808
5115	Brush tension spring	1919-23	20	70	3 00		05			1809
5116	Terminal washer	1919-23	24		75		01			1792
5117	Terminal inner steel washer	1919-23	24		50		01			1798
5118	Motor yoke assembly	1919-23	2				3 50			1852
GENERATOR AND PARTS										
5119	Generator	1919-23	2				17 00	MH.		1879
†5120	Armature (less bearings)	1919-23	6				5 00			1925
5121	Small bearing	1919-23	6				1 20			1838
5122	Large bearing	1919-23	6				1 45			1841
5123	Terminal bolt	1919-23	24		2 00		03			1836
5124	Brush end bracket	1919-23	6				30			1894
5125	Large brush	1919-23	24		16 00		20			1844
5126	Small brush	1919-23	24		15 00		20			1845
5127	Large bearing disc	1919-23	12				03			1847
5128	Small bearing felt	1919-23	12		1 00		02			2035
5130	Head	1919-23	4				50			2044
5131B	Small brush holder	1919-23	12		12 00		05			1821
5132B	Brush holder ring	1919-23	12				05			1996
5132C	Brush holder assembly	1919-23	6				50			1865
5132D	Brush holder assembly less small brush holder	1919-23	6				35			1920
5133	Terminal outer insulator	1919-23	20	50	2 00		03			1827
5134	Terminal nut	1919-23	24		1 50		03			1818
5134B	Brush holder stud nut	1919-23	24				01			6754
5135	Oiler	1919-23	20				05			1837
5136	Pinion to shaft pin	1919-23	24				doz. 05			1750
5137	Pinion	1919-23	6				40			1752
5138	Small brg. felt retainer	1919-23	24		1 50		02			1832
5139	Large brush spring	1919-23	20	70	3 00		05			1967
5140	Small brush spring	1919-23	20	70	3 00		05			1988
5141B	Small brush holder stud	1919-23	20	25	1 00		02			1823C
5142	Terminal washer	1919-23	100		1 00		02			1831
5142B	Small brush holder stud washer	1919-23	24				doz. 05			2058
5143	Field winding assembly	1919-23	2				1 50			1978
5144	Brush to terminal wire	1919-23	6				05			1851
5145	Gen. yoke assembly	1919-23	1				3 00			1887
BATTERY BRACKET AND PARTS										
5150	Bracket assembly	1919-23	2				90	MH.	8841AR	
*5150B	Battery bracket assy.	1923	2				90	MH.	8841B	1
5151	Clamp bolt	1919-23	24				03			8846
5151B	Clamp bolt nut	1919-23	24				03			8846
5152	Clamp	1919-23	6				05			8844AR
*5152B	Battery clamp	1921-23	6				05			8844B
5153B	Battery support angle— truck	1921-23	2				10			TT8816
5154	Battery box support— truck	1921-23	6				20			TT8817
5155	Battery clamp support— rear—truck	1921-23	2				15			TT8818

*Used on cars without starter, with switch on instrument panel.

†Used with steel battery box.

‡Also for generator.

†Armature may be exchanged with dealer at \$4.00.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax	Fac. Status No.	No. Req. per Car
				Lots of 20 per lot	Lots of 100 per lot	Lots of 1000 per lot			
BATTERY BRACKET AND PARTS—Continued									
5156	Battery clamp support— front—truck	1921-23	2				\$ 0 15	TT8819	1
5158	Battery box—less cover	1921-23	2				75	7671	1
5159	Battery box cover assy.	1921-23	2				60	5491	1
5160	Battery box cover door	1921-23	2				10	5493	
BATTERY (FORD)									
5175	Battery	1919-23	4				20 00	MH. 7670	1
5176	Battery case assy.	1919-23	2				1 25	5434	
5177	Cell connector	1919-23	6				15	5435	
5178	Cell cover	1919-23	6				30	5436AR	
5178B	Cell cover	1921-23	6				30	5436B	
5179	Terminal post gasket	1919-23	20				01	5437AR	
5179B	Terminal post gasket	1921-23	20				01	5437B	
5180	Rubber jar	1919-23	6				75	5438	
5181	Terminal post nut	1919-23	20				04	5439AR	
5181B	Terminal post nut	1921-23	20				04	5439B	
5182	Negative group assy.	1919-23	6				2 25	5440AR	
5182B	Negative group assy.	1921-23	6				2 25	5440B	
5183	Positive group assy.	1919-23	6				2 25	5441AR	
5183B	Positive group assy.	1921-23	6				2 25	5441B	
5184	Filler plug with gasket	1919-23	10				15	5444AR	
5184B	Filler plug with gasket	1921-23	10				15	5444B	
5184C	Filler plug	1923	10				10	5442C	
5185	Plate separator	1919-23	100		\$ 3 00	\$25 00	05	5445	
5186	Positive plate	1919-23	20				30	5427AR	
5186B	Positive plate	1921-23	20				30	5427B	
5187	Negative plate	1919-23	20				30	5428AR	
5187B	Negative plate	1921-23	20				30	5428B	
5188	Negative terminal post	1919-23	10				20	5425AR	
5188B	Negative terminal post	1921-23	10				15	5425B	
5189	Positive terminal post	1919-23	10				20	5426AR	
5189B	Positive terminal post	1921-23	10				15	5426B	
SPARK PLUGS									
5201	Spark plug "Ford" (Champion)	1909-23	20	\$9.00 net.	40.00 net.		60	1386A3	4
5203	Spark plug porcelain (Champion X)	1909-23	20	4.40 net.	20.00 net.		30	3760A	4
5203B	Spark plug porcelain "Ford" (Champion)	1909-23	20	4.40 net.	20.00 net.		30	3760C	4

Part No.	Name of Part	Minimum Whole- sale Quan.	List Price Each	Tax Status	Fac. No.
REPAIR TOOLS					
1349	Hub cap wrench	6	\$0 15		1349
1387	Adjustable wrench	6	40		1387
1903	Pliers	6	25		1903
1917	Double end wrench	6	15		1917
2335	Spark plug and cyl. head bolt wrench	6	40		5893
2336	Tool roll	6	25		1979
2337	Oil can	6	20		1384
2338	Tire pump	6	1 40	MH.	1368
2340	Tire irons, each	6	15		4069
2343	Jack	6	1 50		3389
TT4069	Tire iron (large)—Old No. 5Z-322	6	45		
5Z-152	Rear axle housing bolt nut wrench	6	40		
5Z-153	Socket wrench for crank shaft bear. bolt nut	6	60		
5Z-154	Body bracket con. bolt R. & L. wrench	6	30		
5Z-155	3/8" L socket wrench	6	45		
5Z-156	Crank shaft bearing bolt wrench	6	50		
5Z-157	Con. rod cap bolt nut L wrench (Cyl. No. 4)	6	40		
5Z-158	D/S housing stud nut wrench for 1/2" nut	6	50		
5Z-159	Connecting rod T wrench	6	55		
5Z-160	3/8" T socket wrench	6	75		
5Z-161	Body bracket connecting bolt T wrench, front and center	6	55		
5Z-162	Large cam gear lock nut wrench	6	55		
5Z-163	Generator third brush adjusting wrench	6	20		
5Z-165	Drive shaft pinion T wrench	6	65		
5Z-193	Spindle cone adjusting open end wrench	6	25		
5Z-195	3/8" open end wrench	6	25		
5Z-196	Rear axle entering wrench	6	30		
5Z-204	Exhaust pack nut open end wrench	6	1 00		
5Z-206	Rear axle nut open end wrench	6	65		
5Z-209	Connecting rod clamp screw wrench	6	45		
5Z-210	Fly wheel cap screw wrench	6	75		
5Z-212	Body bracket connecting bolt holding open end wrench	6	25		
5Z-232	Spindle arm bushing driver	6	40		

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Minimum Whole-sale Quan.	List Price Each	Tax Status	Fac. No.
REPAIR TOOLS—Continued					
5Z-249	Generator third brush adj. wrench—new style	6	\$0 20		
5Z-280	Valve grinder	6	75		
5Z-285	1 1/2" hex. brace wrench	6	75		
5Z-286	Rear axle nut and housing plug brace wrench	6	80		
5Z-287	Rear wheel puller assembly	4	1 00		
5Z-289	1 1/2" brace socket wrench	6	75		
5Z-290	Piston ring squeezer	6	30		
5Z-314	Transmission clutch disc drum puller	3	75		
5Z-319	Valve spring lifter	6	30		
5Z-323	Bendix shaft head puller	2	1 00		
5Z-324	Trans. band ratchet wrench	6	50		
5Z-325	Con. rod cap bolt nut brace wrench with universal joint for No. 4 connecting rod	2	2 50		
5Z-326	Small time gear and trans. driven gear puller	2	1 50		
5Z-361	Large time gear puller	2	9 00		
5Z-362	Cam gear puller (3-spoke design)	2	6 50		
5Z-457	Valve seat reamer—Old No. 20Z-340	2	2 50		
20Z-340-1	Valve seat reamer cutter	2	1 50		
21Z-356	Valve seat reamer handle	2	1 00		
REPAIR TOOLS—TRUCK					
5Z-288	Rear wheel puller assembly	2	1 20		
3389X	Jack	2	2 50		
COTTER PINS					
		Fac. No.			Fac. No.
3/8" x 1" cotter pins		421	3/8" x 1 1/2" cotter pins		66
3/8" x 3/4" cotter pins		753	1/2" x 1 1/2" cotter pins		544
1/2" x 1" cotter pins		82	3/4" x 3/8" cotter pins		88
Price, per dozen				05	
Price, per gross				25	
Price, per thousand				75	

Part No.	Name of Part	Year	LIST PRICE			Tax Status
			Minimum Whole-sale Quan.	Lots of 20 per lot	Lots of 100 per lot	
ELECTRIC HORN						
6432BRX	Electric horn complete		2			\$1 80
6432CX	Electric horn complete—battery type		2			2 00
7915X	Electric horn terminal wire 9"		6			05 MH
7917BX	Electric horn to switch wire 35 1/2"		6			10 MH
8028X	Horn switch assembly		6			30 MH
6437CX	Battery horn bracket		6			10
ELECTRIC HEADLAMPS (STANDARD 1915-23)						
6511CX	Headlamp—two bulb type		2 pr.		pr	7 00
6511HX	Headlamp assembly		2 pr.		pr	6 00
6511KX	Headlamp assembly		2 pr.		pr	6 00
6594AX	Door assembly—used with 6511DX		6			60
6594HX	Door assembly—with refracting lens		6			70
6589X	Switch assembly—with screws		6			35 MH
8650X	Headlamp and horn switch assembly		6			40 MH
8892ARX	Dimmer resistance coil with wires		2			50 MH
*8892BX	Dimmer assembly		2			50 MH
*8890X	Dimmer cover		2			10
6572AX	Headlamp bulb—9 volt—18 c.p.—double contact—used with magneto without dimmer	1915-18	20			35
6572EX	Headlamp bulb—6-8 volt—bright, 18 c. p., dim, 2 3/4 c.p.—double contact—double filament—clear—used with T6576BX lens	1921	20	\$37 50		40
6572HX	Headlamp bulb—6-8 volt—bright, 21 c. p., dim, 6/10 c.p.—double contact—double filament—used with T6576HX lens	1922-23	20	37 50		40
6572KX	Headlamp bulb—6-8 volt—21 c.p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens	1922-23	20			35
6578X	Door lens gasket		10			03
6576HX	Headlamp lens—refracting—in carton		10 pr.		pr	50
6592X	Plug—with thimble		10		8 00	10
6585AX	Reflector		6			75
6585BX	Reflector (dimmer type)		6			90
6580X	Focusing screw		10			03
6591X	Focusing screw spring		10			01
6574X	Bulb socket		10			15
6574BX	Head lamp plug socket		10			15
6586X	Reflector spring		10			05
7487X	Switch to terminal wire—11 1/2" long		10			05 MH
7489X	Lamp to lamp wire—40" long		10			10 MH
7490X	Lamp to ground wire—10 3/4" long		10			05 MH
2122X	Head lamp wire bushing		10			03
4082X	Head lamp and tail lamp wire bushing		10			01

*Used on cars without starter with switch on instrument panel.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status
			Whole-sale Quan.	Lots of 20	Lots of 100	Each	
SIDE OIL AND TAIL LAMPS—1915-23							
6561X	Side oil lamp, per pair		2 pr.			\$4 50	
6568X	Tail lamp		2			2 50	
6568BX	Oil tail lamp	1923	2			2 50	
7669X	Electric tail lamp assembly		4	\$16 00		90	
8786BX	Electric tail lamp and bracket assy	1923	4			1 30	
6484AX	Tail lamp red lens	1915-23	10			15	
6484BX	Electric tail lamp red lens		10		\$10 00	15	
6484CX	Oil tail lamp door lens (white) Edmunds & Jones design	1923	4			15	
6484DX	Oil tail lamp door lens (white) J. W. Brown design	1923	4			15	
6485B	Oil tail lamp side lens (red)	1923	4			10	
6405BX	Electric tail lamp white lens	1923	4			15	
6406X	Electric tail lamp white lens retainer	1923	4			05	
6520X	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2 1/4 c.p.—single contact	1919-23	20			20	
6495X	Electric tail lamp bulb socket		6			15	
2107X	Tail lamp wire clip		10			01	
2108X	Tail lamp wire spring		10			03	
6409X	Tail lamp wire bushing assembly		10			03	
6410X	Tail lamp wire bushing support		10			01	
TT8821X	Tail lamp to ground wire assembly		6			15 MH	
6599X	Side oil and tail lamp fount		2			50	
6956X	Side oil lamp door		2			50	
6957X	Tail lamp door		2			50	
6966X	Tail lamp white lens and frame		2			20	
6460X	Lamp burner		2			25	
6483X	Side oil lamp door lens		2			15	
6392X	Lamp wick		6			05	

TOURING CAR AND TORPEDO WINDSHIELDS—1915-22

†7840ARX	Windshield assembly, less glass		2			4 00
7818BX	W/S hinge assembly—right	1917-22	2			30
7819BX	W/S hinge assembly—left	1917-22	2			30
7820BX	W/S frame assembly—upper	1917-22	2			1 50
7822AX	W/S upper half assembly—less glass	1915-16	2			1 40
7822BX	W/S upper half assembly—less glass	1917-22	2			1 40
7823ARX	W/S lower half assembly—less glass	1915-22	2			1 65
7802ARX	W/S lower frame only	1915-22	2			1 00
7803ARX	W/S lower frame filler block	1915-22	2			15
7839X	W/S frame filler block	1915-17	2			15
7888ARX	W/S block (frame filler)—upper	1917-22	2			15
7810X	W/S hinge bolt	1915-16	10			03
7845ARX	W/S bracket—right	1915-22	2			50
7845BX	W/S bracket—right	1919-22	2			50
7846ARX	W/S bracket—left	1915-22	2			50
7846BX	W/S bracket—left	1919-22	2			50
7824ARX	W/S glass clamp	1915-22	6			02
7887X	W/S frame—upper	1917-22	2			75
3827X	W/S top snap loop	1915-22	2			02
1154X	W/S hinge bolt nut	1915-22		Order 3929C		
2449BX	W/S glass clamp screw	1915-22	10			01
2257BX	W/S hinge to frame screw	1915-22	10			02
292X	W/S hinge spring			Order 2742		
7851ARX	W/S upper glass stop—nickel	1915-22	6			20
7852ARX	W/S lower glass stop—nickel	1915-22	6			20
7808X	W/S hinge thimble	1915-22	6			03

TOURING CAR AND ROADSTER WINDSHIELDS—1922-23

7836X	Anti-rattler (windshield)	1922-23	4			15
6645X	Bolt (W/S bracket to instrument panel)	1922-23	12			03
7837X	Bracket (windshield) assembly—R. H.	1922-23	2			1 00 MH
7838X	Bracket (windshield) assembly—L. H.	1922-23	2			1 00 MH
*7891X	Bracket (side oil lamp)	1922-23	4			30
9066X	Channel (windshield) center	1922-23	4			35
7816X	Cone (W/S frame)	1922-23	4			10
7802BX	Frame (windshield) assembly—lower	1922-23	2			1 00
7887CX	Frame (windshield) assembly—upper	1922-23	2			1 00
7888BX	Filler (windshield upper frame)—lower	1922-23	4			05
7847X	Filler (windshield upper frame)—upper	1922-23	4			05
7803BX	Filler (windshield lower frame)	1922-23	4			10
7825X	Nut (windshield clamp stud wing)	1922-23	6			15
7842X	Nut (windshield cone lock)	1922-23	12			02
1307X	Nut (windshield bracket to instrument panel bolt) lower	1922-23	12			05
7851BX	Retainer (windshield glass) upper	1922-23	6			20
7852BX	Retainer (windshield glass) lower	1922-23	6			20
7826X	Stud (windshield frame clamping)	1922-23	12			03
7833X	Washer (windshield clamp stud nut)	1922-23	12			01
7840BX	Windshield assembly—less glass	1922-23	2			5 75 MH
7822CX	Windshield (upper half) ass'y.—less glass	1922-23	2			1 90
7823BX	Windshield (lower half)—less glass	1922-23	2			1 40
*8064X	Windshield bracket to body bolt	1922-23	12			02

*Used on cars without starter with switch on instrument panel.

†Order 7845X-7846X extra for 1915-16 cars.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	List Price Each	Tax Status
TOURING CAR TOPS—1915-22					
†7940ARX	Touring car top complete	1915-22	1		MH
6882ARX	T. C. storm curtain—R. H.	1915-22	2	\$2 00	MH
6883ARX	T. C. storm curtain—L. H.	1915-22	2	2 00	MH
4966BRX	T. C. side curtain—R. H.	1915-22	2	2 50	MH
4967BRX	T. C. side curtain—L. H.	1915-22	2	2 50	MH
6894ARX	T. C. center deck complete	1915-22	2	7 00	MH
6886ARX	T. C. center deck only 91 1/2" x 50"	1915-22	2	4 00	
8913ARX	T. C. side quarter—R. H.	1915-22	2	1 50	
8914ARX	T. C. side quarter—L. H.	1915-22	2	1 50	
6815ARX	T. C. side quarter pad	1915-22	2	1 00	
6940ARX	T. C. back stay and curtain assembly	1915-22	3	3 00	MH
3897X	T. C. wood bow	1913-17	2	75	
8973ARX	T. C. front and rear extension rib	1918-22	2	40	
8974ARX	T. C. front and rear upright rib	1918-22	2	40	
4596X	T. C. bow separator—male	1913-17	6	05	
4597X	T. C. bow separator—female	1913-17	6	05	
6832X	T. C. bow separator	1918-22	6	05	
6860ARX	T. C. front extension bow socket—R. H.	1915-17	2	1 00	
6860BRX	T. C. front extension rib socket—R. H.	1918-22	2	1 00	
6861ARX	T. C. front extension bow socket—L. H.	1916-17	2	1 00	
6861BRX	T. C. front extension rib socket—L. H.	1918-22	2	1 00	
3884ARX	T. C. rear extension bow socket—R. H.	1913-17	2	1 00	
3884BRX	T. C. rear extension rib socket—R. H.	1918-22	2	1 00	
3885ARX	T. C. rear extension bow socket—L. H.	1913-17	2	1 00	
3885BRX	T. C. rear extension rib socket—L. H.	1918-22	2	1 00	
6862ARX	T. C. front upright bow socket—R. H.	1915-17	2	1 00	
6862BRX	T. C. front upright rib socket—R. H.	1918-22	2	1 00	
6863ARX	T. C. front upright bow socket—L. H.	1915-17	2	1 00	
6863BRX	T. C. front upright rib socket—L. H.	1918-22	2	1 00	
3882ARX	T. C. rear upright bow socket—R. H.	1913-17	2	1 00	
3882BRX	T. C. rear upright rib socket—R. H.	1918-22	2	1 00	
3883ARX	T. C. rear upright bow socket—L. H.	1913-17	2	1 00	
3883BRX	T. C. rear upright rib socket—L. H.	1918-22	2	1 00	
7831ARX	Curtain to windshield hook	1915-22	10	02	
7832X	Curtain to body hook	1915-22	10	02	
8992X	Rib socket cotter	1918-22	10	05	
3924ARX	T. C. top to windshield strap assembly	1915-22	6	25	
3629ARX	T. C. rear strap assembly complete	1913-21	6	40	
3629BRX	Strap assembly	1921-22	4	40	
6829AX	T. C. duquesne clip—upper	1914-17	10	10	
6829BX	T. C. extension support—upper	1918-22	10	10	
6830AX	T. C. duquesne clip—lower	1914-17	10	10	
6830BX	T. C. extension support—lower	1918-22	10	05	
8937X	T. C. top snap fastener—single	1917-22	10	05	
8938X	T. C. top snap fastener—double	1917-22	10	05	
3314ARX	T. C. top prop rest with strap	1913-22	4	60	
3858X	T. C. top prop rest arm	1913-21	4	25	
3624X	T. C. bow socket to seat iron japanned nut	1913-22	6	03	
6682X	Curtain celluloid 20" x 50"—.015 thick (old No. 3383X)	1913-22	2	2 20	
6682X	Curtain celluloid 10" x 18"—.015 thick (old No. 3383X)	1913-22	2	40	
4981ARX	Touring car top visor	1920-22	2	50	
†8940X	Curtain fastener eyelet	1917-22	10	01	
†8943X	Curtain fastener eyelet washer	1917-22	10	01	
TOURING CAR TOPS—1922-23					
3573X	Brace (top extension)—R. H.	1922-23	2	35	
3574X	Brace (top extension)—L. H.	1922-23	2	35	
**3588X	Top clamping bracket assembly	1922-23	2	25	
**6902X	Glove fastener button	1922-23	12	02	
††6940BRX	Curtain (rear) assembly	1922-23	2	2 50	MH
6940CX	Curtain (rear) assembly	1922-23	2	2 50	MH
††4966CRX	Curtain (rear side) assembly—R. H.	1922-23	2	2 00	MH
4966DX	Curtain (rear side) assembly—R. H.	1922-23	2	2 00	MH
††4967CRX	Curtain (rear side) assembly—L. H.	1922-23	2	2 00	MH
4967DX	Curtain (rear side) assembly—L. H.	1922-23	2	2 00	MH
6882BX	Curtain (front side) assembly—R. H.	1922-23	2	2 00	MH
6883BX	Curtain (front side) assembly—L. H.	1922-23	2	2 00	MH
6886BX	Deck (top) only	1922-23	2	3 50	
††6894BRX	Deck (top) assembly	1922-23	2	6 00	MH
6894CX	Deck (top) assembly	1922-23	2	6 00	MH
**6903X	Eyelet (side curtain rear glove fastener)	1922-23	12	02	
**6904X	Fastener (rear curtain glove)	1922-23	12	02	
**7831BX	Hook (curtain to windshield)	1922-23	12	02	
6815BX	Pad (top side quarter) assembly	1922-23	2	1 00	
††8913BRX	Quarter (side) and reinforcement assembly—R. H.	1922-23	2	1 25	
8913CX	Quarter (side) and reinforcement assembly—R. H.	1922-23	2	1 25	
††8914BRX	Quarter (side) and reinforcement assembly—L. H.	1922-23	2	1 25	
8914CX	Quarter (side) and reinforcement assembly—L. H.	1922-23	2	1 25	
**3314BX	Rest (prop) and strap assembly	1922-23	6	40	
8975X	Rib (top) center and rear	1922-23	2	40	
8973BX	Rib (top) front	1922-23	2	40	
8974BX	Rib (top) center ext.	1922-23	2	40	
**3548X	Screw (front socket fastener)	1922-23	12	doz. 05	

†Inquire of Branch or Dealer for price.

‡Quantity price \$0.50 per hundred.

**Also used on 1922 Roadster Top.

††Used on tops with straight side quarters.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents the excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	List Price Each	Tax Status
TOURING CAR TOPS—1922-23—Continued					
6860CX	Socket (top rib) front—R. H.	1922-23	2	\$ 1 00	
6861CX	Socket (top rib) front—L. H.	1922-23	2	1 00	
3882CX	Socket (top rib) center—R. H.	1922-23	2	1 25	
3883CX	Socket (top rib) center—L. H.	1922-23	2	1 25	
†3884CRX	Socket (top rib) rear—R. H.	1922-23	2	1 25	
3884DX	Socket (top rib) rear—R. H.	1922-23	2	1 25	
†3885CRX	Socket (top rib) rear—L. H.	1922-23	2	1 25	
3885DX	Socket (top rib) rear—L. H.	1922-23	2	1 25	
6862CX	Socket (top rib) center ext.—R. H.	1922-23	2	1 00	
6863CX	Socket (top rib) center ext.—L. H.	1922-23	2	1 00	
6844BX	Top center strainer	1922-23	4	40	
6846X	Top quarter strainer	1922-23	4	40	
*3629CX	Strap (stay)	1922-23	4	20	
**3542X	Strip (rear curtain finishing)	1922-23	2	15	
**6901X	Stud (rear curtain glove fastener)	1922-23	12	02	
3551X	Center support on rear socket	1922-23	6	05	
3564X	Center ext. support—on center socket	1922-23	6	05	
3572X	Center ext. to brace support	1922-23	6	05	
*7940BX	Top assembly	1922-23	2	75	MH
**4981BX	Visor (top) assembly	1922-23	2	75	
**6905X	Washer (side curtain rear glove fastener)	1922-23	12	02	
TORPEDO TOP PARTS—1915-22					
*7941ARX	Torpedo top complete	1915-22	2		MH
4971X	Torpedo top—second and third wood bows	1914-18	2	50	
6929X	Torpedo top—first bow	1915-18	2	50	
8772X	Rib—upright	1918-22	2	40	
8988X	Rib—front extension	1918-22	2	40	
8989X	Rib—rear extension	1918-22	2	40	
6870AX	Torp. bow socket—upright—(R. H.)	1915-18	2	1 25	
6870BX	Torp. rib socket—upright—(R. H.)	1918-22	2	1 00	
6871AX	Torp. bow socket—upright—(L. H.)	1915-18	2	1 25	
6871BX	Torp. rib socket—upright—(L. H.)	1918-22	2	1 00	
6872AX	Torp. bow socket—front extension—(R. H.)	1915-18	2	1 00	
6872BX	Torp. rib socket—front extension—(R. H.)	1918-22	2	1 00	
6873AX	Torp. bow socket—front extension—(L. H.)	1915-18	2	1 00	
6873BX	Torp. rib socket—front extension—(L. H.)	1918-22	2	1 00	
4907AX	Torp. bow socket—rear extension—(R. H.)	1913-18	2	1 00	
4907BX	Torp. rib socket—rear extension—(R. H.)	1918-22	2	1 00	
4908AX	Torp. bow socket—rear extension—(L. H.)	1913-18	2	1 00	
4908BX	Torp. rib socket—rear extension—(L. H.)	1918-22	2	1 00	
6937AX	Torp. side curtain—rear—(R. H.)	1915-22	2	1 50	MH
6938AX	Torp. side curtain—rear—(L. H.)	1915-22	2	1 50	MH
6935AX	Torp. side curtain—front—(R. H.)	1915-22	2	2 00	MH
6936AX	Torp. side curtain—front—(L. H.)	1915-22	2	2 00	MH
6950AX	Torp. back curtain assembly	1915-22	3	2 50	MH
6965AX	Torp. center deck complete	1915-22	2	4 50	MH
6964AX	Torp. top deck only	1915-22	2	2 50	
6962AX	Torp. side quarter—(R. H.)	1915-22	2	1 00	
6963AX	Torp. side quarter—(L. H.)	1915-22	2	1 00	
6806AX	Torp. side quarter pad	1914-22	2	60	
3877X	Torp. prop rest with strap	1913-22	6	60	
4955AX	Torp. top visor	1920-22	2	50	
†ROADSTER TOP—1922-23					
6935BX	Curtain (front side) assembly—R. H.	1922-23	2	2 00	MH
6936BX	Curtain (front side) assembly—L. H.	1922-23	2	2 00	MH
6937BX	Curtain (rear side) assembly—R. H.	1922-23	2	1 50	MH
6938BX	Curtain (rear side) assembly—L. H.	1922-23	2	1 50	MH
6950BX	Rear curtain assembly	1923	2	2 50	MH
6964BX	Top deck only	1922-23	2	2 50	
6865BX	Top deck assembly	1922-23	2	4 00	MH
6806BX	Top side quarter pad assembly	1922-23	2	60	
6962BX	Side quarter and reinforcement assembly—R. H.	1922-23	2	1 00	
6963BX	Side quarter and reinforcement assembly—L. H.	1922-23	2	1 00	
8988BX	Top rib—front	1922-23	2	40	
8989BX	Top rib—center and rear	1922-23	2	40	
4907CX	Top rib socket, rear—R. H.	1922-23	2	1 00	
4908CX	Top rib socket, rear—L. H.	1922-23	2	1 00	
6872CX	Top rib socket, front	1922-23	2	1 00	
6870CX	Top rib socket, center—R. H.	1922-23	2	1 00	
6871CX	Top rib socket, center—L. H.	1922-23	2	1 00	
*7941BX	Top assembly	1922-23	2		MH

*Inquire of Branch or Dealer for price.

**Also used on 1922 Roadster Top.

††Used on tops with straight side quarters.

‡For additional 1922 Roadster top parts see 1922 Touring Car top parts marked with a double asterisk (**)

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			No. Fac. Req. Model No. per Car
				Lots of 100 per lot	Each	Tax Status	
REAR AXLE							
1000	Rear axle assembly	1918-23	2	\$125 00	MH	TT	95 1
1001	Axle housing—right	1918-23	2	15 00	MH	TT	4 1
1002	Axle housing—left	1918-23	2	15 00	MH	TT	5 1
1003	Axle housing bolt	1918-23	20	03		TT	52 13
1003B	Axle housing bolt nut	1918-23		Order 2719			
1004	Axle housing cap	1918-23	6		MH	TT	133 1
1005	Axle housing cap gasket	1918-23	20	\$1 50	02	TT	134 1
1006	Axle housing cap screw	1918-23	20	05		TT	72 4
1007	Axle housing cap screw lock wire	1918-23	20	01		TT	140 1
1008	Axle housing gasket—upper	1918-23	10	02		TT	138 1
1009	Axle housing gasket—lower	1918-23	10	05		TT	139 1
1010	Axle brake housing plate—right	1918-23	6	35	MH	TT	147 1
1011	Axle brake housing plate—left	1918-23	6	35	MH	TT	148 1
1012	Axle housing drain plug	1918-23	2	05		TT	136 2
1013	Axle shaft	1918-23	10	4 00	MH	TT	48 2
1014	Axle shaft cotter	1918-23	24	doz.	05	TT	165 2
1015	Axle shaft nut	1918-23	20	8 00	10	TT	166 2
1016	Axle shaft washer	1918-23	20	2 00	03	TT	135 2
1017	Axle shaft dust cap	1918-23	10			TT	56 2
1018	Axle shaft inner ball bearing assy.	1918-23	2	5 00		TT	125 2
1019	Axle shaft outer roller bearing	1918-23	2	1 25		TT	253 2
1020	Axle shaft outer R. B. sleeve—R	1918-23	2	35		TT	170 2
1020B	Axle shaft outer R. B. sleeve—L	1918-23	2	35		TT	161 1
1021	Axle shaft bearing felt	1918-23	20	12 00	15	TT	143 4
1022	Axle shaft bearing retainer	1918-23	10	05		TT	20 2
1023	Axle shaft bearing retainer washer	1918-23	20	1 50	02	TT	23 2
1024	Axle shaft felt retainer assembly	1918-23	10	20		TT	144 1
1025	Axle shaft felt retainer cup	1918-23	10	03		TT	145 2
1025	Axle shaft felt retainer plate	1918-23	10	03		TT	146 2
1027	Diff. gear	1918-23	2	1 00	MH	TT	13 2
1028	Diff. gear case R. or L. half	1918-23	2	2 00	MH	TT	11 2
1029	Diff. gear case bolt	1918-23		Order 1003			
1031	Diff. gear lock ring	1918-23	10		02	TT	118 2
1032	Diff. pinion	1918-23	2	50	MH	TT	14 2
1033	Diff. pinion shaft	1918-23	2	20	MH	TT	15 1
1034	Drive shaft	1918-23	2	7 00	MH	TT	87 1
1036	D. S. tube assembly	1918-23	2	10 00	MH	TT	153 1
1037	D. S. tube flange gasket	1918-23	20	1 25	02	TT	194 1
1038	D. S. tube flange screw	1918-23		Order 1006			
1039	D. S. felt	1918-23	10		10	TT	109 1
1040	D. S. felt container	1918-23	10	03		TT	110 1
1041	D. S. to worm coupling	1918-19	2	1 00		TT	85A 1
1041B	D. S. to worm coupling	1920-23	2	70		TT	85B 1
1042	D. S. to worm coupling pin	1918-23	10	01		TT	86 2
1043	Worm—7/8 to 1	1918-23	2	6 00	MH	TT	16A 1
1043B	Worm—5/8 to 1	1918-23	2	6 00	MH	TT	16B 1
1044	Worm gear—7/8 to 1	1918-23	2	10 00	MH	TT	12A 1
1044B	Worm gear—5/8 to 1	1918-23	2	10 00	MH	TT	12B 1
1045	Worm cotter	1918-23		Order 1014			
1046	Worm roller bearing	1918-23	2	90		TT	108 2
1047	Worm roller bearing retainer	1918-23	10	50		TT	106 1
1048	Worm roller bearing sleeve	1918-23	2	1 02		TT	107 2
1049	Worm roller bearing housing screw	1918-23	10	03		TT	101 2
1050	Worm thrust bearing collar	1918-23	2	80		TT	114 2
1051	Worm thrust ball and separator assy.	1918-23	2	75		TT	123 1
1052	Worm thrust bearing plate	1918-23	2	15		TT	22 1
1053	Worm thrust bearing retainer	1918-23	2	15		TT	111 1
1054	Worm thrust bearing retainer nut	1918-23		Order 1015			
1055	Worm thrust bearing retainer pin	1918-23	10	01		TT	112 1
1056	Brake shoe	1918-23	4	1 50	MH	TT	281A 2
1057	Brake shoe lining, each	1918-23	10	25	MH	TT	58 4
1058	Brake shoe lining rivet	1918-23	100	doz.	10	TT	68 40
1059	Brake shoe spring	1918-23	10	05		TT	67 2
1060	Brake shoe bolt	1918-23	10	05		TT	59 2
1060B	Brake shoe bolt nut	1918-23		Order 2828			
1061	Brake expander	1918-23	4	40	MH	TT	61 2
1062	Brake expander lever	1918-23	4	15	MH	TT	62 2
1064	Brake expander adjustment collar	1918-23	4	15		TT	175 2
1065	Brake expander bushing	1918-23	4	10		TT	173 2
1066	Brake expander pin	1918-23	4	01		TT	7 2
1067	Brake expander link	1918-23	10	08	MH	TT	176 4
1068	Brake expander link pin	1918-23	20	03		TT	177 8
1069	Brake rod	1918-23	4	30	MH	TT	119 2
*1070	Brake rod support—right	1918-23	6	5 00	10	TT	120 1
*1071	Brake rod support—left	1918-23	6	5 00	10	TT	121 1
1072	Brake rod support bolt	1918-23	10	02		T7181	2
1072B	Brake rod support bolt nut	1918-23		Order 3088E			
1073	Rear radius rod—right	1918-23	2	2 80		TT	152 1

*20-lot price \$1.40.
 †100-lot price \$0.50.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Cart No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			No. Fac. Req. No. per Car
				Lots of 100	Each	Tax Status Model	
REAR AXLE—Continued							
1073B	Rear radius rod—left	1918-23	2		\$2 80	TT	158 1
1074	Rear radius rod bolt—front	1918-23	10		10	TT	84 1
1075	Rear radius rod bolt—rear	1918-23	10		10	TT	83 4
1075B	Rear radius rod bolt nut	1918-23	Order	2828			
1076	Universal joint bushing	1918-23	2		50	TT	69 1
SPRINGS							
1077	Rear spring—right or left, each	1918-23	2		4 50	MH TT	333 2
1078	Spring leaf No. 1	1918-23	2		1 00	TT	334 2
1079	Spring leaf No. 2	1918-23	2		60	TT	362 2
1080	Spring leaf No. 3	1918-23	2		55	TT	363 2
1081	Spring leaf No. 4	1918-23	2		45	TT	364 2
1082	Spring leaf No. 5	1918-23	2		40	TT	365 2
1083	Spring leaf No. 6	1918-23	2		35	TT	366 2
1084	Spring leaf No. 7	1918-23	2		30	TT	367 2
1085	Spring leaf No. 8	1918-23	2		25	TT	368 2
1086	Spring leaf No. 9	1918-23	2		20	TT	331 2
1087	Spring bushing	1918-23	2		20	TT	332 2
1088	Spring clip	1918-23	2		45	TT	325 2
1089	Spring clip nut	1918-23	10		05	TT	327 2
1091	Spring clip plate	1918-23	4		20	TT	329 4
1092	Spring tie bolt	1918-23	4		20	TT	330 2
1093	Spring tie bolt nut	1918-23	Order	1089			
1094	Spring tie bolt cotter	1918-23	24		*doz. 05	TT	328 2
1095	Spring clamp	1918-23	4		10	TT	375 2
1096	Spring clamp bolt	1918-23	4		03	TT	376 2
1096B	Spring clamp bolt nut	1918-23	Order	3514			
1097	Spring perch	1918-23	2		80	MH TT	2804 2
1098	Spring perch nut	1918-23	Order	1015			
1099	Spring perch cotter	1918-23	Order	1014			
1100	Spring perch bushing	1918-23	2		25	TT	172 2
1101	Spring perch bushing spacer	1918-23	10		05	TT	169 4
1102	Spring hanger assembly	1918-23	6		30	TT	91 4
WHEELS							
1105B	Rear wheel—dem. Kelsey	1919-23	2		18 50	TT	7698 2
1105C	Rear wheel—dem. Hayes	1919-23	2		18 50	TT	7698B 2
1105D	Rear wheel—dem.—less rim and hub—Kelsey	1919-23	2		9 00	TT	2817AR 2
1105E	Rear wheel—dem.—less rim and hub—Hayes	1919-23	2		9 00	TT	2817BR 2
1106C	Dem. rim only—Hayes	1919-23	2		3 50	TT	8774B 2
1106D	Dem. rim only—Kelsey	1922-23	2		3 50	TT	8774C 2
1106E	Dem. rim retainer ring—Kelsey	1922-23	2		45	TT	178 2
1107B	Clamp and nut assembly—Kelsey	1919-23	20		15	TT	8807 12
1108B	Clamp bolt	1919-23	20		05	TT	8832 12
1109	Rear wheel complete, less tire	1918-20	2		17 50	TT	99 2
1109B	Rear wheel—solid tire design—less hub and tire	1919-23	2		13 25	TT	2816 2
1110	Rear wheel complete, with solid tire	1918-20			MH	TT	7645 2
1111	Rear hub	1918-23	2		2 25	TT	40 2
1112	Rear hub flange	1918-23	2		40	TT	149 2
1113	Rear hub brake drum	1918-23	2		1 25	TT	3 2
1114	Rear hub bolt	1918-23	20	\$3 00	05	TT	28 12
1114B	Rear hub bolt nut	1918-23	20	1 50	02	TT	29 12
1116	Rear hub cap	1918-23	6		25	TT	150 2
1117	Rear hub key	1918-23	10		03	TT	26 2
1118	Rear hub felt	1918-23	10	4 00	05	TT	162 2
FRAME							
1119	Frame assembly	1918-23	2		30 00	MH TT	300 1
1120	Side member—right	1918-23	2		10 00	TT	301 1
1121	Side member—left	1918-23	2		10 00	TT	302 1
1122	Front cross member	1918-23	2		1 00	TT	303 1
1123	Rear cross member	1918-23	2		4 00	TT	304 1
1124	Front corner bracket—right	1918-23	2		15	TT	305 1
1125	Front corner bracket—left	1918-23	2		15	TT	306 1
1125B	Front end spacer—right	1918-23	2		15	TT	319 1
1125C	Front end spacer—left	1918-23	2		15	TT	318 1
1126	Rear cross member gusset plate	1918-23	2		25	TT	307 2
1127	Rear cross member reinforcement	1918-23	2		35	TT	325 2
TRANSMISSION CONTROL							
1133	Speed lever	1918-23	2		10	MH TT	862 1
1134	Controller shaft with speed lever	1918-23	2		60	MH TT	1557 1

*\$0.25 gross, \$0.75 per thousand.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

