

Ford

THE UNIVERSAL CAR

WHOLESALE

PRICE LIST OF PARTS

MODEL T

Effective October 1, 1924

Ford Motor Company
Detroit, Michigan

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*

Ford Factory, Ford, Ontario, Canada

Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Buffalo	Columbus	Houston	Louisville	Omaha	San Francisco
Cambridge	Dallas	Indianapolis	Memphis	Philadelphia	Seattle
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Washington
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	
Cincinnati	Detroit	Kearny, N. J.	New Orleans	St. Louis	

Instructions for Ordering Parts

- 1—Order all parts through the Authorized Ford Dealer.
- 2—On parts delivered from Dealers' stocks, regardless as to quantity ordered, the Wholesale Trade is entitled to a discount of 25% from list price. Parts may be obtained f. o. b. the nearest Ford Branch at a discount of 30% from list price, providing the net amount of the order exceeds \$200.00. The above discounts apply to the ten, hundred and thousand lot prices as well as to prices on individual items.
- 3—Always give Catalog Number and Name of each part ordered.
- 4—Specify whether shipments are to be made by freight or express.
- 5—Remittance by Draft or Money Order must accompany all parts orders placed for shipment from the Ford Branch.

Telegraph Code

We list below a brief General Code covering miscellaneous instructions relative to the shipment of parts.

- | | |
|--|---|
| Toperig —Ship to me (us) by express. | Topfton —When and how did you ship parts called for in my (our) telegram of — |
| Toperkleur —Ship by express to — | Topflutch —When and how will you ship parts called for in my (our) telegram of — |
| Topersteen —Ship to me (us) by freight. | Topwasser —When and how will you ship parts called for in my (our) letter of — |
| Toper —Ship to me (us) by parcel post. | |

WHOLESALE PRICE LIST OF PARTS

FORD MODEL T 1909-1924

EFFECTIVE OCTOBER 1, 1924

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac.	No. Req. per Car	
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
REAR AXLE									
2500	Rear axle assembly	1909-24				\$55 00	MH	95E	1
2501	Axle housing—right	1915-24				8 00	MH	7635D	1
2502	Axle housing—left	1915-24				8 00	MH	7636D	1
2503E	Axle housing bolt	1913-24	\$0 20	\$1 00	\$6 00			2854	7
2503F	Axle housing bolt nut	1909-24	.15	1 00	6 00			44	7
2504	Rear axle case gasket	1919-24	.15	1 00				139	1
2505	Axle shaft	1912-24	14 00			1 50	MH	2818	2
2506	Axle shaft washer	1909-24	.15	.75				39	1
2507	Axle shaft nut	1909-24	.45	3 50				242	2
2508	Axle shaft R. B.	1909-24	6 00					253	4
2509	Axle shaft R. B. sleeve—R	1909-24						170	2
2509B	Axle shaft R. B. sleeve—L	1909-24						161	2
2510	Axle housing cap	1909-19	.25	2 00				56AR	2
2510 1/2	Axle housing cap	1919-24	.20	1 80				56B	2
2510A	Axle outer roller bearing steel washer	1909-24	.15	1 00				199B	2
2510B	Axle outer roller bearing felt washer	1909-24	.40	3 00	27 50			54	2
2512C	Diff. case—left	1914-24				1 50	MH	84	1
2513C	Diff. case—right	1914-24				90	MH	81	1
2514B	Diff. case stud	1915-21	.35	3 00				52BR	3
2514C	Diff. case bolt	1922-24	.35	3 00				52C	3
2515	Diff. case stud nut	1909-24	.20	1 50	10 00			8	3
2518	Diff. drive gear	1909-24				2 50	MH	12B	1
2519	Diff. drive gear screw	1909-24	.25	2 00	15 00			103	10
2519A	Diff. gear lock ring	1909-24	.15	1 00				118	2
2520B	Diff. gear	1909-24				90	MH	13B	2
2521B	Diff. gear key	1911-24	.40	3 50				137	2
2524C	Diff. pinion	1915-24				35	MH	14D	3
2526B	Diff. spider	1909-24				75	MH	15D	1
2528	Diff. thrust washer	1909-24				15		30	2
2529	Diff. thrust plate	1909-24	1 25	10 00				31	4
2530	Diff. thrust plate pin	1909-16		1 50				17	4
2531	Diff. thrust plate pin	1909-16		1 00				37	2
2531B	Diff. thrust plate pin	1917-24	.10	.75				7640	6
2532	Diff. housing oil plug	1909-24				05		817	1
2545	Rear axle grease cup	1909-24	.60	5 00				76A2	1
2547	Rear radius rod—right	1909-24	10 00			1 25	MH	152	1
2547B	Rear radius rod—left	1909-24	10 00			1 25	MH	158	1
2548	Radius rod nut	1909-24	.40	3 00	25 00			77	2
2549	Radius rod lock nut	1909-24	.40	3 00				78	2
2550	Radius rod lock washer	1909-24	.15	1 00				2823	2
2551	Radius rod bolt	1909-24	.35	3 00				83	4
2551B	Radius rod bolt nut	1909-24		2 50	20 00			60	4
2557	Hub cam shaft—right	1909-24				10	MH	92B	1
2558	Hub cam shaft—left	1909-24				10	MH	61B	1
2559	Hub cam shaft bushing	1909-24	.35	2 50				173	2
2562	Cam shaft lever	1909-24				10	MH	62	2
2563	Cam shaft lever pin	1909-24	.10	.50				7	4
2564	Lever clevis pin	1909-24	.15	1 00				65	4
2566	Hub brake shoe	1909-24				35	MH	2814	2
2567	Brake shoe support bolt	1909-24	.35	3 00	25 00			59	2
2568	Brake shoe support nut	1909-24							
2570B	Brake shoe coil spring	1913-24	20	1 50				2862	4
2571	Universal joint assembly	1909-24				1 50		151B	1
2572	Joint knuckle (male)	1909-24				50		45B	1
2573	Joint knuckle (female)	1909-24				60		46B	1
2574	Joint knuckle pin	1909-24	.10	.75				6	1
2575	Joint ring, complete	1909-24	.40	00				49B	1
2576	Joint ring rivets (per set 4)	1909-24	.10	.50				50	4
2577B	Univ. joint housing	1914-24				1 00		7609	1
2578	Joint housing plug	1909-24	.30	2 00				75	2
2579	Ball joint grease cup	1909-24	.10	20	10 00			195	1
2580	Ball cap gasket	1909-24	.30	2 50	20 00			1518	1

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac.	No. Req. per Car	
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
REAR AXLE—Continued									
2581	Drive shaft housing front bushing	1909-24				\$ 0 30		69	1
2582	D. S. rubbing	1911-24				7 00	MH	153B	1
2583B	D. S. bearing housing	1920-24				1 40	MH	191C	1
2584B	D. S. R. B. cap screw	1912-24		\$ 3 00		.05		183B	6
2584C	D. S. R. B. stud nut	1912-21	\$ 0 25	2 00		.03		184R	6
2584D	D. S. R. B. cap screw lock washer	1912-24		.20			doz.	05	157
2586	D. S. R. B. housing set screw	1911-21		45	4 00			05	101R
2587	D. S. roller bearing	1911-24	6 00					75	108
2588	D. S. R. B. distance plate	1911-21	.15	1 00				05	MH
2589	D. S. ball race	1911-21						25	185R
2589B	D. S. ball bearing easy	1911-21						90	185AR
2590	D. S. ball retainer	1911-21		20	1 25			03	190AR
2591	D. S. ball thrust collar	1911-24						20	188
2591B	D. S. thrust ball and retainer assembly	1920-24		1 50				20	162
2592	D. S. ball bearing	1911-21						1 50	107R
2593	D. S. R. B. sleeve	1911-21						3 00	MH
2595B	D. S. only	1911-24						50	163B
2596	D. S. sleeve	1911-24	.40					1 00	MH
2597B	D. S. pinion	1911-24						1 00	MH
2597C	D. S. pinion	1911-24						1 00	MH
2598	D. S. castle nut	1911-24		6 00				08	124
2598B	D. S. pinion key	1911-24	.40	3 00				05	57B
REAR AXLE—60 INCH TREAD									
2600C	Rear axle housing—right	1915-16				12 00	MH	2728C	1
2601C	Rear axle housing—left	1915-16				12 00	MH	2729C	1
2602B	Rear axle shaft—tapered	1911-16				3 00	MH	2725	2
2604	Rear radius rod	1909-16				2 00		1726	2
FRONT AXLE									
2691	Front axle only	1909-24				9 00	MH	202B	1
2694B	Spindle body—right	1911-24	.14	00				1 50	MH
2695B	Spindle body—left	1911-24	.14	00				1 50	MH
2696	Spindle arm—right or lf.	1911-19						50	MH
2696C	Spindle arm—right	1919-24						45	MH
2696D	Spindle arm—left	1919-24						45	MH
2697	Spindle arm nut	1911-24						45	MH
2704	Stationary cone	1909-24						15	205A
2705	Adj. cone—right thread	1909-24						15	206A
2706	Adj. cone—left thread	1909-24						15	207A
2707	Spindle nut—right thread	1909-24						05	209B
2708	Spindle nut—left thread	1909-24						05	208B
2709	Spindle washer	1909-24	.15	1 00	\$ 6 00			02	210
2710	Spindle bolt with oiler	1910-24	1 60	15 00				20	7708
2711	Spindle bolt nut	1909-24						1 80	17 00
2713	Spindle body bush. (pair)	1909-24		17 00	150 00			20	223
2714	Spindle arm bushing	1909-24	.15	1 25	9 00			05	225
2715D	Spindle oiler	1919-24						12 50	
2717	Spindle con. rod	1909-24						1 75	MH
2718	Spindle con. rod bolt with oiler	1909-24	1 20	10 00				15	7706
2719	Spindle con. rod bolt nut	1909-24		2 00	15 00			03	220
2721B	Spindle con. rod yoke ball	1919-24	.15	50				20	MH
2721C	Spindle con. rod yoke	1919-24	.35	50				40	MH
2725B	Steering gear con. rod	1909-24	.60	00				80	MH
2728	Ball socket cap	1909-24	1 20					15	254B
2729B	Ball socket bolt and nut	1909-24						14 00	
*2733B	Front radius rod	1919-24				1 50	MH	263B	1
2736	Front radius rod ball cap	1909-24				10		217	1
2737	Front radius rod ball socket	1911-21						20	809B
2741	Radius rod ball cap stud	1911-24		2 00				03	4365
2741B	Radius rod ball cap stud nut	1911-24							
2742	Radius rod ball cap spr'g	1911-24	.20	1 25	8 00			03	292

When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

* Substitute 2733B, with spring perches, for 2733

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
FRONT AXLE—Continued									
2760	Front axle only—60"	1911-16				\$10 00	MH	1720B	1
2761	Spindle con. rod—60"	1909-16				3 00	MH	1725	1
2762	Steer. gear con. rod—60"	1909-16				1 25	MH	2739	1
WHEELS									
2800	Front wheel—clincher	1909-24				6 00		291B	2
2800B	Front wheel—dem. less rim and brgs.—Kelsey	1919-24				6 00		291D	2
2800C	Front wheel—dem. less rim and brgs.—Hayes	1919-24				6 00		291E	2
2800D	Front wheel—clincher—less hub	1909-24				4 00		295AR	2
2800E	F. and rear wheel—dem. less rim & hub—Kelsey	1919-24				3 80		293AR	4
2800G	Front wheel—dem.—less rim and brgs.—Ford	1919-24				6 00	MH	291G	2
2800H	Frt. and rear wheel—dem. less rim & hub—Ford	1919-24				3 80	MH	293CR	4
2801	Front wheel complete R. or L.—dem.—Kelsey	1919-24				8 00		7697A	2
2801B	Front wheel complete R. or L.—dem.—Hayes	1919-24				8 00		7697B	2
2801C	Front wheel complete R. or L.—dem.—Ford	1919-24				8 00	MH	7697C	2
2803	Front hub assy.	1909-24				1 60		200	2
2803B	Front hub with R B cups	1909-24	\$16 00			1 80		219	2
2804	Outer race	1909-24		\$ 7 50		10		234	2
2805	Inner race	1909-24		11 00		15		235	2
2806	Outer ball retainer	1909-24		15 1 00		02		236	2
2807	Inner ball retainer	1909-24		20 1 25		03		237	2
2808	Dust ring	1909-24		25 1 50		03		238	2
2809	Front & rear hub felt washer	1909-24	45	3 50	\$ 30 00	05		239	4
2810	Large balls	1909-24		3 00	25 00	04		241	24
2811	Small balls	1909-24		1 50	13 50	03		249	22
2814C	Rear wheel—clincher	1912-24				6 50		2815	2
2814D	Rear wheel—clincher—less hub	1909-24				4 25		2816	2
2814E	Rear wheel complete—dem.—Kelsey	1919-24				7 75		7698A	2
2814F	Rear wheel complete—dem.—Hayes	1919-24				7 75		7698B	2
2814G	Rear wheel—dem. less rim—Kelsey	1919-24				5 75		2815B	2
2814J	Rear wheel—complete—dem.—Ford	1919-24				7 75	MH	7698C	2
2814K	Rear wheel—dem.—less rim—Ford	1919-24				5 75	MH	2815E	2
2815C	REAR HUB	1912-24				1 25	MH	2819	2
2816A	Rear hub key	1912-24	20	1 50	12 00	03		2863	2
2818	Rear hub brake drum	1909-24	3 50			40		3B	2
2819	Hub cap	1909-24	1 30	12 00		15		7727	4
2825	Rear hub bolt	1911-24	20	1 50	8 00	03		28B	12
2825B	Hub bolt nut	1911-24	15	1 00	6 00	03		29	24
2826	Front hub bolt	1911-24	20	1 50	8 00	03		27	12
2827	Hub flange	1911-24				20		233B	4
2828	Rear hub lock nut	1912-24	45	3 50		05		242	2
2833	Front hub bear. cup inner	1919-24	4 25	35 00		50		2955	2
2834	Inside cone and roller assy	1919-24	10 00			1 10		205B	2
2836	Front hub bearing cup—outer	1919-24	3 50	30 00		40		2956	2
2837	Outside cone and roller assy.—right thread	1919-24	6 50			75		206B	1
2838	Outside cone and roller assy.—left thread	1919-24	6 50			75		207B	1
2841	Front hub dust cap assy	1919-24	80	7 00		10		350	2
2845	Demountable rim only—Kelsey	1919-24	13 50			1 50		8774A	4
2845B	Demountable rim only—Hayes	1919-24	13 50			1 50		8774B	4
2845C	Demountable rim only—Ford	1922-24	13 50			1 50		8774C	4
2846B	Demountable rim clamp—Kelsey	1919-24	50	4 25		10		8831B	16

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
WHEELS—Continued									
2846C	Dem. rim clamp and nut assy.—Ford	1922-24				\$ 15		8807	16
2847	Demountable rim bolt	1919-24	\$0 35	\$ 2 50	\$23 00	05		8832A	16
2848	Dem. rim nut—Hayes	1919-24	35	2 50	23 00	05		8834B	16
2848B	Dem. rim nut—Kelsey	1919-24	35	2 50	23 00	05		8834A	16
2849	Spare rim carrier	1919-24				2 25	MH	8848C	1
2849C	Spare rim carrier clamp support and bolt assy.	1921-24		10 00		15	MH	7511	1
2849D	Spare rim carrier clamp	1921-24				10		7312C	1
2870	Spare rim carrier brkt—R	1919-22				50		8824AR	1
2870B	Spare rim carrier brkt—L	1922-24				50		8824B	1
2871	Spare rim carrier brkt—L	1919-22				50		8825AR	1
2871B	Spare rim carrier brkt—L	1922-24				50		8825B	1
FRAME									
2850	Frame assembly	1909-24				13 00	MH	2916	1
2851B	Slide member—right	1914-24				4 00		2914	1
2852B	Slide member—left	1914-24				4 00		2915	1
2853	Front cross member	1909-24	8 00			90		303	1
2854B	Rear cross member	1914-24				1 20		2913	1
2855	Front corner bracket—R	1909-24				15		305	1
2856	Front corner bracket—L	1909-24				15		306	1
2857	Rear corner bracket—R	1909-24				15		307	1
2858	Rear corner bracket—L	1909-24				15		308	1
2859	Front end spacer—L	1909-24				10		318B	1
2860	Front end spacer—R	1909-24				10		319B	1
2863	Body bracket	1909-24				10		344	4
GASOLINE TANK									
2900B	Gas tank—Sedan	1916-24				6 00	MH	7950	1
2900C	Gasoline tank	1909-24				4 00	MH	1303B	1
2901	Filling plug	1909-24	90	8 00		10		1317	1
2902B	Sediment bulb	1909-24				90		2088	1
2908	Pet cock	1909-24				25		1364	1
2909	Feed pipe—40 1/2"	1909-24				30		7965	1
2909B	Feed pipe—51 1/2"	1916-24				35		9775R	1
2909C	Feed pipe—66 1/2"	1918-19				35		8690	1
2909D	Feed pipe—56 1/2"	1919-24				05		1374	2
2910	Feed pipe pack nut	1909-24	45	3 00		60		1394R	1
2911	Feed pipe—78"	1915				02		5892	1
2913	Feed pipe gasket	1909-24		1 00		20		2132	1
2914	Gas tank support—R	1917-20				20		2132B	1
2914B	Gas tank support—R	1920-24				20		2133	1
2915	Gas tank support—L	1917-20				20		2133B	1
2915B	Gas tank support—L	1920-24				20		2133B	1
2916	Feed pipe clamp	1921-24				01		2118	1
MOTOR									
*2990B	Motor assy.—less starter	1909-24				*110 00	MH	532C	1
2991	Cylinder assy. (oversize)	1909-24				55 00	MH	449	1
2991B	Cyl. assy.—std.	1909-24				65 00	MH	449	1
3000C	Cylinder	1909-24				25 00	MH	400D	1
3001	Cylinder head	1909-24				6 00	MH	401C	1
3002	Cyl. head gasket	1909-24	2 70	25 00		30	MH	402B	1
3003	Cyl. head cap screw	1909-17	35	2 50		05		483B	15
3003B	Cyl. head cap screw	1918-24	35	2 00	16 00	05		483C	1
3004	Cyl. head outlet con.	1909-16				35	MH	446C	1
3004B	Cyl. head outlet con.	1917-24				30	MH	8719	1
3005	Cyl. head out. con gasket	1909-24	25	1 50		05	MH	445B	1
3006	Cyl. head outlet hose	1909-24		12 50		15		448B	1
3007	Cyl. head outlet hose clip	1909-24	40	3 00		05		607B	2
3008	Cyl. head out. con. screw	1909-24	25	2 00		05		550C	2
3009B	Cyl. front cover	1909-19				1 00	MH	690B	1
3009C	Cyl. front cover	1919-24				1 00	MH	690C	1
3010	Cyl. cover bolt and nut	1909-24				0 20		432	3
3011	Cyl. cover cap screw	1909-24	40	2 50		05		504	1
3012	Cyl. cover felt	1909-24							
Order 4808 and 2515									

*Not subject to regular discount.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
3013	Cyl. cover liner	1909-19	\$ 0 15	\$ 1 00		\$0 02	505B	1
3013B	Cyl. cover liner	1919-24	15	75		02	505C	1
3014	Cyl. cover and crank case bolt and nut	1909-24	Order 3362 and 2515					
3015	Cyl. water inlet con.	1909-24				30	MH 442B	1
3016	Cyl. inlet con. screw	1909-24	25	2 00		03	597	2
3017	Time gear cover	1919-24				90	MH 1754B	1
3017B	Time gear cover	1919-21				90	MH 1754AR	1
3017C	Time gear cover gasket	1919-24		60		01	1775	1
3017D	Time gear cover plate	1919-24				05	MH 1773	1
3018	Cyl. water inlet gasket	1909-24	20	1 50		03	MH 596	1
3019B	Cyl. water jacket plug	1914-24	10	50		02	5619	3
3021	Piston only	1909-24	9 50			1 00	MH 418CR	4
3021B	Piston only—.0025" O. S.	1909-24	9 50			1 00	MH 418DR	4
3021C	Piston only—.03125" O. S.	1909-24	9 50			1 00	MH 418ER	4
3021D	Piston only—.033" O. S.	1909-24	9 50			1 00	MH 418FR	4
3021E	Piston only—.005" O. S.	1909-24	9 50			1 00	MH 418GR	4
3021F	Piston and pin	1909-24	12 50			1 30	MH 4473C	4
3021G	Piston and pin	1909-24	12 50			1 30	MH 4473DR	4
3021H	Piston and pin	1909-24	12 50			1 30	MH 4473ER	4
3021J	Piston and pin	1909-24	12 50			1 30	MH 4473FR	4
3021K	Piston and pin	1909-24	12 50			1 30	MH 4473GR	4
3021L	Piston only	1909-24	9 50			1 00	MH 418H	4
3021M	Piston only—.0025" O. S.	1909-24	9 50			1 00	MH 418IR	4
3021N	Piston only—.005" O. S.	1909-24	9 50			1 00	MH 418JR	4
3021P	Piston only—.03125" O. S.	1909-24	9 50			1 00	MH 418KR	4
3021Q	Piston only—.033" O. S.	1909-24	9 50			1 00	MH 418LR	4
3021R	Piston and pin	1909-24	12 50			1 30	MH 4473H	4
3021S	Piston and pin—.0025" O. S.	1909-24	12 50			1 30	MH 4473IR	4
3021T	Piston and pin—.005" O. S.	1909-24	12 50			1 30	MH 4473JR	4
3021U	Piston and pin—.03125" O. S.	1909-24	12 50			1 30	MH 4473KR	4
3021V	Piston and pin—.033" O. S.	1909-24	12 50			1 30	MH 4473LR	4
3022	Piston pin	1909-24				30	419B	4
*3022½	Piston pin bushing (pair)	1909-23		16 00		20	668AR	4
†3022C	Piston pin bushing (pair)	1909-24		16 00		20	668B	4
3023	Piston ring	1909-24	1 35	12 00		15	422C	12
3023B	Piston ring	1909-24	1 35	12 00		15	422ER	12
3023C	Piston ring	1909-24	1 35	12 00		15	MH 422DR	12
3023D	Piston ring	1909-24	1 35	12 00		15	422FR	12
†3024	CONNECTING ROD	1909-24				1 20	MH 641B	4
**3024B	Connecting rod	1909-24				1 20	MH 641AR	4
3025	Con. rod cap bolt	1909-24	40	3 00	\$20 00	05	489B	8
3026	Con. rod cap bolt nut	1909-24	30	1 50	12 00	05	490	8
3029	Con. rod clamp screw	1909-24	25	2 00		03	578	4
3030	CRANK SHAFT	1909-24				8 00	MH 498B	1
3031	C. S. rear bearing cap	1909-24				50	405AR	1
3031B	C. S. rear bearing cap	1909-24				50	405AR	1
3032	C. S. front bearing cap	1909-24				40	406B	1
3032B	C. S. front bearing cap	1909-24				40	406B	1
3033	C. S. center bearing cap	1909-24				40	407B	1
3033B	C. S. center bearing cap	1909-24				40	407B	1
3034	C. S. bearing bolt—center and front	1909-24				10	408	4
3035	C. S. bearing bolt nut	1909-24						
3036	C. S. rear bearing bolt	1909-24				10	478	2
3038	C. S. bearing liner—center and front	1909-24		40	2 00	01	502B	8
3039	C. S. rear bearing liner	1909-24		40	2 00	01	503B	1
3040	C. S. starting pin	1909-20	30	2 00		05	529B	1
3040B	C. S. starting pin	1920-24	30	2 00		05	529C	1
3041	CAM SHAFT	1909-24				2 50	MH 410	1
3042	Cam shaft front bearing	1909-24				35	411AR	1

†Used with 3000C cylinder on cars not equipped with starter.
 ††Connecting rods requiring new bearings will be exchanged by dealers at 60c each.
 **Special rod for crankshafts worn .025" undersize.
 *O. D. .934"
 ††O. D. .872"
 †Light type piston.
 †Rough habbitted.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
3042B	Cam shaft front bearing	1924				\$0 35	411B	1
3043	Cam shaft center bearing	1909-24				35	412B	1
3044	Cam shaft rear bearing	1909-24				15	413	1
3045	Cam shaft bearing ring	1909-24	\$0 15	\$1 00		03	534	2
3046	Camshaft bear'g set screw	1909-24	35	3 00		05	414	2
3047B	Time gear—large	1909-24	7 50			90	MH 415B	1
3048B	Time gear—small	1909-24	4 50			60	MH 416B	1
3049	Cam shaft gear dowel pin	1909-24	15	1 25		02	417	2
3050B	Cam shaft gear lock nut	1909-24				10	4453	1
3051	Small time gear key	1909-24	25	1 75		03	477	1
3052	Valve	1909-24		12 00		15	MH 424B	8
3052B	Valve—½" O. S. stem	1909-24		12 00		15	MH 424AR	8
3053½	Valve bushing	1909-24				25	428	8
3054	Valve spring	1909-24		3 50		05	431	8
3056	Valve spring seat	1909-24		40	3 00	05	425	8
3057	Valve spring seat pin	1909-24		25	2 00	05	429	8
3058	Push rod	1909-24	90	7 00		10	MH 426B	8
3058B	Push rod—½" O. S. stem	1909-24	90			10	MH 426AR	8
3059½	Push rod bushing	1909-24				25	427	8
3060B	Exhaust manifold	1913-24				1 25	MH 4483	1
3061	Exhaust pipe pack out	1909-24				20	518	1
3062	Inlet pipe	1909-24				1 00	MH 512B	1
3063	Inlet and exh. pipe gasket	1909-24	15	1 20	8 00	02	MH 513	6
3064	Inlet and exh. pipe gland	1909-24		75	6 00	01	514	6
3065	Inlet and exh. pipe clamp	1909-24				10	MH 515	4
3066	Inlet and exh. clamp stud	1909-24	30	2 50		05	516	4
3066B	Inlet and exh. clamp stud nut	1909-24	20	1 25	7 50	03	517	4
3068	Breather pipe	1909-24	80	6 00		10	MH 4468	1
3069B	C. C. front end support	1911-17				1 00	801C	1
3069C	C. C. front end support	1917-24				75	801D	1
3070B	C. C. & cyl. gasket—L	1909-24	30	2 50		05	886	1
3071B	C. C. & cyl. gasket—R	1909-24	30	2 50		05	887	1
3072	C. C. & cyl. cover cap screw	1909-24	25	1 50		03	1388	2
3073	C. C. arm bolt—side	1909-24	30	2 25		05	479	2
3074	C. C. arm bolt—top	1909-24	20	1 75		05	940	2
3074B	C. C. arm bolt nut	1909-24						
3075B	C. C. frt. bearing & spring clip assy	1921-24				80	2921B	1
3076B	C. C. front bearing and spring clip	1921-24				60	320C	1
3076C	C. C. front bearing and spring clip nut	1921-24						
3077	C. C. front bearing cap	1909-24				10	321	1
3078	C. C. front bearing screw	1909-21	35	3 00		05	322	2
3078B	C. C. front bearing screw	1921-24						
3078C	C. C. front bearing lock washer	1921-24		50		01	5636	2
3079	C. C. oil cock	1909-24		12 00		15	1515	2
3080	C. C. drain cup plug	1909-24						
3080B	C. C. drain cup plug gasket	1909-24		1 50		02	MH 4339	1
3081	C. C. oil tube	1909-24				20	543B	1
3083	C. C. arm block	1909-24				05	890	2
3084	Engine pan—right	1909-24	2 50			30	MH 1330	1
3085	Engine pan—left	1909-24	2 50			30	MH 1331B	1
3088B	Engine pan and hood board bolt	1909-24		20	1 50	03	4074	2
3088C	Engine pan and hood board bolt	1909-24	20	1 50		03	4073	2
3088D	Engine pan and hood board bolt—Truck	1918-24	20	1 50		03	TT4073	2
3088E	Engine pan and hood board bolt nut	1909-24		75	5 00	01	1309	1
3100	CRANK CASE	1912-24				11 00	MH 1526E	1
3101	Crank case lower cover	1912-24				35	MH 1582	1
3101B	Crank case lower cover reinforcement	1912-24				25	4378-4379	1
3102B	C. C. lower cover gasket	1912-24	70	6 00		10	1586	1
3103	C. C. lower cover screw	1912-24	15	1 00	8 00	02	4328	14
3110	Cylinder valve cover	1912-21				15	MH 656A	2

†When ordered to replace old style C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664 1-3810 and 2-753 cotter.
 Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
MOTOR—Continued									
3110B.	Cylinder valve cover	1921-24				\$0 20	MH	656B.	2
3111B.	Cyl. valve cover gasket	1912-21	\$0 30	\$ 2 50	\$21 00	05		660A.	1
3111C.	Cyl. valve cover gasket	1921-24	60	4 50	40 00	10		660B.	2
3112.	Cyl. valve cover screw	1912-24		2 00		03		654	1
3114.	C. C. arm with rivets	1909-24				30		815B.	2
3115.	C. C. arm rivet	1909-24				doz. 05		312	
COMMUTATOR									
3162.	Com. case support bolt	1912-19				05		4441	1
3162B.	Com. case support bolt	1919-24				05		1756	1
3163.	Com. case spring	1912-24				05		689	1
3165.	Com. brush only	1912-24	1 75	15 00		20		4481	1
3176C.	Com. oiler	1919-24	40	2 50		05		480C.	1
3177.	Com. felt ring	1912-24	15	75		02		5930	1
3206.	Com. brush cap	1909-24	15	1 00		02		468B.	1
3207.	Com. brush cap pin	1909-24		50		01		466	1
3210.	Com. contact point nut	1910-24		50		01		472B.	8
3220.	Com. lock nut	1909-24	25	2 00		03		471	1
3221.	Com. case with fibre	1912-24		55 00		60		5908	1
3222.	Com. shield	1912-24		1 25		02		5923	1
MAGNETO									
3250D.	Magneto coil assembly	1915-24				6 00		5941B.	1
3252.	Magneto spool support screw	1909-24							
3254.	Magnet bolt	1909-24	25	2 00		03		537B.	16
3255.	Magnet bolt washer	1911-24		50		01		624	16
3257.	Magnet support	1909-24	30	2 00		05		535C.	16
3260.	Magneto contact assy.	1909-24	1 50	13 50		20	MH	1545	1
3261B.	Magneto contact nut	1909-24		50		01		1508	2
3261C.	Magneto contact screw washer	1909-24		50		01		1565	
3262.	Magneto contact spring	1909-24	30	2 00		05		1509	1
3262B.	Magneto contact screw and spring assembly	1919-24		7 50		10		4350	
3266.	Magneto contact fibre screw	1909-24		50		01		1505	3
3267.	Magneto primary insulating block	1915-24				03		4382	
3267B.	Magneto contact insulator	1919-24		3 00		05		1503B.	
3267C.	Magneto contact insulator shell	1919-24				03		8611	
3268.	Fly wheel ring gear	1919-24				90	MH	1885	1
3269C.	Fly wheel	1911-19				6 00	MH	701B.	1
3269G.	Fly wheel	1919-24				5 00	MH	701C.	1
3269H.	Fly wheel with ring gear and magnets assembled	1919-24				15 00	MH	5946B.	1
3270.	Fly wheel cap screw	1909-24	80	7 00		10		721	4
3271.	Fly wheel dowel pin	1909-24	40	3 00		05		722	2
3272.	Magneto coil support shim	1909-24	40	3 00		05		584AR.	1
3272B.	Magneto coil support washer	1909-24				05 doz.		584B.	4
3276B.	Magnet (16)	1915-24				4 00		5933	16
3277.	Magnet clamp	1911-24	25	1 60		03		623	16
3278.	Magnet clamp screw	1911-24		1 50	14 00	02		625	16
3279.	Magneto contact washer	1909-24		75		01		560	1
TRANSMISSION									
3300B.	Transmission assy.	1919-24				30 00	MH	744C.	
3301.	Trans. reverse plate assy.	1909-24				2 40	MH	747	1
3304.	Trans. reverse gear bushing	1909-24				40		705	1
3305.	Trans. rev. and S. S. rivet	1909-24				doz. 05		708	8
3306.	Trans. slow speed plate assy.	1909-24				2 30	MH	748	1
3309.	Trans. slow speed gear bushing	1909-24				30		745	1
3310.	Trans. brake drum rivet	1909-24				doz. 05		711	8
3311.	Trans. brake drum assy.	1909-24				2 40	MH	750	1
3313.	Trans. triple gear assy.	1909-24				1 40	MH	751B.	3
3314 1/2.	Trans. triple gear flanged bushing	1911-24				20		716B.	3
3315.	Trans. triple gear shaft	1909-24				15	MH	715	3

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
TRANSMISSION—Continued									
3316.	Trans. triple gear rivet-ing pin	1909-24				doz. \$05		720	24
3317.	Trans. driven gear	1909-24				70	MH	713	1
3318.	Trans. driven gear key	1909-24				03		714	2
3320C.	Trans. driven gear sleeve bushing	1909-24				20		712	2
3320D.	Driven gear sleeve washer	1909-24	\$40	\$3 00		05		776	3
3321.	Trans. driving plate assy.	1909-24				3 00	MH	749	1
3323.	Trans. driving plate screw	1909-24							
3325.	Trans. driving plate rivet	1909-24				doz. 05		736	8
3327B.	Trans. driving plate bush	1909-24				15		772	1
3328.	Trans. clutch disc—small	1909-24	90	8 00		10	MH	727	12
3329.	Trans. clutch disc—large	1909-24	90	8 00		10	MH	728	13
3331.	Trans. gear shaft	1909-24				1 25	MH	723B.	1
3332.	Trans. clutch disc drum	1909-24				1 25	MH	725B.	1
3333.	Trans. clutch disc drum key	1909-24		3 50		05		726B.	1
3334.	Trans. clutch disc drum set screw	1909-24		4 00		05		752	1
3336.	Trans. clutch push ring	1909-24				35	MH	770	1
3337.	Trans. clutch finger	1909-24				15	MH	732B.	3
3337 1/2.	Trans. clutch finger screw	1909-24		3 00		05		756	
3337B.	Trans. clutch finger and screw	1909-24				20	MH	765	3
3338.	Trans. clutch finger pin	1909-24				01		735	3
3340.	Trans. clutch spring	1909-24				25		737	1
3341.	Trans. clutch spring support	1909-24				10	MH	738	1
3342.	Trans. clutch spring thrust ring pin	1909-24	25	1 50		03		739	1
3344.	Trans. clutch shift	1909-24				45	MH	733	1
TRANSMISSION COVER									
3362.	Trans. cover bolt	1909-24		2 00	\$16 00	03		79	
3362B.	Trans. cover bolt nut	1909-24							
3363.	Trans. cover gasket (front)	1909-24	30	2 50		05		872B.	
3367.	Trans. cover door screw	1909-24	15	1 00		02		430	6
3368.	Universal ball cap (rear)	1909-24				30	MH	818	1
3369.	Universal ball cap (front)	1909-24	7 50			80	MH	819D.	1
3371.	Universal ball cap screw	1909-24	25	1 75	13 00	03		731	2
3372.	Universal ball cap bolt and nut	1909-24							
3375.	Trans. cover screw	1909-24							
3376B.	TRANS. COVER	1919-24				7 00	MH	826E.	1
3377B.	Trans. cover gasket	1909-24	80	7 00		pr 10		885B.	1
3378.	Trans. cover door	1911-24				15	MH	1546D.	1
3379B.	Trans. cover door gasket	1911-24	40	3 50		05		1547C.	1
3380.	Bendix cover	1919-24				15	MH	1763	1
3381.	Bendix cover gasket	1919-24	20	1 50		03		1764	1
3382.	Trans. cover rear plate	1919-24				05	MH	1761	1
3383.	Trans. cover front plate	1919-24				05	MH	1758	1
TRANSMISSION CONTROL									
3400.	Trans. clutch release ring	1909-24				20	MH	741	1
3402D.	Clutch lever and shaft	1913-24				30	MH	1548	
3403.	Clutch lever screw	1909-24							
3403B.	Clutch lever screw nut	1909-24							
3405.	Clutch lever pin	1909-24		60		01		1553	1
3406B.	Clutch release fork—Rorl	1913-24				15	MH	4345	2
3406C.	Clutch release fork pin	1913-24							
3411.	Clutch lever clevis pin	1909-24							
3413.	TRANSMISSION BAND ASSEMBLY	1909-24				60	MH	838B.	2
(Bands will be exchanged by dealers at 45 cents each)									
3415.	Trans. band washer	1909-24	15	1 25		03		840	2
3416.	Trans. band lining	1909-24		20 00		25	MH	1562	3

†When using short bushing in making repairs remove driving plate key
 †When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
TRANSMISSION CONTROL—Continued								
3416B	Trans. band lining—set of 3 inc. rivets—in carton	1909-24	\$ 8 00	\$70 00		\$1 00	264	1
3419	Trans. band adj. screw	1909-24		7 50		10	1533	1
3420	Trans. band adj. screw nut	1909-24	0 30	2 50		05	1532	1
3421B	Trans. band ear iron rivet	1909-24						\$2 00
3422B	Trans. band brass rivet	1909-17				05 doz.	843	12
3423B	Trans. band brass rivet	1909-24				05 doz.	844B	6
3425	Trans. band spring	1909-24	15	1 25		03	845B	24
3426	Trans. band adj. nut	1909-24	25	2 00		05	841B	3
3427	Slow speed shaft	1909-24				15	851	2
3428	Slow speed notch	1909-24				15	MII 848B	1
3429	Slow speed notch pin	1909-24		60		25	MH 4327	1
3432	Speed lever	1909-24				01	1560	1
3434	Reverse pedal	1909-24				10	MH 862B	1
3435	Brake and rev. pedal shaft	1909-24				50	MH 4324	1
3436	Brake and rev. pedal support	1909-24				15	MH 849B	2
3437	Brake and rev. support bolt	1909-24	25	2 00		05	4325	2
3437B	Brake and rev. support bolt nut	1909-24					1534	2
3439	Brake pedal	1909-24				50	MH 4323	1
3440	Clutch pedal	1909-24				50	MII 854B	1
3441	Pedal pin	1909-24						
3442	Clutch pedal support	1909-24				15	4326	1
3443	Clutch pedal support bolt	1909-24	25	2 00		05	1536	1
3443B	Clutch pedal support bolt nut	1909-24						
3445	Slow speed connection	1909-24	40	3 50		05	1540	1
3446	Slow speed con. lock nut	1909-24						
3447	Slow speed con. clevis	1909-24	60	5 00		10	802	1
3448	Controller quadrant	1909-24				20	309B	1
3449	Con. shaft w/hspeed lever	1909-24				60	MH 1557	1
3450	Controller shaft bracket	1909-24				15	MH 311	2
3452	Controller shaft bracket bolt	1909-24	25	2 00	15 00	03	315	4
3452B	Controller shaft bracket bolt nut	1909-24	15	1 25	9 00	02	316	4
3455	Hand brake lever	1909-24				1 00	MH 1550	1
3456B	Hand brake lever pin	1909-24						
3457	Hand brake lever key	1909-17				05	874	1
3458	Hand brake lever pawl	1909-24				05	875	1
3459	Hand brake lever pawl pin	1909-24		50		01	876	1
3460	Hand brake lever pawl rod	1909-24				10	MH 877	1
3462	Hand brake lever pawl lift assembly	1909-24						
3463	Hand brake lever pawl lift spring	1909-24				10	4363	1
3465	Hub brake lever	1909-24				02	888	1
3466	Hub brake lever pin	1909-24				15	MH 864	1
3467	Hub brake lever clevis	1909-24						
3468	Hub brake pull rod—R	1909-24	2 50			30	MH 891B	1
3469	Hub brake pull rod—L	1909-24	2 50			30	MH 1513B	1
3470	Brake rod support—R	1909-24	60	5 00		10	1367C	1
3471	Brake rod support—L	1909-24	60	5 00		10	1398C	1
3472	Brake rod support bolt	1909-24		75	5 00	01	1308	2
3472B	Brake rod sup. bolt nut	1909-24						
STEERING GEAR								
3500C	Steering gear Assy	1911-24				10 00	MH 5044	1
3501C	St. gear rim	1920-24				70	901C	1
3502	St. gear rim screw	1909-24				01	6849	4
3503D	St. gear spider	1920-24				50	MH 902C	1
3503E	St. gear spider and rim	1909-24				1 25	MH 995A2	1
3504	St. gear cover	1909-24				30	MH 5039	1
3505	St. gear cover screw	1909-24		50		01	910	1
3506	St. gear cover bushing	1909-24				15	914	1
3506B	St. gr. driv. pinion washer	1909-24				03	5026	1
3507	St. gr. int. gear case and bushing	1909-24				1 25	MH 5036	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
STEERING GEAR—Continued								
3509	St. gear quadrant	1909-24				\$0 10	MH 906B	1
3510	St. gear quadrant rivet	1909-24		\$ 0 50			5041	2
3511	St. gear wheel nut	1909-24	\$0 80	7 00			913	1
3512C	St. gear tubing Assy	1912-24				4 00	MH 5016	1
3513C	St. tubing flange screw	1913-24	15	1 00			5018	3
3514	St. tub. flange screw nut	1913-24	10	65	\$ 4 00		926	1
3516C	St. gear post	1912-21				1 75	MH 5043	1
3516D	St. gear post	1921-24				1 75	MH 5043B	1
3517	St. gear pinion	1909-24				15	MH 916	3
3518	St. gear pinion pin—short	1909-24				02	917	2
3518B	St. gear pinion pin—long	1921-24				02	918	1
3519	St. gear drive pinion	1909-24				30	MH 911	1
3520	St. gear drive pinion key	1909-24		20	1 00		909	1
3523	St. gear post castle nut	1909-24						
3524E	Throttle rod	1912-24						
3525E	Lead rod	1912-24						
3527	Lead & throttle rod spring	1909-24						
3528	Lead & throttle rod collar	1909-24	15	1 00				
3529	Lead & throttle rod pin	1909-24		50				
3530	Lead rod lever	1909-24	50	6 00			MH 946	1
3531	Throttle rod lever	1909-24	80	6 00			MH 947	1
3532	Lead & throttle rod guide	1909-24				05	938	1
3534B	Commutator pull rod	1912-24		75			MH 2082	1
3535	Carburetor pull rod	1909-24		75	6 00		MH 1329	1
3536	Ball and socket joint	1909-21		85	7 50		1326	1
3537	Ball and socket joint nut	1909-21		15	1 00		1327	1
3539B	St. brkt. with bushing	1911-24		6 00			MH 996	1
3539C	St. brkt. with bushing—truck	1918-24		6 00			MH TT996	1
3540	Brkt. bolt and nut—long	1909-24						
3541	Brkt. bolt and nut—short	1911-24						
3544	St. brkt. felt washer	1909-24		80				
3545	St. brkt. bushing	1909-21				02	943	1
3545B	St. brkt. bushing	1921-24				20	944-5027	1
3546	St. brkt. block	1909-24				10	944	1
3546B	St. brkt. block—Truck	1918-24				10	945	1
3547	St. gear ball arm	1909-24				10	TT945	1
3548	St. gear ball arm key	1909-24		25	1 50		MH 929B	1
3549	St. brkt. dust cap—Truck	1918-24				03	930	1
						05	TT5044	1
BODY PARTS								
3601B	Body brkt. on body	1910-24					1624	6
3601C	Body brkt.—front—R	1921-24				20	7267B	1
3601D	Body brkt.—front—L	1921-24				20	7268B	1
3601E	Body bracket—rear	1913-24				05	5650	2
3601F	Body bracket—rear—R	1921-24				20	7137C	1
3601G	Body bracket—rear—L	1921-24				20	8001B	1
3602E	Body brkt. con. bolt	1916-24		2 00		03	2431	6
3602F	Body brkt. con. bolt nut	1916-24						
3624E	Front floor rubber mat	1915-24						
3626C	Floor board with plate (first)	1915-24						
3627C	Floor board with plate (second)	1915-24						
3628B	Floor board with plate (third)	1915-24						
3630	Floor board forward plate for pedals	1909-24						
3632	Floor board rear plate for pedals	1909-24						
3633	Floor board plate for side lever	1909-24						
3634D	Dash	1913-14						
3634E	Dash	1915-16				7 00	5336	1
3634H	Dash—(steel)	1917-24				5 00	7462	1
3634J	Dash—steel	1923-24				2 50	MH 8754B	1
3638B	Dash shield	1919-22				2 50	MH 8751C	1
3639	Dash weatherstrip—side	1917-22				10	5432B	1
3639B	Dash weatherstrip—top	1917-22				05	8747	2
3640C	Dash brkt.—left	1917-22				15	8752R	1
*3640D	Dash brkt.—left	1923-24				20	8722	1
3641C	Dash brkt.—right	1917-22		1 25		15	8722B	1
						20	8721	1
††When used on 1911-16 cars redrill frame.								
*Used with steel dash.								
Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.								

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
†3641D	Dash brkt.—right	1923-24	\$1 25			\$0 15	8721B	1
3642B	Dash brkt. to dash bolt	1917-22	25	\$2 00		03	8740	4
3642C	Dash brkt. to dash nut	1917-22						
3653B	Dash to body brkt. bolt	1915-24	15	1 00		03	4248	2
3653C	Dash to body brkt. nut	1915-24						
3654	Dash to body gasket	1918-24	35	2 50		05	8769	
3660C	Lamp & license brkt. assy	1915-21	2 00			25	MH 7506AR	1
3660D	Lamp & license brkt. assy	1915-21	2 00			25	MH 7505	1
†3660E	Lamp & license brkt. support assy	1923-24				75	MH 7506B	1
†3661	Lamp & license brkt. sup.	1923-24				25	MH 8767B	1
3664	Front license bracket	1921-24				10	MH 493	1
3667E	Front seat cushion	1909-21				6 00	MH 8076A	1
3667F	Front seat cushion	1921-24				6 00	MH 8076B	1
3670D	Rear seat cushion	1909-21				6 50	MH 7032A	1
3670E	Rear seat cushion	1921-24				6 50	MH 7032B	1
3676B	Rear floor mat	1911-21				1 00	1606B	1
3676C	Rear floor mat	1921-24				70	1606C	1
3680	Pedal shield	1924				15	1096	1
**3681	Deck lock key	1916-24		7 00		10	9484	1

SPRINGS

3800	Front spring	1909-24	22 50			2 50	MH 332	1
3801	First leaf (main leaf)	1909-24	6 00			80	MH 2943	1
3802B	Second leaf	1909-24	4 00			45	2935	1
3803B	Third leaf	1916-24	3 00			40	2936	1
3804B	Fourth leaf	1916-24	2 50			30	2937	1
3805B	Fifth leaf	1916-24	2 00			25	2938	1
3806B	Sixth leaf	1916-24	1 50			20	2939	1
3807B	Seventh leaf	1916-24	1 25			15	2947	1
3808	Front spring clip	1909-20				20	325C	2
3809	Front spring clip nut	1909-24						
3810	Front spring clip bar	1921-24	2 00			25	342	1
3811	Front spring tie bolt	1909-24	20	1 50		04	1362	1
3811B	Front spring tie bolt nut	1909-24	15	1 00		02	1363	1
3813B	Front spring hanger	1909-24	1 75	15 00		20	246C	2
3814	Front spring hanger bar	1909-24				05	7648	2
3815	Spring hanger nut	1909-24						
3818	Front spring perch—right	1909-19				80	MH 274A	1
3818B	Front spring perch—right	1909-24	4 00			50	MH 274B	1
3819	Front spring perch—left	1909-19				80	MH 275A	1
3819B	Front spring perch—left	1919-24	4 00			50	MH 275B	1
3820	Front spring perch bush	1909-24	25	2 00		05	230	4
3821	Front spring perch nut	1909-21				05	240	1
3821B	Front spring perch nut	1921-24				05	262	1
3823	Front spring pad	1909-24	\$0 45	\$4 00				
3824	REAR SPRING	1909-24				6 50	MH 333	1
*3824B	REAR SPRING	1922-24				6 75	MH 388	1
†3824C	Rear spring	1923-24				5 00	MH 384	1
3825	First leaf (main leaf)	1909-17	1 50			1 50	361A	1
3825B	First leaf (main leaf)	1918-24	1 35			1 35	355	1
*3825C	First leaf (main leaf)	1922-24	1 35			1 35	389	1
3826	Second leaf	1909-17	1 25			1 25	362A	1
3826B	Second leaf	1918-24	1 10			1 10	362B	1
*3826C	Second leaf	1922-24	1 10			1 10	391	1
3827	Third leaf	1909-17	1 10			1 10	363A	1
3827B	Third leaf	1918-24	8 50			95	363B	1
*3827C	Third leaf	1922-24				95	392	1
†3827D	Third leaf	1923-24				75	379	1
3828	Fourth leaf	1909-17				95	364A	1
3828B	Fourth leaf	1918-24	7 50			85	364B	1
*3828C	Fourth leaf	1922-24				85	393	1

†Used on Touring Cars and Roadster without starter and demountable rims.

‡Used on Touring Car and Roadster with starter without demountable rims.

§Used with steel dash.

**Used on Coupe 1916-24, Roadster 1923-24.

*Nine-leaf spring for Sedan.

††Six-leaf spring for Roadster.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
3828D	Fourth leaf	1923-24				\$0 60	380	1
3829	Fifth leaf	1909-17				80	365A	1
3829B	Fifth leaf	1918-24	\$6 50			75	365B	1
*3829C	Fifth leaf	1922-24				75	394	1
3829D	Fifth leaf	1923-24				45	381	1
3830	Sixth leaf	1909-17				75	366A	1
3830B	Sixth leaf	1918-24	5 00			60	366B	1
*3830C	Sixth leaf	1922-24				60	395	1
3830D	Sixth leaf	1923-24				35	382	1
3831	Seventh leaf	1909-17				70	367A	1
3831B	Seventh leaf	1918-24	3 50			45	367B	1
*3831C	Seventh leaf	1922-24				45	396	1
3832B	Eighth leaf	1909-24	3 00			35	368B	1
*3832C	Eighth leaf	1922-24				35	397	1
*3832D	Ninth leaf	1922-24				30	398	1
3833	Rear spring clip	1909-24				20	326	2
*3833B	Rear spring clip	1922-24				20	1737	2
3834	Rear spring clip nut	1909-24						
3835	Rear spring clip bar	1909-24						
3837	Rear spring tie bolt	1909-24	20	\$1 50		05	329	2
3837B	Rear spring tie bolt nut	1909-24	15	1 00		02	1352	1
*3838	Rear spring tie bolt	1922-24				02	1353	1
3838B	Rear spring tie bolt	1923-24	2 00			05	1355	1
3840B	Rear spring hanger	1909-24	1 50			03	383	1
3841	Rear spring hanger bar	1909-24	2 25	20 00		25	91 1/2C	2
3842	Rear spring pad	1909-24				05	7649	2
3843	Rear spring perch	1909-24	3 50			05	94	1
3844	Rear spring perch bush	1909-24	35	3 00		40	MH 2804	2
3845	Rear spring perch nut	1909-24				05	172	4
3846	Spring perch oiler	1917-24				05	174	2
3847B	Front spr'g clamp assembly with bolt and nut	1916-24	35	3 00		05	2944	4
3848	Rear spr'g clamp assembly with bolt and nut	1909-17	75	6 00		10	2953	2
3848B	Rear spr'g clamp assembly with bolt and nut	1918-24	75	6 00		10	376	2
3850	REAR SPRING	1909-16				75	6 00	10
						10		378
						9 00	MH 1704	1

STARTING CRANK

3901	Starting crank handle	1909-22				15	520	1
3902	Starting crk. handle bolt	1909-22	60	5 00		10	521	1
3903	Starting crank sleeve	1909-22	60	4 00		10	523	1
3905	Starting crk. ratchet pin	1909-24	25	2 00		05	4491	1
3906	Starting crank ratchet	1909-24	1 50			20	MH 528B	1
3908	Starting crank spring	1909-24	20	1 00		03	626	1
3909	Starting crk handle spring	1915-22	15	1 00		02	5911	1
3910	Starting crank assy.	1909-24				40	MH 5931	1

RADIATOR—THERMO SYPHON

3925	Radiator	1909-16				20 00	MH 1100C	1
3925B	Radiator	1917-23				16 00	MH 8700B	1
3925C	Radiator less shell	1917-23				15 00	MH 8736B	1
3925D	Radiator	1923-24				16 00	MH 8700D	1
3925E	Radiator—less shell	1923-24				15 00	MH 8736A	1
3926	Radiator cap	1909-24	1 25	11 50		15	MH 8714	1
3928	Radiator pad	1909-19				05	1105	2
3929	Radiator stud	1909-19				05	1162A	2
3929B	Radiator stud	1919-24	45	4 00		05	1162B	2
3929C	Radiator stud nut	1909-24	20	1 50		03	1154	2
3930	Radiator stud spring	1909-24						
3931 1/2	Radiator stud washer nut	1909-24	20	1 50		03	1161	2
3932	Radiator rod	1909-23	1 00			15	MH 1111B	1
3932B	Radiator rod	1923	1 00			15	MH 1111C	1
3932C	Radiator rod	1923-24	1 00			15	MH 1111D	1
3934	Radiator rod nut	1909-24						
3939	Outlet connection pipe	1909-24	2 00			25	1121	1
3940	Outlet connection cock	1909-24						
3944	Outlet connection hose	1909-24	8 00			10	507B	2

*Nine-leaf spring for Sedan.

†Six-leaf spring for Roadster.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
RADIATOR—THERMO SYPHON—Continued								
3945	Outlet con. hose clip	1909-24	\$0 30	\$2 50		\$0 05	554B.....4	
3947B	Radiator shell	1917-24				1 00	MH 8737B.....1	
3947C	Radiator shell	1923-24				1 00	MH 8737C.....1	
3975	Rad. stud spring upper thimble	1919-24		1 50		02	1115.....1	
3976	Rad. stud spring lower thimble	1919-24		2 00		03	1114.....1	
3977	Radiator apron	1924-24				50	MH 8016.....1	

RADIATOR FAN

3960	Fan and pulley assembly	1909-20				1 25	MH 619.....1
3961	Fan blade	1909-20				10	611.....4
3961B	Fan blade rivets	1909-20			\$1 50 doz.	05	1566.....16
3961C	Fan blade assembly	1929-24	2 00			25	MH 620.....1
3962B	Dr. fan pulley with bush	1920-24	6 00			70	MH 618B.....1
3963	Fan drive pulley	1909-20				25	MH 602A.....1
3963B	Fan drive pulley	1920-24				30	MH 602B.....1
3964	Fan belt—23" fabric	1909-16				35	609A.....1
3964C	Fan belt—26" fabric	1917-20				35	609B.....1
3964E	Fan belt—rubber	1920-24	3 00	26 00	220 00	35	609C.....1
3966	Fan shaft	1909-20				25	MH 606A.....1
3966B	Fan shaft	1920-24	1 75	12 50		20	MH 606B.....1
3967	Fan bracket	1909-16	3 00			40	MH 604A.....1
3967B	Fan bracket	1917-24	2 50			30	MH 604B.....1
3968	Fan bracket bolt	1909-24	85	7 50		10	605.....1
3970	Fan grease cup	1909-24	85	7 00		10	601.....1
3973	Fan adjusting screw	1909-24	15	1 00		02	645.....1
3973B	Fan adjusting screw nut	1909-24					
3974	Fan driven pulley bush	1917-20				15	8757A.....1
3974B	Fan driven pulley bush	1920-24	1 00			15	8757B.....2
3980	Fan pulley plug	1920-24	25	2 00		03	633.....1
3981	Fan pulley gasket	1920-24	15	90		02	634.....1
3982	Fan shaft cap	1920-24	10	90		02	635.....1
3983	Fan shaft felt washer	1920-24	15	1 00		02	637.....1
3984	Fan blade screw	1920-24		60		01	652.....4
3985	Fan blade screw washer	1920-24					
3986	Fan shaft nut	1920-24					
							Order 3066B
							Order 3261C
							Order 2719

MUFFLER

4025B	Muffler assembly	1909-24		(Replaces old design)		2 25	MH 1200C.....1
4026B	Muffler head—front	1917-20				35	1202C.....1
4026C	Muffler head—front	1921-24				10	1202D.....1
4027	Muffler shell—outer	1909-24				25	1203.....1
4028	Muffler shell—middle	1909-24				20	1204.....1
4029	Muffler shell—inner	1909-20				15	1205.....1
4030	Muffler rod	1909-17				10	1206A.....3
4030B	Muffler rod	1917-20				10	1206B.....1
4031	Muffler rod nut	1909-20					
4032	Muffler head retainer	1921-24				02	1210.....1
4033	Muffler head retainer bolt and nut	1921-24					
4035	Muffler head bolt washer	1921-24				doz. 05	925.....1
4037B	Long exhaust pipe	1909-20				1 25	1214A.....1
4037C	Long exhaust pipe	1920-24				1 40	MH 1214B.....1
4040B	Muffler head—rear	1917-21				35	1201D.....1
4040C	Muffler head—rear	1921-24				20	1201E.....1
4041B	Muffler head to frame bolt and nut	1921-24					
							Order 2503F
							Order 4819B and 3514
							Order 3074 and 2515

HOOD

4050	Hood	1909-16				8 00	1300.....1
4050B	Hood	1917-23				6 00	MH 8726.....1
4050C	Hood	1923-24				6 00	MH 8726B.....1
4051	Hood handle	1909-24				05	1314.....2
4052	Hood clip	1909-16				10	1310.....4
4052B	Hood clip	1917-24		4 00		05	8731.....4
4053	Hood clip spring	1909-16				02	1311.....4
4053B	Hood clip spring	1917-24	15	1 00		02	8734.....4

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
HOOD—Continued								
4056B	Hood block—left	1917-23				\$0 20	8742.....1	
4056C	Hood block—left	1923-24	\$1 50			20	8742B.....1	
4057B	Hood block—right	1917-23				20	8741.....1	
4057C	Hood block—right	1923-24	1 50			20	8741B.....1	
4060C	Hood pad (on dash)	1917-24		70	\$6 00	08	MH 8711AR.....2	
4060D	Hood pad (on rad. shell)	1917-23	1 35	12 00		15	MH 8710.....1	
4060E	Hood pad (on dash)	1923-24		70	6 00	08	MH 8711B.....2	
4061B	Hood clasp (on dash)	1917-20		35	2 50	05	8720AR.....1	
4061C	Hood clasp (on dash) screw	1917-23				02	8763.....2	
4061D	Hood clasp (on dash)	1920-23		35	2 50	05	8720BR.....1	
4061E	Hood clasp (on dash)	1923		35	2 50	05	8720C.....1	
4061F	Hood clasp (on dash)	1923-24		35	2 50	05	8720D.....1	
4073	Hood bl support—front	R1917-23				05	8743.....1	
4073B	Hood bl support—frt.	R1923-24				05	8743B.....1	
4074	Hood bl support—front	L1917-23				05	8744.....1	
4074B	Hood bl support—frt.	L1923-24				05	8744B.....1	
4075	Hood bl support—rear	R1917-23				05	8745.....1	
4075B	Hood bl support—rear	R1923-24				05	8745B.....1	
4076	Hood bl support—rear	L1917-23				05	8746.....1	
4076B	Hood bl support—rear	L1923-24				05	8746B.....1	

FORD CARBURETOR (MODEL "NH")

6200B	Carburetor	1920-24	40 00			4 50	MH 553A4.....1
6201	Float with lever	1920-24	2 00			25	6333B.....1
6202B	Float chamber and bushing assy	1920-24				50	6318B.....1
6202C	Float chamber	1923-24				30	4802F.....1
6203	Float chamber gasket	1920-24				03	555B.....1
6204	Spray nozzle gasket	1920-24		50		01	4820B.....1
6205	Mixer chamber gasket	1920-24				02	6367B.....1
6206	Throttle lever	1920-24					
6206B	Aux. throttle lever	1920-24					
6207B	Mixer chamber	1920-24				2 50	6343R.....1
6208	Adj. needle clamp nut	1920-24				05	4812B.....1
6209	Throttle plate	1920-24				02	4517B.....1
6210	Float lever pin	1920-24				01	6320B.....1
6211	Float chamber screw	1920-24				05	6284.....1
6212	Float valve seat	1920-24				05	6321B.....1
6213	Spray needle assembly	1920-24	1 00			15	6335B.....1
6214B	Spray nozzle	1920-24	1 50			20	6341C.....1
6215	Air passage vent plug	1920-24				10	6273R.....1
6216	Drain valve plug assy	1916-24				10	6329.....1
6217	Throttle lever stop screw	1920-24					
6218	Aux. throttle lever spring	1920-24					
6219	Float valve seat gasket	1920-24				01	6322C.....1
6220	Gasoline inlet needle	1920-24					
6221	Drain valve body	1923-24				15	6328D.....1
							Order 6070
							Order 6077
							Order 6064
							Order 6076
							Order 4453A

KINGSTON CARBURETOR (MODEL "L-4")

6150	Carburetor	1921-24	40 00			4 50	553A1.....1
6151	Drain valve body	1921-24				15	6328C.....1
6152	Float chamber	1921-24				50	4802E.....1
6153	Mixing chamber	1921-24				2 50	6340G.....1
6154	Carb. inlet elbow	1921-24					
6155	Float with lever	1921-24				50	6333C.....1
6156	Float chamber gasket	1921-24				05	555D.....1
6157	Mix chamber gasket	1921-24				05	6367E.....1
6158	Float valve seat gasket	1921-24				03	6322F.....1
6159	Constant air supply lever assy	1921-24				30	6327D.....1
6160	Throttle lever assy	1921-24				30	4836D.....1
6161	Spray needle assembly	1921-24					
6162	Drain valve body clamp nut	1921-24				05	6395.....1
6163	Mix. chamber nut	1921-24				10	4810C.....1
6164	Constant air supply spring	1921-24					
							Order 6115
							Order 6125

†Used with mixing chamber having slots at bottom.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
KINGSTON CARBURETOR (MODEL "L-4")—Continued								
6165	Spray needle sleeve	1915-24				\$0 20	4812C	
6166	Float lever pin	1915-24				02	6320C	
6167	Constant air supply plate	1921-24					Order 6068	
6168	Throttle plate	1921-24					Order 6209	
6169	Drain valve plug assy.	1915-24				10	6329B	
6170	Throttle lever adj. screw	1915-24					Order 6120	
6171	Air valve stop assy.	1921-24				15	6397	
6172	Float valve seat	1921-24				20	6321E	
6173	Air valve shaft assy.	1921-24				20	6381B	
6174	Air valve	1921-24				30	6355B	
6175	Gasoline valve	1921-24				30	6324D	

FORD CARBURETOR PARTS (MODEL "G")

4451A	Float with lever	1914-21				25	6333AR	1
4452A	Spray needle assembly	1914-21	1 00			15	6335AR	1
4453A	Gasoline inlet needle	1914-21	1 00			15	6324A	1
6041	Mix chamber	1914-20				2 50	6340AR	
6042	Mix chamber top	1912-14-20				40	4801R	
6043	Mix chamber top screw	1912-20				02	4808R	
6044	Mix chamber top gasket	1914-20				01	6317R	
6044B	Mix chamber bottom gasket	1912-20				03	6367AR	
6045	Mix chamber nut	1912-20				07	4810AR	
6046	Float chamber & bush	1914-20				50	6318AR	
6047	Float lever pin	1914-20				03	6320AR	
6048	Float valve seat	1914-20				10	6321AR	
6049	Float valve seat gasket	1914-20				01	6322A	
6051	Spray needle clamp nut	1912-20				05	4812AR	
6052	Spray nozzle	1914-20				30	6341AR	
6053	Spray nozzle gasket	1912-14-20		50		01	4820AR	
6055	Gas inlet elbow	1913-20	1 00			15	4859	
6057	Low speed tube with nut	1915-20				15	6360R	
6058	Low speed tube retaining screw	1912-14-20				03	4814R	
6060	Low speed boss screw	1912-14-20				03	4816R	
6061	Strangling tube	1912-14-20				15	4817R	
6062	Strangling tube retainer	1912-14-20				02	4818R	
6064	Throttle lever stop screw	1911-21				02	4520A	
6065	Throttle lever clamp scr.	1911-19				02	4521AR	
6068	Throttle plate	1912-14-20				10	4517AR	
6070	Throttle lever	1912-14-20				10	4836B	
6070B	Throttle lever—over-size	1912-14-20				10	4836AR	
6071	Throttle lev. adj. lock nut	1911-20				02	4528R	
6074	Aux. throttle plate	1915-20				03	6337AR	
6076	Aux. throttle lever spring	1914-20				02	6342A	
6077	Aux. throttle lever assy.	1914-21				15	6327A	
4463	Float lever holding screw	1912-19				02	4805AR	
4464	Float lever holding screw	1913-19				03	4853AR	

Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.

KINGSTON CARBURETOR PARTS (MODEL "L-2")

6101A	Carburetor float assy.	1917-21				60	6333FR	1
6102	Throttle lever	1913-20				30	4836CR	
6103A	Constant air supply lever	1913-20				30	6327CR	
6104	Gas valve cap	1910-16				20	3005	
6105A	Air valve cap	1915-16				30	6357AR	
6105B	Air valve cap	1917-20				30	6357BR	
6106A	Float chamber	1917-20				1 00	4802DR	
6107A	Mix chamber	1917-20				2 50	6340FR	
6108	Mix chamber gasket	1913-16				15	6367CR	
6108A	Mix chamber gasket	1917-20				05	6367DR	
6109	Throttle gate	1915-20					Use 6068	
6110A	Constant air supply gate	1915-20				10	6337CR	
6111	Mix chamber nut	1913-20				10	4810BR	
6114	Gas valve retainer nut	1910-16				10	3027	
6115	Spray needle assembly	1910-21				40	6335D	1
6118A	Float to lever screw	1917-20				03	4853B	

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
KINGSTON CARBURETOR PARTS (MODEL "L-2")—Continued								
6120	Throttle lever adj. screw	1913-20				\$0 03	4520B	
6121	Throttle lev. clamp screw	1910-20				03	4521BR	
6122	Gas valve operating lever shaft	1913-16				15	6320DR	
6123	Air valve shaft	1915-20				20	6381AR	
6124A	Spray needle sleeve	1913-16					Order 6165	
6125	Constant air supply spring	1913-20				05	6342C	
6126	Float valve seat	1915-16				20	6321CR	
6126A	Float valve seat	1917-20				20	6321DR	
6127A	Gasoline valve	1917-21				30	6324CR	
6128	Air valve	1915-20				30	6355AR	
6129	Float valve seat gasket	1915-16				03	6322DR	
6129A	Float valve seat gasket	1917-20					Order 6049	

Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.

CARBURETOR ATTACHMENTS

4127A	Carburetor adj. rod brkt.	1909-22				05	1857 R	1
4129A	Carb. adjusting rod	1909-24				10	MH 7920	1
4130	Carb. flange bolt	1909-24						
4130B	Carb. flange bolt nut	1909-24						
4134	Carb. flange gasket	1909-24						
4431	Carb. priming rod	1909-24						
4582	Carb. hot air pipe	1912-24				15 00		
4583	Priming bell crank	1919-24				20	MH 686	1
4585	Priming rod plate—Coupe	1919-20				10	7664	1
4586	Priming rod plate—Sedan	1919-20				10	7665	1
4587B	Priming rod—17 1/2"	1919-22	1 00			15	MH 6629BR	1
4588B	Priming rod—13 1/2"	1919-22	1 00			15	MH 6627AR	1
*4588C	Priming rod—16 1/2"	1922	1 00			15	MH 6630AR	1
4588D	Priming rod—13 1/2"	1923-24	1 00			15	MH 6627B	1
4588E	Priming rod—17 1/2"	1923-24	1 00			15	MH 6629C	1
*4588F	Priming rod—16 1/2"	1923-24	1 00			15	MH 6630B	1
4589	Priming rod—20 1/2"	1919-24				05	MH 8797B	1
4589B	Priming rod—14 1/2"	1922-24				05	MH 8797A	1

FENDERS—56 INCH TREAD

4800B	Front fender—right	1917-23	35 00			4 00	MH 7976	1
4800C	Front fender—right	1923-24	35 00			4 00	MH 7976B	1
4801B	Front fender—left	1917-23	35 00			4 00	MH 7977	1
4801C	Front fender—left	1923-24	35 00			4 00	MH 7977B	1
4802F	Rear fender—right	1917-24	30 00			3 50	MH 8850	1
*4802G	Rear fender—right	1922-24	32 50			3 75	MH 7730	1
4802H	Rear fender—right	1923-24	35 00			4 00	MH 8850B	1
4803F	Rear fender—left	1917-24	30 00			3 50	MH 8851	1
*4803G	Rear fender—left	1922-24	32 50			3 75	MH 7731	1
4803H	Rear fender—left	1923-24	35 00			4 00	MH 8851B	1
4804D	Rear fender iron—R. & L.—T. C.	1913-24				15	5405	2
4804E	Rear fender iron—right Cp. & Rbt.	1913-23				50	5563AR	1
4804F	Rear fender iron—left Cp. & Rbt.	1913-23				50	5390AR	1
4804G	Rear fender iron—R. or L.—Sedan	1916-17				25	8154A	2
4804K	Fender iron—R. or L.—Sedan	1918-24				15	8154B	2
4804L	Rear fender iron—T. C.	1921-24				10	7395	2
4804-M	Rear fender iron—right	1923-24				50	5563B	1
4804-N	Rear fender iron—left	1923-24				50	5390B	1
4805B	Rear fender iron bolt	1915-24	\$0 20	\$1 50		03	7171	6
4805C	Rear fender iron bolt nut	1915-24	15	1 00	\$6 00	02	341	
4806B	Fender eye bolt	1909-24				05	1942	4
4806C	Fender eye bolt washer	1909-24		50	2 50	01	1943	4
4806D	Fender eye bolt nut	1909-24						
4808	Front fender iron bolt (side)	1910-24	25	2 00	15 00	03	1323	2
4808B	Front fender iron bolt (bottom)	1910-24	25	2 00	15 00	03	347	2

*For Four-door Sedan.

†Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot	Each			
FENDERS—56-INCH TREAD—Continued									
4808D.	Front fender iron bolt nut	1910-24	Order 2515						
4808C.	Front fender apron to frame bolt	1915-24	\$0 15	\$1 25	\$8 00	\$0 03	4088	4	
4808E.	Front fender apron to frame bolt nut	1915-24	Order 3088E						
4809	Front fender iron—R or L	1909-24				60	343	2	
4850	Frt.fender apron brkt.—R.	1917-24				10	8854	1	
4851	Frt.fender apron brkt.—L.	1917-24				10	8855	1	
4852	Frt. fender iron brkt.—R.	1915-24				10	7984	1	
4853	Frt. fender iron brkt.—L.	1915-24				10	7998	1	
4854	Rear fender iron bracket.	1915-24				10	7483	2	
4855	Rear fdr to R.B.shield bkt	1915-24				05	7994	2	

RUNNING BOARD AND SHIELDS—56 INCH TREAD

4812	Running board—R.	1909-24				1 25	MH	5418	1
4813	Running board—L.	1909-24				1 25	MH	5480	1
4814C.	R. B. shield—R.	1917-24				2 40	MH	7986	1
*4814D.	R. B. shield—R.	1922-24				2 40	MH	7747	1
4815C.	R. B. shield—L.	1917-24				2 40	MH	7987	1
*4815D.	R. B. shield—L.	1922-24				2 40	MH	7748	1
4816	R. B. truss rod—front with nuts	1909-21				35	MH	5804	1
4817	R. B. truss rod—rear with nuts	1909-21				35	MH	5805	1
4817B.	Truss rod nut	1909-21	20	1 50		03		339	4
4818H.	R. B. bracket assy.	1909-20				1 10		2926	2
4819	R. B. to rear fender bolt.	1909-20	15	1 25		03		1344B	4
4819B.	R. B. to rear fender bolt.	1921-24	20	1 50		03		8161	4
4819C.	R. B. to rear fender nut.	1909-24	Order 3088E						
4819D.	R. B. to rear fender nut.	1909-24	Order 3514						
4820	R. B. to front fender bolt and nut	1909-20	Order 4808C and 3088E						
4820C.	R. B. to front fender bolt	1921-24	Order 4805B						
4821	R. B. to shield clamp	1919-24				05		5478	

RUNNING BOARD—TRUCK

4830	Running board—R. or L.	1918-24				50	MH	TT5418	2
4831	R. B. bracket	1918-24				35	TT	2926	4
4832	R. B. bracket brace	1918-24				15	TT	2927	2
4833	R. B. bracket rear brace.	1918-24				30	TT	2929	1
4834	R. B. bracket—rear	1918-24				35	TT	2925	
4835	R. B. bracket and brace assy.—frt.	1918-24				50	TT	2928	
4836	R. B. bracket and brace assy.—rear	1918-24				1 10	TT	2930	

FORD SPARK COIL

5000	Coil (includes switch)	1909-22				8 65	MH	1383	1
5001	Coil (less switch)	1909-24				7 90	MH	1383B	1
5002	Coil box with cover	1914-22				2 25	MH	5858	1
5003	Coil box with cover	1919-24	14 00			1 50	MH	5858B	1
5004	Coil box cover	1915-24				25		7910	1
5005B.	Switch cover	1918-22				10		5835B	1
5006	Switch plug	1914-22	20	1 50		05		5815A	1
5007	Coil unit	1914-24	14 50	140 00		1 60	MH	5845	4
5908	Vibrator	1914-24	50	4 00	30 00	10		6797	4
5008B.	Vibrator and lower bridge assy.	1904	75	5 00		10		6737B	4
5009	Vibrator bridge	1914-24	70	6 00	52 00	10		6702	4

SWITCH

5010	Switch assembly (on coil).	1914-22				60		5873	1
5012	Ignition switch (on instrument board)	1919-24	8 00			1 00		7675E	1
5013B.	Switch key—give serial number	1919-24	50	4 50	40 00	10		5815C	1
5014	Starting switch (on floor bd)	1919-24	4 50			55	MH	8792	1
5014B.	Starting switch bracket bolt—long	1920-24		2 00		03		8760	1
5014C.	Starting switch brkt assy.	1923-24	2 50			30		8696	

*For Four-door Sedan.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot	Each			
SWITCH—Continued									
5014E.	Starting switch cover and plunger assy.	1923-24	\$ 1 50			\$0 20		8698	
5015	Starting switch plunger extension	1919-24	50			10		8793	1
AMMETER									
5016	Ammeter	1919-24	5 50	\$45 00C		65		7680	1
5017	Ammeter lens & rim	1919-24	1 50			20		8105	1
5017B.	Ammeter lens	1919-24				05		8121	1

STARTER DRIVE

5018	Starter drive	1919-24	36 00			4 00		1883	1
5019	Starter drive head	1919-24	4 00			50		2007	1
5020	Starter drive key	1919-24	15	1 00		02		1751	1
5021	Starter drive shaft & gear	1919-24				3 50		2026	1
5022	Starter drive spring	1919-24	2 50	20 00		35		2006	1
5023	Starter drive shaft spring screw	1919-24		2 25		03		1983	1
5024	Starter drive head spring screw	1919-24	30	2 50		05		1781	1
5025	Starter drive spring screw lock washer	1919-24		50		01		1782	2

WIRING

5026	Spark plug wire 14 3/4"	1909-24	70	6 50		10	MH	1365	1
5027	Spark plug wire (also magneto to coil) 10 3/4"	1909-24	65	6 00		10	MH	1366	1
5028	Spark plug wire, 7"	1909-24	60	5 00		10	MH	1376	2
5030	Commutator wire	1909-22				80	MH	7502AR	1
*5030B	Commutator wire	1922-24				1 00	MH	7502C	1
5031	Com. wire (starter type)	1919-24				1 00	MH	7502B	1
5033	Com. wire loom support	1909-24				03		1390	2
5033B.	Com wire term. retainer	1921-24				01		2124	2
5033C	Wire on dash clip	1919-24				01		7688	7
5034	Ammeter to cutout wire—Sedan 33"	1919				15	MH	7683A	1
5035	Ammeter to cutout wire—Sedan 49"	1919-24				20	MH	7683B	1
5036	Ammeter to cutout wire—Coupe 23"	1919				15	MH	7684A	1
5037	Ammeter to cutout wire—Coupe 41"	1919-24				15	MH	7684B	1
5038	Ammeter to ignition switch wire	1919-24	80			10	MH	7681	1
5039	Gen. to cutout wire	1919				15	MH	7687	1
5040	Terminal block to switch wire	1919-24	60			10	MH	8894B	1
5041	Lighting wire	1919-24				90	MH	7682B	1
5041B.	Lighting wire—truck	1921-24				1 00	MH	TT7682	1
*5041C.	Lighting wire	1922-24	4 50			50	MH	7661	1
5042	Switch wire—Sedan	1919-24	6 50			75	MH	7685B	1
5043	Switch wire	1919-24	6 00			70	MH	7686B	1
*5043B.	Switch wire	1922-24	3 50			40	MH	7660	1
5044	Terminal block	1919-24				05		1950AR	1
5044B.	Terminal block	1923-24	60	5 00		10		1950B	1
*5044C.	Terminal block	1922				05		1951AR	1
*5044D.	Terminal block	1923-24	60	5 00		10		1951B	1
5045	Terminal block to dash screw	1919-24				01		2073	2
5046	Battery to switch cable—28 3/4"	1919-24				80	MH	1889B	1
5046C.	Battery to switch cable—truck	1921-24	7 00			80	MH	TT1889	1
5047	Battery to switch cable—34"	1920				75	MH	1889C	1
5047B.	Battery to switch cable support—truck	1920-24	50			10		2116	1
5047C.	Battery to switch cable support	1920-24	75			10		2112	1

*Used on cars without starter, with switch on instrument panel.

†Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
WIRING—Continued								
5047D.	Battery to switch cable support bush.....	1920-24				05	2113	1
5047E.	Battery to switch cable sleeve.....	1921-24				05	2120	1
5048.	Ground cable—20".....	1919				70	MH. 1890A	1
5049B.	Ground connector.....	1919-24	\$2 50			30	MH. 1890B	1
5050.	Ground cable—11 1/2".....	1920				60	MH. 1890C	1
5051.	Switch to motor cable.....	1919-23				50	MH. 1891	1
5051B.	Switch to motor cable sleeve.....	1921-24	2 50			30		1
5052.	Battery cable terminal bolt.....	1919-24				02	1937	2
5052B.	Battery cable terminal bolt nut.....	1919-24				01	1938	2
CUT-OUT								
5055.	Cut-out (electric).....	1919-24	8 00	\$70.00		1 00	MH. 7677B	1
STARTER PARTS								
5056.	Motor mount'g gasket.....	1919-24	15	1 20		02	1768	
5057.	Gen. head gasket.....	1919-24	10	60		02	1774	
5058.	Gen. m'nt'g short screw.....	1919-24	20	1 50		03	1755	
5059.	Bendix cover screw.....	1919-24		50		01	1765	
5060.	Term. blk. to wire screw.....	1919-24		50		01	2015	
5061.	Ammeter to plate screw.....	1919-24		50		01	5819	
5062.	Motor mounting screw.....	1919-24	15	1 00		02	5510	
STARTING MOTOR AND PARTS								
5099.	Starting motor.....	1919-24	135 00			15 00	MH. 1877	
5100.	Armature.....	1919-24	45 00			5 00	1940	
5101.	Cover band.....	1919-24				10	1801C	
5102.	Brush end bracket.....	1919-24				30	1868	
5103.	Bracket assy. mounting.....	1919-24				1 30	2037	
5104.	Brush.....	1919-24		17 00		20	1806	
5105.	Shaft rear bushing.....	1919-24				30	1759	
5106.	Shaft front bushing.....	1919-24		7 50		10	1789	
5107.	Field coil assembly.....	1919-24				2 50	1871	
5108.	Brush holder assembly.....	1919-24				45	1864B	
5109.	Terminal outer insulator.....	1919-24	15	1 00		02	1795	
5110.	Terminal inner insulator.....	1919-24		50		01	1794	
5112.	Terminal nut.....	1919-24	20	1 50		03	1791	
5113.	Field screw.....	1919-24	15	1 00		02	1788	
5114.	Brush end bracket to yoke screw.....	1919-24				doz. 05	1808	
5115.	Brush tension spring.....	1919-24	25	2 00		05	1809	
5116.	Terminal washer.....	1919-24		50		01	1792	
5117.	Terminal inner steel washer.....	1919-24		50		01	1798	
5118.	Motor yoke assembly.....	1919-24				3 50	1852	
GENERATOR AND PARTS								
5119.	Generator.....	1919-24	135 00			15 00	MH. 1879	
5120.	Armature (less bearings).....	1919-24	40 00			4 50	1925	
5121.	Small bearing.....	1919-24	10 00			1 10	1838	
5122.	Large bearing.....	1919-24	11 00			1 25	1841	
5123.	Terminal bolt.....	1919-24		1 50		03	1836	
5124.	Brush end bracket.....	1919-24				25	1894	
5125.	Large brush.....	1919-24	1 35	12 00		15	1844	
5126.	Small brush.....	1919-24	1 35	11 50		15	1845	
5127.	Large bearing disc.....	1919-24		2 00		03	1847	
5128.	Small bearing felt.....	1919-24	15	1 00		02	2033	
5130.	Head.....	1919-24				50	2044	
5131B.	Small brush holder.....	1919-24	90	8 00		10	1821	
5132B.	Brush holder ring.....	1919-24				03	1996	
5132C.	Brush holder assembly.....	1919-24				40	1865	
5132D.	Brush holder assembly less small brush holder.....	1919-24				\$0 30	1920	

†Also for generator.

†Armature may be exchanged with dealer at \$4.00.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
GENERATOR AND PARTS—Continued								
5133.	Terminal outer insulator.....	1919-24	\$0 15	\$1 00		\$0 03	1827	
5134.	Terminal nut.....	1919-24	15	1 00		03	1818	
5134B.	Brush holder stud nut.....	1919-24				01	6754	
5135.	Oilier.....	1919-24				05	1837	
5136.	Pinion to shaft pin.....	1919-24				doz. 05	1750	
5137.	Pinion.....	1919-24	3 00			35	1752	
5138.	Small brg. felt retainer.....	1919-24		1 00		02	1832	
5139.	Large brush spring.....	1919-24	30	2 50		05	1967	
5140.	Small brush spring.....	1919-24	35	3 00		05	1988	
5141B.	Small brush holder stud.....	1919-24	10	80		02	1823C	
5142.	Terminal washer.....	1919-24		50		01	1831	
5142B.	Small brush holder stud washer.....	1919-24		30		doz. 05	2058	
5143.	Field winding assembly.....	1919-24	14 00			1 50	1978	
5144.	Brush to terminal wire.....	1919-24		3 00		05	1851	
5145.	Gen. yoke assembly.....	1919-24				3 00	1887	
BATTERY BRACKET AND PARTS								
5150.	Bracket assembly.....	1919-23				75	MH. 8841AR	
*5150B.	Battery bracket assy.....	1923-24				75	MH. 8841B	1
5151.	Clamp bolt.....	1919-24		2 00		03	8846	
5151B.	Clamp bolt nut.....	1919-24						
5152.	Clamp.....	1919-23				05	8844AR	
*5152B.	Battery clamp.....	1921-24				05	8844B	2
5153.	Battery support angle—truck.....	1921-24	1 25			15	TT8816	1
5154.	Battery box support—truck.....	1921-24	1 50			20	TT8817	2
5155.	Battery clamp support—rear—truck.....	1921-24	1 00			15	TT8818	1
5156.	Battery clamp support—front—truck.....	1921-24	1 00			15	TT8819	1
5158.	Battery box—less cover.....	1921-24				60	7671	1
5159.	Battery box cover assy.....	1921-24	5 00			60	5491	1
5160.	Battery box cover door.....	1921-24				10	5493	
BATTERY (FORD)								
5175.	Battery.....	1919-24				†16 50	MH. 7670	1
5176.	Battery case assy.....	1919-24				1 25	5434	
5177.	Cell connector.....	1919-24	80			10	5435	
5178.	Cell cover.....	1919-22				30	5436AR	
5178B.	Cell cover.....	1921-24	1 50			20	5436B	
5178C.	Cell cover.....	1923-24	1 50			20	5436C	3
5179.	Terminal post gasket.....	1919-22				01	5437AR	
5179B.	Terminal post gasket.....	1921-24		.60		01	5437B	
5179C.	Terminal post gasket.....	1923-24		.60		01	5437C	
5180.	Rubber jar.....	1919-24	5 50			60	5438	
5181.	Terminal post nut.....	1919-22	30	2 50		04	5439AR	
5181B.	Terminal post nut.....	1921-24	30	2 50		04	5439B	
5182.	Negative group assy.....	1919-22				2 00	5440AR	
5182B.	Negative group assy.....	1921-24				1 70	5440B	
5183.	Positive group assy.....	1919-22				2 00	5441AR	
5183B.	Positive group assy.....	1921-24				1 70	5441B	
5184.	Filler plug with gasket.....	1919-22	1 00	9 00		15	5444AR	
5184B.	Filler plug with gasket.....	1921-24	1 00	9 00		15	5444B	
5184C.	Filler plug.....	1923-24	75	5 00		10	5442C	
5185.	Plate separator.....	1919-24		2 50	\$18 50	05	5445	
5186.	Positive plate.....	1919-22				25	5427AR	
5186B.	Positive plate.....	1921-24				25	5427B	
5187.	Negative plate.....	1919-22				25	5428AR	
5187B.	Negative plate.....	1921-24				25	5428B	
5188.	Negative terminal post.....	1919-22	1 75			20	5425AR	
5188B.	Negative terminal post.....	1921-24	1 25			15	5425B	
5189.	Positive terminal post.....	1919-22	1 75			20	5426AR	
5189B.	Positive terminal post.....	1921-24	1 25			15	5426B	
5190.	Terminal—negative.....	1909-24	1 20			15	1929B	
5191.	Terminal—positive.....	1909-24	1 20			15	2049	
M6022.	Battery Sealing Compound		10 lb.			per lb.	15	
M1051.	Electrolyte							
SPARK PLUGS								
5201.	Spark plug "Ford" (Champion).....	1909-24	4.50 net.	40.00 net.		160	1386A3	4
5203B.	Spark plug porcelain "Ford" (Champion).....	1909-24	2.20 net.	20.00 net.		130	3760C	4

*Used with steel battery box.

†Not subject to regular discount.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Co. 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	LIST PRICE			Tax Status	Fac. No.
		Lots of 10 per lot	Lots of 100 per lot	List Price Each		
REPAIR TOOLS						
1349	Hub cap wrench	\$1 00		\$0 15		1349
1387	Adjustable wrench	3 50		40		1387
1903	Pliers			25		1903
1917	Double end wrench		\$12 00	15		1917
2335	Spark plug and cyl. head bolt wrench			40		5893
2336	Tool roll			20		1979
2337	Oil can	1 50		20		1384
2338	Tire pump			1 20	MIL	1368
2340	Tire irons, each			15		4069
2343	Jack	11 00		1 25		3389
TT4069	Tire iron (large)			40		
5-Z-152	Rear axle housing bolt nut wrench	3 00		40		
5Z-153	Socket wrench for crank shaft bearing nut	4 00		50		
5Z-154	Body bracket con. bolt R. & L. wrench			30		
5Z-155	1/4" L socket wrench	3 50		45		
5Z-156	Crank shaft bearing bolt wrench	3 00		45		
5Z-157	Con. rod cap bolt nut L wrench Cyl. No. 4)	3 00		40		
5Z-158	D S housing stud nut wrench for 1/2" nut	3 00		45		
5Z-159	Connecting rod T wrench	4 50		55		
5Z-160	1/2" T socket wrench	4 30		50		
5Z-161	Body bracket connecting bolt T wrench, front and center	3 60		45		
5Z-162	Large cam gear lock nut wrench			75		
5Z-165	Drive shaft pinion T wrench	5 00		60		
5Z-193	Spindle cone adjusting open end wrench	3 00		35		
5Z-195	1/4" open end wrench	2 00		25		
5Z-196	Rear axle entering wrench			30		
5Z-204	Exhaust pack nut open end wrench	8 00		90		
5Z-206	Rear axle nut open end wrench			55		
5Z-209	Connecting rod clamp screw wrench	4 00		45		
5Z-210	Fly wheel cap screw wrench	5 00		60		
5Z-212	Body bracket connecting bolt holding open end wrench			25		
5Z-232	Spindle arm bushing driver			40		
5Z-249	Generator third brush adj. wrench—new style			20		
5Z-280	Valve grinder	5 00		60		
5Z-285	1/4" hex. brace wrench	5 00		60		
5Z-287	Rear wheel puller assembly			80		
5Z-289	1/4" brace socket wrench			65		
5Z-290	Piston ring squeezer			30		
5Z-314	Transmission clutch disc drum puller	5 50		65		
5Z-319	Valve spring lifter			30		
5Z-323	Bendix shaft head puller	4 50		60		
5Z-324	Trans. band ratchet wrench	4 00		50		
5Z-325	Con. rod cap bolt nut brace wrench with universal joint for No. 4 connecting rod	16 00		1 80		
5Z-326	Small time gear and trans. driven gear puller			1 70		
5Z-361	Large time gear puller			6 50		
5Z-362	Cam gear puller (3-spoke design)			6 00		
5Z-457	Valve seat reamer—Old No. 20Z-340			2 50		
20Z-340-1	Valve seat reamer cutter			1 50		
21Z-356	Valve seat reamer handle			1 00		

REPAIR TOOLS—TRUCK

5Z-288	Rear wheel puller assembly	1 80
3389X	Jack	2 40

COTTER PINS

	Fac. No.		Fac. No.
3/8" x 1" cotter pins	421	3/8" x 1 1/2" cotter pins	66
1/2" x 3/4" cotter pins	753	1/2" x 1 1/2" cotter pins	544
1/2" x 1" cotter pins	82	3/4" x 1 1/2" cotter pins	88
Price, per dozen			05
Price, per gross			25
Price, per thousand			75

FORD SPECIALTIES

	Each
**4095BX... Emergency kit	\$11 50
7962ARX... Tire repair kit	140
7962BX... Tire repair kit (small)	125
M-111... Black touch-up enamel 1/2 pt.	11 00
M-165... Black enamel (air-dry) 1 qt.	11 00

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

†Not subject to regular discount

Part No.	Name of Part	Year	LIST PRICE			Tax Status
			Lots of 10 per lot	Lots of 100 per lot	Each	
FORD SPECIALTIES—Continued						
5760X	Dash lamp		\$5 50	\$50 00		\$ 60
5773X	Dash lamp cap					10
18257X	Windshield wiper		9 00	75 00		1 25
17343X	Windshield wiper nut					02
118259X	Rear view mirror assy.		12 00	100 00		1 50 .MH
117853X	Rear view mirror assy.		12 00	100 00		1 50 .MH
18253X	Rear view mirror only		5 50	45 00		65
ELECTRIC HORN						
6432BRX	Electric horn complete					1 50
6432CX	Electric horn complete—battery type					1 60
7915X	Electric horn terminal wire 9'					05 .MH
7917BX	Electric horn to switch wire 35 1/4'					10 .MH
8028X	Horn switch assembly		2 50			30 .MH
6437CX	Battery horn bracket					10
ELECTRIC HEADLAMPS (STANDARD 1915-24)						
6511HX	Headlamp assembly	pr.		pr		5 50
6511KX	Headlamp assembly	pr.		pr		5 50
6594AX	Door assembly—used with 6511DX					60
6594HX	Door assembly with refracting lens		\$ 5 50			65
6589X	Switch assembly—with screws					30 .MH
8650X	Headlamp and horn switch assembly					40 .MH
8892ARX	Dimmer resistance coil with wires					50 .MH
*8892BX	Dimmer assembly					50 .MH
*8890X	Dimmer cover					10
6572AX	Headlamp bulb—9 volt—18 c.p.—double contact—used with magneto without dimmer				1915-18	\$27 50
6572HX	Headlamp bulb—6-8 volt—bright, 21 c.p., dim, 6/10 c.p.—double contact—double filament—used with T6576HX lens				1922-24	36 00
6572KX	Headlamp bulb—6-8 volt—21 c.p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens				1922-24	30 00
6578X	Door lens gasket					03
6576HX	Headlamp lens—refracting—in carton (Pair)	pr.		45 00		50
6592X	Plug—with thimble			7 50		10
6585AX	Reflector		6 00			75
6585BX	Reflector (dimmer type)					90
6580X	Focusing screw					03
6591X	Focusing screw spring					01
6574X	Bulb socket		1 25			15
6574BX	Head lamp plug socket					15
6586X	Reflector spring					05
7487X	Switch to terminal wire—11 3/4" long					05 .MH
7489X	Lamp to lamp wire—40" long					10 .MH
7490X	Lamp to ground wire—10 3/4" long					05 .MH
2122X	Head lamp wire bushing					03
4082X	Head lamp and tail lamp wire bushing					01
SIDE OIL AND TAIL LAMPS—1915-24						
6561X	Side oil lamp, per pair	pr.				4 50
6568X	Tail lamp					2 50
6568BX	Oil tail lamp				1923-24	2 50
7669X	Electric tail lamp assembly		8 00			90
18786CX	Electric tail lamp and license brkt. assy.		9 00			1 00 .MH
6484AX	Tail lamp red lens				1915-24	15
6484BX	Electric tail lamp red lens			10 00		15
6484DX	Oil tail lamp side lens (rod)				1924	10
6405CX	Electric tail lamp, white lens					15
6405EX	Oil tail lamp door lens (white) Edmonds & Jones design				1924	15
6405FX	Oil tail lamp door lens (white) J. W. Brown design				1924	15
6406X	Electric tail lamp white lens retainer				1923	05
6520X	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2 3/4 c.p.—single contact		1 80		1919-24	20

*Used on cars without starter with switch on instrument panel.

†Includes lamp.

**Consists of 1 spark plug, 2 head lamp bulbs and 1 tail lamp bulb in carton.

††For closed cars. ‡‡For open cars.

Part No.	Name of Part	Year	LIST PRICE		Tax Status
			of 10	of 100 Each	

SIDE OIL AND TAIL LAMPS—1915-24—Continued

6495X	Electric tail lamp bulb socket		\$0	15	
2107X	Tail lamp wire clip			01	
2108X	Tail lamp wire spring			03	
6409X	Tail lamp wire bushing assembly			03	
6410X	Tail lamp wire bushing support			01	
TT8821X	Tail lamp to ground wire assembly		15	MH	
6599X	Side oil and tail lamp fount		50		
6956X	Side oil lamp door		50		
6957X	Tail lamp door		50		
6957BX	Tail lamp door		50		
6966X	all lamp white lens and frame		20		
6460X	Lamp burner		25		
6483X	Side oil lamp door lens		15		
6392X	Lamp wick		05		

TOURING CAR AND TORPEDO WINDSHIELDS—1915-22

7840ARX	Windshield assembly		110	50	MH
7818BX	W/S hinge assembly—right	1917-22		40	
7819BX	W/S hinge assembly—left	1917-22		40	
7820BX	W/S frame assembly—upper	1917-22	1	50	
7822BX	W/S upper half assembly	1917-22	14	50	MH
7823ARX	W/S lower half assembly	1915-22	15	25	MH
7802ARX	W/S lower frame only	1915-22	1	00	
7803ARX	W/S lower frame filler block	1915-22		20	
7839X	W/S frame filler block	1915-17		15	
7888ARX	W/S block (frame filler)—upper	1917-22		20	
7810X	W/S hinge bolt	1915-16		03	
7845ARX	W/S bracket—right	1915-22		50	
7845BX	W/S bracket—right	1919-22		50	
7846ARX	W/S bracket—left	1915-22		50	
7846BX	W/S bracket—left	1919-22		50	
7824ARX	W/S glass clamp	1915-22		02	
7887X	W/S frame—upper	1917-22		75	
3827X	W/S top snap loop	1915-22		02	
1154X	W/S hinge bolt nut	1915-22		02	
2449BX	W/S glass clamp screw	1915-22		01	
2257BX	W/S hinge to frame screw	1915-22		02	
292X	W/S hinge spring				
7851ARX	W/S upper glass stop—nickel	1915-22		20	
7852ARX	W/S lower glass stop—nickel	1915-22		20	
7808X	W/S hinge thimble	1915-22		03	
7827AX	W/S glass—upper	1915-22	13	00	
7828X	W/S glass—lower	1915-22	13	50	

TOURING CAR AND ROADSTER WINDSHIELDS—1922-24

7836X	Anti-rattler (windshield)	1922-24		15	
6645X	Bolt (W/S bracket to instrument panel)	1922-24		03	
7837X	Bracket (windshield) assembly—R. H.	1922-24		60	MH
7838X	Bracket (windshield) assembly—L. H.	1922-24		60	MH
*7891X	Bracket (side oil lamp)	1922-24		30	
9066X	Channel (windshield) center	1922-24		35	
7816X	Cone (W/S frame)	1922-24		10	
7802BX	Frame (windshield) assembly—lower	1922-24	1	00	
7887CX	Frame (windshield) assembly—upper	1922-24	1	00	
7888BX	Filler (windshield upper frame)—lower	1922-24		05	
7847X	Filler (windshield upper frame)—upper	1922-24		05	
7803BX	Filler (windshield lower frame)	1922-24		10	
7827BX	W/S glass—upper	1922-24	12	75	
9534X	W/S glass—lower	1922-24	13	00	
7825X	Nut (windshield clamp stud wing)	1922-24		15	
7842X	Nut (windshield cone lock)	1922-24		02	
1307X	Nut (windshield bracket to instrument panel bolt) lower	1922-24		05	
7851BX	Retainer (windshield glass) upper	1922-24		20	
7852BX	Retainer (windshield glass) lower	1922-24		20	
7826X	Stud (windshield frame clamping)	1922-24		03	
7833X	Washer (windshield clamp stud nut)	1922-24		01	
7840BX	Windshield assembly	1922-24	11	50	MH
7822CX	Windshield (upper half) ass'y.	1922-24	14	75	MH
7823BX	Windshield (lower half)	1922-24	15	00	MH
*8064X	Windshield bracket to body bolt	1922-24		02	

*Used on cars without starter

†Not subject to regular discount

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE		Tax Status
			of 100	Each	

TOURING CAR TOPS—1915-22

7940ARX	Touring car top complete	1915-22		\$27	00	MH
6882ARX	T. C. storm curtain—R. H.	1915-22		2	00	MH
6883ARX	T. C. storm curtain—L. H.	1915-22		2	00	MH
4966BRX	T. C. side curtain—R. H.	1915-22		2	50	MH
4967BRX	T. C. side curtain—L. H.	1915-22		2	50	MH
6894ARX	T. C. center deck complete	1915-22		7	00	MH
6815ARX	T. C. side quarter pad	1915-22		1	00	
6940ARX	T. C. back stay and curtain assembly	1915-22		3	00	MH
3897X	T. C. wood bow	1913-17			60	
8973ARX	T. C. front and rear extension rib	1918-22			30	
8974ARX	T. C. front and rear upright rib	1918-22			30	
4596X	T. C. bow separator—male	1913-17			05	
4597X	T. C. bow separator—female	1913-17			05	
6832X	T. C. bow separator	1918-22			05	
6860BRX	T. C. front extension rib socket—R. H.	1918-22			1	00
6861BRX	T. C. front extension rib socket—L. H.	1918-22			1	00
3884BRX	T. C. rear extension rib socket—R. H.	1918-22			1	00
3885BRX	T. C. rear extension rib socket—L. H.	1918-22			1	00
6862BRX	T. C. front upright rib socket—R. H.	1918-22			1	00
6863BRX	T. C. front upright rib socket—L. H.	1918-22			1	00
3882BRX	T. C. rear upright rib socket—R. H.	1918-22			1	00
3883BRX	T. C. rear upright rib socket—L. H.	1918-22			1	00
7831ARX	Curtain to windshield hook	1915-22			02	
7832X	Curtain to body hook	1915-22			02	
8992X	Rib socket cotter	1918-22			02	
3924RX	T. C. top to windshield strap assembly	1915-22			25	
3629ARX	T. C. rear strap assembly complete	1913-21			40	
3629BRX	Stay strap assembly	1921-22			40	
6829BX	T. C. extension support—upper	1918-22			10	
6830BX	T. C. extension support—lower	1918-22			05	
8937X	T. C. toy snap fastener—single	1917-22		\$ 3	50	05
8938X	T. C. top snap fastener—double	1917-22		3	50	05
3314ARX	T. C. top prop rest with strap	1913-22			60	
3858X	T. C. top prop rest arm	1913-21			25	
3624X	T. C. bow socket to seat iron japanned nut	1913-22			03	
6682X	Curtain celluloid 20" x 50"—.015 thick (old No. 3383X)	1913-22			2	20
4981ARX	Touring car top visor	1920-22			50	
8940X	Curtain fastener eyelet	1917-22			75	01
8943X	Curtain fastener eyelet washer	1917-22			50	01

TOURING CAR TOPS—1922-24

3573X	Brace (top extension)—R. H.	1922-24			25		
3574X	Brace (top extension)—L. H.	1922-24			25		
*3588X	Top clamping bracket assembly	1922-24			20		
**6902X	Glove fastener button	1922-24			02		
††6940BRX	Curtain (rear) assembly	1922			2	50	MH
6940CX	Curtain (rear) assembly	1922-24			2	30	MH
††4966CRX	Curtain (rear side) assembly—R. H.	1922			2	00	MH
4966DX	Curtain (rear side) assembly—R. H.	1922-24			1	75	MH
††4967CRX	Curtain (rear side) assembly—L. H.	1922			2	00	MH
4967DX	Curtain (rear side) assembly—L. H.	1922-24			1	75	MH
6882BX	Curtain (front side) assembly—R. H.	1922-24			1	75	MH
6883BX	Curtain (front side) assembly—L. H.	1922-24			1	75	MH
††6894BRX	Deck (top) assembly	1922			6	50	MH
6894CX	Deck (top) assembly	1922-24			6	50	MH
**6903X	Eyelet (slide curtain rear glove fastener)	1922-24			02		
**6904X	Fastener (rear curtain glove)	1922-24			02		
**7831BX	Hook (curtain to windshield)	1922-24			02		
6815BX	Pad (top side quarter) assembly	1922-24			1	00	
**3314BX	Rest (prop) and strap assembly	1922-24			40		
8975X	Rib (top) center and rear	1922-24			30		
8973BX	Rib (top) front	1922-24			30		
8974DX	Rib (top) center ext.	1922-24			30		
**3548X	Screw (front socket fastener)	1922-24			doz.	05	
6860CX	Socket (top rib) front—R. H.	1922-24			1	00	
6861CX	Socket (top rib) front—L. H.	1922-24			1	00	
3882CX	Socket (top rib) center—R. H.	1922-24			1	00	
3883CX	Socket (top rib) center—L. H.	1922-24			1	00	

*Not subject to regular discount.

††Used on tops with straight side quarters.

**Also used on 1922 Roadster Top.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents the excise tax.

Part No.	Name of Part	Year	LIST PRICE		Tax Status
			Lots of 10 per lot	List Price Each	

TOURING CAR TOPS—1922-24—Continued

†3884CRX	Socket (top rib) rear—R. GH.	1922		\$1 25	
3884DX	Socket (top rib) rear—R. H.	1922-24		1 00	
†3885CRX	Socket (top rib) rear—L. H.	1922		1 25	
3885DX	Socket (top rib) rear—L. H.	1922-24		1 00	
6862CX	Socket (top rib) center ext.—R. H.	1922-24		1 00	
6863CX	Socket (top rib) center ext.—L. H.	1922-24		1 00	
6844BX	Top center strainer	1922-24		40	
6846X	Top quarter strainer	1922-24		40	
*3629CX	Strap (stay)	1922-24		20	MH
*6901X	Stud (rear curtain glove fastener)	1922-24		02	
3551X	Center support on rear socket	1922-24		05	
3564X	Center ext. support—on center socket	1922-24		05	
3572X	Center ext. to brace support	1922-24		05	
7940BX	Top assembly	1922-24		†27 00	MH
*4981BX	Visor (top) assembly	1922-24		75	
*6905X	Washer (side curtain rear glove fastener)	1822-24		02	

TORPEDO TOP PARTS—1915-22

7941ARX	Torpedo top complete	1915-22		†22 00	MH
4971X	Torpedo top—second and third wood bows	1914-18		50	
6929X	Torpedo top—first bow	1915-18		50	
8772X	Rib—upright	1918-22		60	
8988X	Rib—front extension	1918-22		30	
8989X	Rib—rear extension	1918-22		30	
6870AX	Torp. bow socket—upright—(R. H.)	1915-18		1 25	
6870BX	Torp. rib socket—upright—(R. H.)	1918-22		1 00	
6871AX	Torp. bow socket—upright—(L. H.)	1916-18		1 25	
6871BX	Torp. rib socket—upright—(L. H.)	1918-22		1 00	
6872AX	Torp. bow socket—front extension—(R. H.)	1915-18		1 00	
6872BX	Torp. rib socket—front extension—(R. H.)	1918-22		1 00	
6873AX	Torp. bow socket—front extension—(L. H.)	1915-18		1 00	
6873BX	Torp. rib socket—front extension—(L. H.)	1918-22		1 00	
4907AX	Torp. bow socket—rear extension—(R. H.)	1913-18		1 00	
4907BX	Torp. rib socket—rear extension—(R. H.)	1918-22		1 00	
4908AX	Torp. bow socket—rear extension—(L. H.)	1913-18		1 00	
4908BX	Torp. rib socket—rear extension—(L. H.)	1918-22		1 00	
6937AX	Torp. side curtain—rear—(R. H.)	1915-22		1 50	MH
6938AX	Torp. side curtain—rear—(L. H.)	1915-22		1 50	MH
6935AX	Torp. side curtain—front—(R. H.)	1915-22		2 00	MH
6936AX	Torp. side curtain—front—(L. H.)	1915-22		2 00	MH
6950AX	Torp. back curtain assembly	1915-22		2 50	MH
6965AX	Torp. center deck complete	1915-22		4 50	MH
6806AX	Torp. side quarter pad	1914-22		60	
3877X	Torp. prop rest with strap	1913-22		60	
4955AX	Torp. top visor	1920-22		50	

ROADSTER TOP—1922-24

6935BX	Curtain (front side) assembly—R. H.	1922-24		1 25	MH
6936BX	Curtain (front side) assembly—L. H.	1922-24		1 35	MH
6937BX	Curtain (rear side) assembly—R. H.	1922-24		90	MH
6938BX	Curtain (rear side) assembly—L. H.	1922-24		90	MH
6950BX	Rear curtain assembly	1922-24		2 30	MH
6965BX	Top deck assembly	1922-24		3 50	MH
6806BX	Top side quarter pad assembly	1922-24		60	
8988BX	Top rib—front	1922-24		30	
8989BX	Top rib—center and rear	1922-24		30	
4907CX	Top rib socket, rear—R. H.	1922-24		1 00	
4908CX	Top rib socket, rear—L. H.	1922-24		1 00	
6872CX	Top rib socket, front	1922-24		1 00	
6870CX	Top rib socket, center—R. H.	1922-24		1 00	
6871CX	Top rib socket, center—L. H.	1922-24		1 00	
7941BX	Top assembly	1922-24		†22 00	MH

†Not subject to regular discount.

**Also used on 1922 Roadster Top.

‡For additional 1922 Roadster top parts see 1922 Touring Car top parts marked with a double asterisk (**)

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	LIST PRICE			Fac. Req. No. per Car
			Lots of 10 per lot	Lots of 100 per lot	Tax Status	

REAR AXLE

1000	Rear axle assembly	1918-24		\$110 00	MH	TT	95	1
1001	Axle housing—right	1918-24		15 00	MH	TT	4	1
1002	Axle housing—left	1918-24		15 00	MH	TT	5	1
1003	Axle housing bolt	1918-24		03		TT	52	13
1003B	Axle housing bolt nut	1918-24						
1004	Axle housing cap	1918-24						
1005	Axle housing cap gasket	1918-24		\$1 50				
1006	Axle housing cap screw	1918-24						
1007	Axle housing cap screw lock wire	1918-24						
1008	Axle housing gasket—upper	1918-24		1 00				
1009	Axle housing gasket—lower	1918-24		3 00				
1010	Axle brake housing plate—right	1918-24						
1011	Axle brake housing plate—left	1918-24						
1012	Axle housing drain plug	1918-24						
1013	Axle shaft	1918-24		4 00	MH	TT	48	2
1014	Axle shaft cotter	1918-24		doz. 05		TT	165	2
1015	Axle shaft nut	1918-24		\$0 90	8 00		10	TT 166 2
1016	Axle shaft washer	1918-24		25	2 00		03	TT 135 2
1017	Axle shaft dust cap	1918-24					03	TT 56 2
1018	Axle shaft inner ball bear. assy.	1918-24		5 00			01	TT 125 2
1019	Axle shaft outer roller bearing	1918-24		10 00			1 25	TT 253 2
1020	Axle shaft outer R. B. sleeve—R.	1918-24					35	TT 170 2
1020B	Axle shaft outer R. B. sleeve—L.	1918-24					35	TT 161 1
1021	Axle shaft bearing felt	1918-24		1 20	10 00		15	TT 143 4
1022	Axle shaft bearing retainer	1918-24					05	TT 20 2
1023	Axle shaft bear. retainer washer	1918-24		1 50			02	TT 23 2
1024	Axle shaft felt retainer assembly	1918-24					20	TT 144 1
1025	Axle shaft felt retainer cup	1918-24					03	TT 145 2
1026	Axle shaft felt retainer plate	1918-24					03	TT 146 2
1027	Diff. gear	1918-24		1 15	MH	TT	13	2
1028	Diff gear case R. or L. half	1918-23		2 50	MH	TT	11A	2
1028B	Differential gear case—R. or L. half	1923-24						
1029	Diff gear case bolt	1918-24					02	TT 118 2
1031	Diff. gear lock ring	1918-24					50	MH TT 14 2
1032	Diff. pinion	1918-24					20	MH TT 15A 1
1033	Diff. pinion shaft	1918-23					1 50	MH TT 15B 1
1033B	Differential spider	1923-24					7 00	MH TT 87 1
1034	Drive shaft	1918-24					10 00	MH TT 153 1
1036	D. S. tube assembly	1918-24		15	1 25		02	TT 194 1
1037	D. S. tube flange gasket	1918-24						
1038	D. S. tube flange screw	1918-24						
1039	D. S. felt	1918-24						
1040	D. S. felt container	1918-24						
1041	D. S. to worm coupling	1918-19						
1041B	D. S. to worm coupling	1920-24						
1042	D. S. to worm coupling pin	1918-24						
1043	Worm—7 1/2 to 1	1918-24					6 00	MH TT 16A 1
1043B	Worm—5 1/2 to 1	1918-24					6 00	MH TT 16B 1
1044	Worm gear—7 1/4 to 1	1918-24					10 00	MH TT 12A 1
1044B	Worm gear—5 1/2 to 1	1918-24					10 00	MH TT 12B 1
1045	Worm cotter	1918-24						
1046	Worm roller bearing	1918-24					75	TT 108 2
1047	Worm roller bearing retainer	1918-24					02	TT 106 1
1048	Worm roller bearing sleeve	1918-24		10 00			1 20	TT 107 2
1049	Worm roller bear. housing screw	1918-24					03	TT 101 2
1050	Worm thrust bearing collar	1918-24					80	TT 114 2
1051	Worm thrust ball and sep. assy.	1918-24		5 00			60	TT 123 1
1052	Worm thrust bearing plate	1918-24					15	TT 22 1
1053	Worm thrust bearing retainer	1918-24					15	TT 111 1
1054	Worm thrust bear. retainer nut	1918-24						
1055	Worm thrust bear. retainer pin	1918-24		50			01	TT 112 1
1056	Brake shoe	1918-24		1 50	MH	TT	2814	2
1057	Brake shoe lining, each	1918-24		2 00			25	MH TT 58 4
1058	Brake shoe lining rivet	1918-24					10	doz. TT 68 40
1059	Brake shoe spring	1918-24					05	TT 67 2

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	No. Fac. Req. Model No.	No. per Car
			Lots of 10 per lot	Lots of 100 per lot	Each			
REAR AXLE—Continued								
1060	Brake shoe bolt	1918-24	\$8 00	\$0 10		TT	59	2
1060B	Brake shoe bolt nut	1918-24						
1061	Brake expander	1918-24			40	MH TT	61	2
1062	Brake expander lever	1918-24			15	MH TT	62	2
1064	Brake expander adj. collar	1918-24			15	TT	175	2
1065	Brake expander bushing	1918-24			10	TT	173	2
1066	Brake expander pin	1918-24			01	TT	7	2
1067	Brake expander link	1918-24			08	MH TT	176	4
1068	Brake expander link pin	1918-24			03	TT	177	8
1069	Brake rod	1918-24			30	MH TT	119	2
1070	Brake rod support—right	1918-24	\$0 60	5 00	10	TT	120	2
1071	Brake rod support—left	1918-24	60	5 00	10	TT	121	1
1072	Brake rod support bolt	1918-24			02	TT	7181	2
1072B	Brake rod support bolt nut	1918-24						
1073	Rear radius rod—right	1918-24			3 00	TT	152	1
1073B	Rear radius rod—left	1918-24			3 00	TT	158	1
1074	Rear radius rod bolt—front	1918-24		7 50	10	TT	84	1
1075	Rear radius rod bolt—rear	1918-24		7 50	10	TT	83	4
1075B	Rear radius rod bolt nut	1918-24						
1076	Universal joint bushing	1918-24			60	TT	69	1

SPRINGS

1077	Rear spring—right or left, each	1918-24			4 00	MH TT	333	2
1078	Spring left No. 1	1918-24	8 00		90	TT	334	2
1079	Spring leaf No. 2	1918-24	4 00		50	TT	362	2
1080	Spring leaf No. 3	1918-24	3 50		45	TT	363	2
1081	Spring leaf No. 4	1918-24	3 00		40	TT	364	2
1082	Spring leaf No. 5	1918-24	2 80		35	TT	365	2
1083	Spring leaf No. 6	1918-24	2 50		30	TT	366	2
1084	Spring leaf No. 7	1918-24	2 30		25	TT	367	2
1085	Spring leaf No. 8	1918-24			20	TT	368	2
1086	Spring leaf No. 9	1918-24			20	TT	331	2
1087	Spring bushing	1918-24			20	TT	332	2
1088	Spring clip	1918-24			45	TT	326	2
1089	Spring clip nut	1918-24			05	TT	327	2
1091	Spring clip plate	1918-24			20	TT	329	4
1092	Spring tie bolt	1918-24			15	TT	330	2
1093	Spring tie bolt nut	1918-24						
1094	Spring tie bolt cotter	1918-24			05	TT	328	2
1095	Spring clamp	1918-24			75	TT	375	2
1096	Spring clamp bolt	1918-24		2 00	03	TT	376	2
1096B	Spring clamp bolt nut	1918-24						
1097	Spring perch	1918-24			90	MH TT	2804	2
1098	Spring perch nut	1918-24						
1099	Spring perch cotter	1918-24						
1100	Spring perch bushing	1918-24			35	TT	172	2
1101	Spring perch bushing spacer	1918-24			05	TT	169	4
1102	Spring hanger assembly	1918-24			30	TT	91	4

WHEELS

1105B	Rear wheel—dem.—Kelsey	1919-24			17 50	TT	7698	2
1105C	Rear wheel—dem.—Hayes	1919-24			17 50	TT	7698B	2
1105D	Rear wheel—dem.—less rim and hub—Kelsey	1919-24			8 00	TT	2817AR	2
1105E	Rear wheel—dem.—less rim and hub—Hayes	1919-24			8 00	TT	2817BR	2
1106C	Dem. rim only—Hayes	1919-24			3 50	TT	8774B	2
1106D	Dem. rim only—Kelsey	1922-24			3 50	TT	8774C	2
1106E	Dem. rim retainer ring—Kelsey	1922-24			45	TT	178	2
1107B	Clamp and nut assy.—Kelsey	1919-24	1 00		15	TT	8807	12
1108B	Clamp bolt	1919-24	3 50		05	TT	8832	12
1109	Rear wheel complete, less tire	1918-24			16 50	TT	99	2
1109B	Rear wheel—solid tire design—less hub and tire	1919-24			12 25	TT	2816	2
1110	Rear wheel com., with solid tire	1918-24				TT	7645	2
1111	Rear hub	1918-24			2 25	TT	40	2
1112	Rear hub flange	1918-24			40	TT	149	2
1113	Rear hub brake drum	1918-24			1 25	TT	3	2
1114	Rear hub bolt	1918-24	40	3 50	05	TT	28	12
1114B	Rear hub bolt nut	1918-24		1 50	02	TT	29	12

*\$0.25 gross, \$0.75 per thousand.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	No. Fac. Req. Model No.	No. per Car
			Lots of 10 per lot	Lots of 100 per lot	Each			
WHEELS—Continued								
1116	Rear hub cap	1918-24			\$0 25	TT	150	2
1117	Rear hub key	1918-24			03	TT	26	2
1118	Rear hub felt	1918-24	\$0 75	\$5 50	10	TT	162	2
FRAME								
1119	Frame assembly	1918-24			25 00	MH TT	300	1
1120	Side member—right	1918-24			9 00	TT	301	1
1121	Side member—left	1918-24			9 00	TT	302	1
1122	Front cross member	1918-24			1 00	TT	303	1
1123	Rear cross member	1918-24			4 00	TT	304	1
1124	Front corner bracket—right	1918-24			15	TT	305	1
1125	Front corner bracket—left	1918-24			15	TT	306	1
1125B	Front end spacer—right	1918-24			15	TT	319	1
1125C	Front end spacer—left	1918-24			15	TT	318	1
1126	Rear cross member gusset plate	1918-24			25	TT	307	2
1127	Rear cross member reinforcement	1918-24			35	TT	325	2
TRANSMISSION CONTROL								
1133	Speed lever	1918-24			10	MH TT	862	1
1134	Control shaft with speed lever	1918-24			60	MH TT	1557	1

Reprinted, October, 1924

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

