

Ford

PRICE LIST

**of Parts and Accessories
FOR OWNERS**

USE GENUINE FORD PARTS

MANUFACTURED BY

Ford Motor Company

SOLD BY

**BRIGHTMOOR MOTOR SALES INC.
AUTHORIZED FORD DEALER**

Parts Price List Index

	Page
Ammeter.....	34
Axle (Front).....	7
Axle (Rear).....	4
Drive Shaft.....	6
Universal Joint.....	6
Battery Bracket and Parts.....	36
Battery (Ford).....	37
Body Parts.....	24
Body Brackets.....	24
Dash.....	24
Floor Boards.....	24
License Brackets.....	25
Carburetor.....	30
Ford Carburetor (Model "N. H.").....	30
Kingston Carburetor (Model "L-4").....	30
Carburetor Attachments.....	30
Coil (Ford Spark).....	32
Fenders.....	31
Fenders.....	31
Fender Bolts, Nuts and Brackets.....	32
Fender Irons.....	32
Frame.....	11
Gasoline Tank.....	12
Generator and Parts.....	36
Hood.....	29
Horn (Electric).....	38
Lamps (Electric Head).....	38
Lamps (Side and Tail).....	39
Magneto and Fly Wheel.....	17
Motor.....	12
Commutator.....	17
Crank Case and Cylinder Valve Cover.....	15
Crank Shaft and Cam Shaft.....	14
Cylinder.....	12
Piston and Connecting Rod.....	14
Valves, Push Rods, Exhaust and Inlet Manifold.....	15
Muffler.....	28
Paints and Polishies (Ford).....	38
Radiator Fan.....	27
Radiator—Thermo Syphon.....	27
Running Board and Shields.....	32
Spark Plugs.....	37
Specialties (Ford).....	37
Springs.....	25
Spring (Front).....	25
Spring (Rear).....	26

Prices Subject to Change Without Notice

Parts Price List Index—Continued

	Page
Starter Drive.....	34
Starter Parts.....	36
Starting Crank.....	26
Starting Motor and Parts.....	36
Steering Gear.....	22
Steering Gear Brackets.....	23
Steering Gear Throttle and Spark Rods.....	23
Steering Gear Tubing and Post.....	22
Steering Wheel and Gear Case.....	22
Switch.....	33
Tops.....	40
Roadster—1915-22.....	41
Roadster—1922-25.....	41
Roadster—1926.....	41
Touring—1915-22.....	40
Touring—1922-25.....	40
Touring—1926.....	40
Tools (Repair).....	37
Tools (Repair)—Truck.....	37
Transmission.....	18
Transmission Control.....	20
Transmission Cover.....	19
Clutch Release.....	20
Hand Brake.....	22
Pedals and Controller Shaft.....	21
Transmission Bands.....	20
Truck Parts.....	42
Axle (Rear).....	42
Brake Parts.....	44
Drive Shaft.....	43
Frame.....	47
Radius Rod.....	45
Spring (Front).....	45
Spring (Rear).....	45
Transmission Control.....	47
Wheels.....	46
Worm.....	43
Vaporizer.....	30
Wheels.....	7
Clincher.....	7
Demountable.....	7
Demountable—Balloon.....	8
Wire.....	9
Hubs and Parts.....	10
Rim and Rim Carrier.....	10
Windshields.....	40
Touring and Roadster—1915-22.....	40
Touring and Roadster—1922-25.....	40
Touring and Roadster—1926.....	40
Wiring.....	34

Prices Subject to Change Without Notice


PRICE LIST OF PARTS

FORD MODEL T 1909-1926

EFFECTIVE DECEMBER 1, 1926

Part No. Name of Part Year Each

Part No. Name of Part Year Each




REAR AXLE

2500...	Rear axle assembly	1909-25	\$50 00
2500B...	Rear axle assembly	1926	50 00
2501...	Axle housing—right	1915-25	8 00
2501B...	Axle housing—right	1926	8 00
2502...	Axle housing—left	1915-25	8 00
2502B...	Axle housing—left	1926	8 00
2503E...	Axle housing bolt	1913-26	03
2503F...	Axle housing bolt nut	1909-26	02
2504...	Rear axle case gasket	1919-26	03
2505...	Axle shaft	1912-26	1 40
2506...	Axle shaft washer	1909-26	02
2507...	Axle shaft nut	1909-26	05
2508...	Axle shaft roller bearing	1909-26	55
2509...	Axle shaft R. B. sleeve—R.	1909-26	15
2509B...	Axle shaft R. B. sleeve—L.	1909-26	15
2510 1/2...	Axle housing cap	1919-26	05
2510A...	Axle outer R. B. steel washer	1909-26	02
2510B...	Axle outer R. B. felt washer	1909-26	05
2511...	Rear axle oil retainer	1926	20
2511B...	Rear axle oil retainer washer	1926	05
2512C...	Diff. case—left	1914-26	1 50
2513C...	Diff. case—right	1914-26	90
2514B...	Diff. case stud	1915-21	05
2514C...	Diff. case bolt	1922-26	05
2515...	Diff. case stud nut	1909-26	02

Insist upon genuine Ford parts

REAR AXLE—Continued

2518...	Diff. drive gear	1909-26	\$2 50
2519...	Diff. drive gear screw	1909-26	03
2519A...	Diff. gear lock ring	1909-26	02
2520B...	Diff. gear	1909-26	1 00
2521B...	Diff. gear key	1911-25	05
2524C...	Diff. pinion	1915-26	35
2526B...	Diff. spider	1909-26	75
2528...	Diff. thrust washer	1909-26	20
2529...	Diff. thrust plate	1909-26	15
2531B...	Diff. thrust plate pin	1917-26	02
2532...	Diff. housing oil plug	1909-26	05
2545...	Rear axle grease cup	1909-26	10
2547...	Rear radius rod—right	1909-25	1 00
2547B...	Rear radius rod—left	1909-25	1 00
2547C...	Rear radius rod assy.—R.	1926	1 00
2547D...	Rear radius rod assy.—L.	1926	1 00
2548...	Radius rod nut	1909-26	05
2549...	Radius rod lock nut	1909-26	05
2550...	Radius rod lock washer	1909-26	02
2551...	Radius rod bolt	1909-26	05
2551B...	Radius rod bolt nut	1909-26	03
2557...	Hub cam shaft—right	1909-25	10
2557B...	Hub brake cam—R.	1926	50
2558...	Hub cam shaft—left	1909-25	10
2558B...	Hub brake cam—L.	1926	50
2559...	Hub brake cam bushing	1909-26	05
2559C...	Hub brake cam bushing	1926	10
2560...	Axle brake housing cover assy.—right	1926	40
2561...	Axle brake housing cover assy.—left	1926	40
2562...	Cam shaft lever	1909-25	10
2562B...	Hub brake cam lever	1926	10
2563...	Cam shaft lever pin	1909-25	01
2563B...	Hub brake cam lever pin (Order 3495)	1926	
2564...	Lever clevis pin	1909-26	02
2566...	Hub brake shoe	1909-25	35
2566B...	Hub brake band assy.	1926	1 25
2567D...	Hub brake band lining	1926	40
2567...	Brake shoe support bolt	1909-25	05
2568...	Brake shoe support nut (Order 2551B)	1909-25	
2570B...	Brake shoe coil spring	1913-25	02
2570C...	Hub brake band spring	1926	10




Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
----------	--------------	------	------

REAR AXLE—Continued

Part No.	Name of Part	Year	Each
UNIVERSAL JOINT			
2571	Universal joint assembly	1909-26	\$1 50
2577B	Univ. joint housing	1914-26	1 00
2578	Joint housing plug	1909-26	05
2579	Ball joint grease cup	1909-26	15
2580	Ball cap gasket	1909-26	05
DRIVE SHAFT			
2581	Drive shaft housing front bushing	1909-26	30
2582	D. S. tubing	1911-26	7 50
2583B	D. S. bearing housing	1920-26	1 40
2584B	D. S. R. B. cap screw	1912-26	05
2584D	D. S. R. B. cap screw lock washer	1912-26	doz. 05
2587	D. S. roller bearing	1911-26	60



2591	D. S. ball thrust collar	1911-26	20
2591B	D. S. thrust ball and retainer assy.	1920-26	20
2595B	D. S. only	1911-26	3 00
2596	D. S. sleeve	1911-26	50
2597B	D. S. pinion	1911-26	1 25
2597C	D. S. pinion	1911-26	1 25
2598	D. S. castle nut	1911-26	08
2598B	D. S. pinion key	1911-26	05



When ordered to replace malleable type housing also order 2-2591 and 1-2591B

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

FRONT AXLE

2691	Front axle only	1909-26	\$9 00
2694B	Spindle body—right	1911-25	1 40
2694C	Spindle body—R	1926	1 40
2695B	Spindle body—left	1911-25	1 40
2695C	Spindle body—L	1926	1 40
2696C	Spindle arm—right	1919-26	45
2696D	Spindle arm—left	1919-26	45
2697	Spindle arm nut (Order 2548)	1911-26	15
2704	Stationary cone	1909-25	15
2705	Adj. cone—right thread	1909-25	15
2706	Adj. cone—left thread	1909-25	15
2707	Spindle nut—right thread	1909-26	05
2708	Spindle nut—left thread	1909-26	05
2709	Spindle washer	1909-26	02
2710	Spindle bolt with oiler	1910-26	20
2711	Spindle bolt nut (Order 2551B)	1909-26	20
2713	Spindle body bushing (pair)	1909-26	05
2715D	Spindle oiler (Order 3176C)	1919-26	1 50
2717	Spindle con. rod	1909-26	15
2718	Spindle con. rod bolt with oiler	1909-26	20
2719	Spindle con. rod bolt nut	1919-26	02
2721B	Spindle con. rod yoke ball	1919-26	40
2721C	Spindle con. rod yoke	1909-25	80
2725B	Steering gear con. rod	1926	80
2725C	Steering gear con. rod	1909-26	15
2728	Ball socket cap	1909-26	15
2729B	Ball socket bolt and nut (Order 3362 and 2515)	1909-26	1 50
*2733B	Front radius rod	1919-26	15
2736	Front radius rod ball cap	1909-26	30
2737	Front radius rod ball socket	1911-24	30
2737B	Front radius rod ball socket	1924-26	05
2741	Radius rod ball cap stud	1911-26	05
2741B	Radius rod ball cap stud nut (Order 2515)	1911-26	03
2742	Radius rod ball cap spring	1911-26	03

WHEELS

WHEELS (Clincher)

2800	Front wheel—clincher	1909-25	6 00
2800D	Front wheel—clincher—less hub	1909-26	4 00
2800A1	Front wheel—clincher—30 x 3 1/2"	1926	6 00
2814C	Rear wheel—clincher	1912-25	6 00
2814C2	Rear wheel—clincher—11" brake drum	1926	6 50
2814D	Rear wheel—clincher—less hub	1909-26	4 00

WHEELS (Demountable)

†2800B	Front wheel—dem. less rim	1919-24	5 50
‡2800C	Front wheel—dem. less rim	1919-24	5 50
§2800G	Front wheel—dem. less rim	1919-26	5 50
‡2800E	Front and rear wheel—dem. less rim and hub	1919-24	3 50

*Substitute 2733B with spring perches for 2733.

†Use with 2845 rim ‡Use with 2845C or 2845D rim.

§Use with attached clamp rim.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

WHEELS—Continued

WHEELS (Demountable)—Continued

‡2800F...	Front and rear wheel—dem. less rim and hub.....	1922-23	\$3 50
§2800H...	Front and rear wheel—dem. less rim and hub.....	1924-25	3 50
§2801B...	Front wheel complete R. or L.—dem.....	1919-26	7 30
§2814F...	Rear wheel complete—dem.—8" brake drum.....	1919-25	7 00
§2814F2...	Rear wheel complete—dem.—11" brake drum.....	1926	7 00
‡2814G...	Rear wheel—dem. less rim—8" brake drum.....	1919-24	5 50
‡2814H...	Rear wheel—dem. less rim—8" brake drum.....	1922-23	5 50
§2814K...	Rear wheel—dem. less rim—8" brake drum.....	1924-26	5 50
§2814K2...	Rear wheel—dem. less rim—11" brake drum.....	1926	5 50

WHEELS (Balloon Demountable)

2800I...	Frt. wheel, balloon—with hub less rim—black.....	1926	5 50
2800J...	Frt. wheel, balloon—with hub less rim—natural.....	1926	5 50
2800K...	Frt. and rear wheel—balloon—less rim and hub—black.....	1926	3 50
2800L...	Frt. and rear wheel—balloon—less rim and hub—natural.....	1926	3 50
2801D...	Front wheel complete—balloon—black.....	1926	7 00
2801E...	Front wheel complete—balloon—natural.....	1926	7 00
2814L...	Rear wheel complete—balloon—black—8" brake drum.....	1925	7 00
2814L2...	Rear wheel complete—balloon—black—11" brake drum.....	1926	7 00
2814M...	Rear wheel complete—balloon—natural—8" brake drum.....	1925	7 00
2814M2...	Rear wheel complete—balloon—natural—11" brake drum.....	1926	7 00
2814N...	Rear wheel—balloon—with hub less rim—black—8" brake drum.....	1925	5 50
2814N2...	Rear wheel—balloon—with hub less rim—black—11" brake drum.....	1926	5 50
2814P...	Rear wheel—balloon—with hub less rim—natural—8" brake drum.....	1925	5 50
2814P2...	Rear wheel—balloon—with hub less rim—natural—11" brake drum.....	1926	5 50

†Use with 2845 rim.

‡Use with 2845C or 2845D rim.

§Use with attached clamp rim.


Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

WHEELS—Continued


WHEELS (wire)

2880...	Wire wheels, set of 5—specify Black, Red, Green or Straw color.....	1926	\$35 00
2881...	Wire wheel, less hub—specify Black, Red, Green or Straw color.....	1926	7 00



2882...	Front hub with bolts, including R. B. cups.....	1926	3 00
2883...	Front hub bolt.....	1926	05
2884...	Front and rear hub bolt nut.....	1926	15
2885...	Front and rear hub cap.....	1926	30
2886...	Front hub grease retainer.....	1926	10
2887...	Rear hub and brake drum with bolts.....	1926	3 50
2888...	Rear hub bolt.....	1926	05
2889...	Hub brake drum.....	1926	75
2890...	Wire wheel locking nut.....	1926	30

Wire wheel socket wrench (Order 5Z161)



Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

WHEELS—Continued

HUBS AND PARTS

2803B...	Front hub with R B cups.....	1909-26	\$1 60
2804...	Outer race.....	1909-25	10
2805...	Inner race.....	1909-25	15
2806...	Outer ball retainer.....	1909-25	02
2807...	Inner ball retainer.....	1909-25	03
2808...	Dust ring.....	1909-26	03
2809...	Front and rear hub felt washer.....	1909-26	05
2810...	Large balls.....	1909-25	04
2811...	Small balls.....	1909-25	03
2815C...	REAR HUB.....	1912-26	1 25
2816B...	Rear hub key.....	1912-26	03
2818...	Hub brake drum—8".....	1909-25	40
2818B...	Hub brake drum—11".....	1926	75
2819...	Hub cap.....	1909-26	10
2825...	Rear hub bolt.....	1911-26	03
2825B...	Hub bolt nut.....	1911-26	02
2826...	Front hub bolt.....	1911-26	03
2827...	Hub flange.....	1911-26	20
2833...	Front hub bearing cup—inner.....	1919-26	50
2834...	Inside cone and roller assy.....	1919-26	1 10
2836...	Front hub bearing cup—outer.....	1919-26	40
2837...	Outside cone and roller assy.— right thread.....	1919-26	75
2838...	Outside cone and roller assy.— left thread.....	1919-26	75
2841...	Front hub dust cap assy.....	1919-26	10



RIM AND RIM CARRIER

2845...	Demountable rim only.....	1919-24	1 50
2845B...	Demountable rim only.....	1919-26	1 50
2845C...	Demountable rim only.....	1922	1 50
2845D...	Demountable rim only.....	1923	1 50
2845E...	Demountable rim only—balloon.....	1926	1 50
§2846B...	Demountable rim clamp.....	1919-24	10
†2846C...	Dem. rim clamp and nut assy.....	1922	15
*2846D...	Dem. rim clamp.....	1923	10
2847...	Demountable rim bolt.....	1919-26	05
*2848...	Dem. rim nut.....	1919-26	05
†2848B...	Dem. rim nut.....	1919-25	05
2849...	Spare rim carrier.....	1919-25	2 25
2849B...	Spare rim carrier clamp bolt.....	1921-25	02
†2849B2...	Spare rim carrier clamp bolt.....	1925-26	02
§2849B3...	Spare rim carrier clamp bolt.....	1926	02

*Use with 2845B, 2845D and 2845E rim. †Use with 2845C rim.
 ‡Use with 2845 rim. §Use with 2845 rim.
 **Use with 2845D rim.
 ††Square shoulder. §§Round shoulder.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------


WHEELS—Continued

RIM AND RIM CARRIER—Continued

2849C...	Spare rim carrier clamp support and bolt assy.....	1921-24	\$0 15
2849G...	Spare rim carrier clamp support and bolt assy.....	1924-25	15
2849D...	Spare rim carrier clamp.....	1921-25	10
2849E...	Spare rim carrier—balloon.....	1925	2 25
2849F...	Spare rim carrier clamp.....	1925-26	10
2870...	Spare rim carrier bracket—R.....	1919-22	50
2870B...	Spare rim carrier bracket—R.....	1922-25	50
†2870C...	Spare rim carrier bracket—L.....	1925	50
2871...	Spare rim carrier bracket—L.....	1919-22	50
2871B...	Spare rim carrier bracket—L.....	1922-25	50
†2871C...	Spare rim carrier bracket—L.....	1925	50
2872...	Spare rim bracket and bolt assy.— Road.—Cp.....	1926	1 50
2872B...	Spare rim bracket and bolt assy.— T. C.—Tudor—Fordor.....	1926	2 75
2873...	Spare rim carrier only—balloon.....	1926	1 25
2874...	Spare rim carrier only—30" x 3 1/2".....	1926	1 25
2875...	Spare rim carrier bolt (Order 2883).....	1926	10
2875B...	Spare rim carrier bolt.....	1926	10
2876...	Spare rim carrier bolt nut.....	1926	05

FRAME

2850...	Frame assembly.....	1909-25	13 00
2850B...	Frame assembly.....	1926	13 00
2851B...	Side member—right.....	1914-25	4 00
2851C...	Side member—R.....	1926	4 00
2852B...	Side member—left.....	1914-25	4 00
2852C...	Side member—L.....	1926	4 00
2853...	Front cross member.....	1909-26	90
2854B...	Rear cross member.....	1914-25	1 20
2854C...	Rear cross member.....	1926	2 00
2863...	Body bracket.....	1909-26	10



††For balloon rim carrier.

Insist upon genuine Ford parts

Part No. Name of Part Year Each

GASOLINE TANK

2900B...	Gas tank—Sedan.....	1916-25	\$6 00
2900C...	Gasoline tank.....	1909-25	4 00
2900D...	Gas tank—Road.—T. C.—Cp.—		
	Tudor.....	1926	6 00
2901B...	Filling plug.....	1909-26	15
2902B...	Sediment bulb.....	1909-26	90
2902C...	Sediment bulb assy.—Road.—T. C.—Cp.—Tudor.....	1926	1 00
2903...	Filling plug gasket.....	1909-26	02
2908...	Pet cock (Order 3079).....	1909-25	
2908B...	Sediment bulb drain plug assy.—Road.—T. C.—Cp.—Tudor (Order 6216).....	1926	
2909...	Feed pipe—5 1/4".....	1909-26	25
2909B...	Feed pipe—5 1/4".....	1916-23	30
2909C...	Feed pipe—6 1/2".....	1918-19	35
2909D...	Feed pipe—5 6 1/2".....	1919-25	35
2909E...	Feed pipe—4 9 1/4".....	1923-25	30
2909F...	Gas feed pipe—Road.—T. C.—Cp.—Tudor.....	1926	20
2910...	Feed pipe pack nut.....	1909-26	05
2913...	Feed pipe gasket.....	1909-26	02
2914B...	Gas tank support—R.....	1920-26	20
2915B...	Gas tank support—L.....	1920-26	20
2916...	Feed pipe clamp.....	1921-26	01
2917...	Gas tank pad—upper—Road.—T. C.—Cp.—Tudor.....	1926	05
2918...	Gas tank pad front—Road.—T. C.—Cp.—Tudor.....	1925	30
2919...	Gas tank support pad—Road.—T. C.—Cp.—Tudor.....	1926	10
2920...	Stop and pad assy., Road.—T. C.—Cp.—Tudor.....	1926	75
2921...	Gas tank overflow pipe—Road.—T. C.—Cp.—Tudor.....	1926	25
2922...	Gas tank support and pad assy.....	1926	50


MOTOR

CYLINDER

2990B...	Motor assembly—less starter.....	1909-26	100 09
2990C...	Motor assembly with starter.....	1919-26	125 03
2991...	Cylinder assembly—oversize.....	1909-26	45 09
2991B...	Cylinder assembly—std.....	1909-26	60 60
3000C...	Cylinder.....	1909-26	20 00
3001...	Cylinder head.....	1909-26	5 00
3002...	Cylinder head gasket.....	1909-26	25
3003...	Cylinder head cap screw.....	1909-17	05
3003B...	Cylinder head cap screw.....	1918-26	05
3004B...	Cylinder head outlet conn.....	1917-25	35
3004E...	Cylinder head outlet conn.....	1926	75
3005...	Cylinder head outlet conn. gskt.....	1909-26	03
3006...	Cylinder head outlet hose.....	1909-26	15
3007...	Cylinder head outlet hose clip.....	1909-26	05
3008...	Cylinder head outlet conn. screw.....	1909-26	05
3009C...	Cylinder front cover.....	1919-26	1 00

Insist upon genuine Ford parts


Part No. Name of Part Year Each



MOTOR—Continued

CYLINDER—Continued

3009D...	Cylinder front cover.....	1926	\$1 00
3010...	Cylinder cover bolt and nut (Order 4808 and 2515).....	1909-26	
3011...	Cylinder cover cap screw.....	1909-26	03
3011B...	Cylinder cover to cylinder screw.....	1926	03
3012B...	Cylinder cover gasket.....	1909-26	05
3013B...	Cylinder cover liner.....	1919-26	02
3014...	Cylinder cover and crank case bolt and nut (Order 3362 and 2515).....	1909-26	
3015...	Cylinder water inlet conn.....	1909-26	30
3016...	Cylinder inlet conn. screw.....	1909-26	03
3017...	Time gear cover.....	1919-26	90
3017C...	Time gear cover gasket.....	1919-26	01
3017D...	Time gear cover plate.....	1919-26	05
3017E...	Time gear cover to C. C. screw.....	1919-26	03
3018...	Cylinder water inlet gasket.....	1909-26	03
3019B...	Cylinder water jacket plug.....	1914-26	02




Insist upon genuine Ford parts

Part No. Name of Part Year Each

MOTOR—Continued

PISTON AND CONNECTING ROD

3021R.	Piston and pin (2 lbs.)	1909-26	\$1 25
3021S.	Piston and pin—.0025" O. S. (2 lbs.)	1909-26	1 25
3021T.	Piston and pin—.005" O. S. (2 lbs.)	1909-26	1 25
3021U.	Piston and pin—.03125" O. S. (2 lbs.)	1909-26	1 25
3021V.	Piston and pin—.033" O. S. (2 lbs.)	1909-26	1 25
3021W.	Piston and pin—.010" O. S. (2 lbs.)	1909-26	1 25
3022.	Piston pin.	1909-26	30
*3022½.	Piston pin bushing (pair)	1909-23	20
††3022C.	Piston pin bushing (pair)	1923-26	20
3023.	Piston ring.	1909-26	15
3023B.	Piston ring .031" O. S.	1909-26	15
3023C.	Piston ring .010" O. S.	1909-26	15
3023D.	Piston ring .038" O. S.	1909-26	15
††3024.	CONNECTING ROD	1909-26	1 20
3025.	Connecting rod cap bolt.	1909-26	05
3026.	Connecting rod cap bolt nut.	1909-26	03
3029.	Connecting rod clamp screw.	1909-26	03
CRANK SHAFT AND CAM SHAFT			
3030.	CRANK SHAFT.	1909-26	8 50
3031.	C. S. rear bearing cap.	1909-26	50
3032.	C. S. front bearing cap.	1909-26	40
3033.	C. S. center bearing cap.	1909-26	40
3034.	C. S. bearing bolt—center and front.	1909-26	10
3035.	C. S. bearing bolt nut (Order 2551B).	1909-26	10
3036.	C. S. rear bearing bolt.	1909-26	01
3038.	C. S. bearing liner—center and front.	1909-26	01
3039.	C. S. rear bearing liner.	1909-26	01
3040B.	C. S. starting pin.	1920-26	03



3041.	CAM SHAFT	1909-26	3 00
3042.	Cam shaft front bearing.	1909-24	40
3042B.	Cam shaft front bearing.	1924-26	40

††Connecting rods of present design requiring new bearings will be exchanged by dealers at 60c each. *O. D. .934". ††O. D. .872".


Insist upon genuine Ford parts

Part No. Name of Part Year Each

MOTOR—Continued

CRANK SHAFT AND CAM SHAFT—Continued

3043.	Cam shaft center bearing.	1909-26	\$0 40
3044.	Cam shaft rear bearing.	1909-26	15
3045.	Cam shaft bearing ring.	1909-26	03
3046.	Cam shaft bearing set screw.	1909-26	05
3047B.	Time gear—large.	1909-26	75
3048B.	Time gear—small.	1909-26	60
3049.	Cam shaft gear dowel pin.	1909-26	03
3050B.	Cam shaft gear lock nut.	1909-26	15
3051.	Small time gear key.	1909-26	03



VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS

3052.	Valve.	1909-26	15
3052B.	Valve— $\frac{1}{8}$ " O. S. stem.	1909-26	15
3053½.	Valve bushing.	1909-26	25
3054.	Valve spring.	1909-26	05
3056.	Valve spring seat.	1909-26	Set 05
3057.	Valve spring seat pin.	1909-26	of 8 05
3058.	Push rod.	1909-26	15
3058B.	Push rod— $\frac{1}{8}$ " O. S. stem.	1909-26	15
3059½.	Push rod bushing.	1909-26	25
3060B.	Exhaust manifold.	1913-26	1 25
3061.	Exhaust pipe pack nut.	1909-26	20
3062.	Inlet pipe.	1909-26	1 00
3063.	Inlet and exhaust pipe gasket.	1909-26	02
3064.	Inlet and exhaust pipe gland.	1909-26	01
3065.	Inlet and exhaust pipe clamp.	1909-26	10
3066B.	Inlet and exhaust clamp stud nut.	1909-26	03
*3066C.	Inlet and exhaust clamp stud— $2\frac{3}{8}$ ".	1924-26	05
3068.	Breather pipe.	1909-26	10


CRANK CASE AND CYLINDER VALVE COVER

3069C.	C. C. front end support.	1917-24	75
3069D.	C. C. front end support.	1924-26	75
3070B.	C. C. and cyl. gasket—L.	1909-26	03
3071B.	C. C. and cyl. gasket—R.	1909-26	03
3072.	C. C. and cyl. cover cap screw.	1909-26	03

*When used to replace stud $3\frac{1}{8}$ " long also use new style 3065 clamp, reversing clamp.

Insist upon genuine Ford parts

Part No. Name of Part Year Each



MOTOR—Continued

Part No.	Name of Part	Year	Each
3073	C. C. arm bolt—side	1909-26	\$0 05
3074	C. C. arm bolt—top	1909-26	03
3074B	C. C. arm bolt nut (Order 2515)	1909-26	
3074C	C. C. arm bolt—top (Truck)	1918-26	03
3075C	C. C. front bearing and spring clip assy.	1921-26	90
3076C	C. C. front bearing and spring clip nut (Order 2548)	1921-26	
3076B2	C. C. front bearing and spring clip	1921-26	70
3077	C. C. front bearing cap	1909-26	15
3078	C. C. front bearing screw	1909-21	05
3078B	C. C. front bearing screw (Order 3008)	1921-26	
3078C	C. C. front bearing lock washer	1921-26	01
3079	C. C. oil cock	1909-26	15
3080	C. C. drain cup plug (Order 2532)	1909-26	
3080B	C. C. drain cup plug gasket	1909-26	02

†Replaces 3075B.

††Replaces 3076B. When ordered to replace 1909-20 C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664, 1-3810, 2-753 cotter.


Insist upon genuine Ford parts

Part No. Name of Part Year Each

MOTOR—Continued

CRANK CASE AND CYLINDER VALVE COVER—Contd.

3081	C. C. oil tube	1909-26	\$0 20
3083	C. C. arm block	1909-26	05
3084	Engine pan—right	1909-26	30
3085	Engine pan—left	1909-26	30
3088B	Engine pan and hood board bolt	1909-26	03
3088C	Engine pan and hood board bolt	1909-26	03
3088D	Engine pan and hood board bolt—Truck	1918-26	03
3088E	Engine pan and hood board bolt nut	1909-26	01
3100	CRANK CASE	1912-25	11 00
3101	Crank case lower cover	1912-24	35
3101B	Crank case lower cover reinforcement	1912-24	25
3101C	C. C. lower cover	1924-26	35
3101D	C. C. lower cover reinforcement	1924-26	25
3102B	C. C. lower cover gasket	1912-24	10
3102C	C. C. lower cover gasket	1924-26	10
3103	C. C. lower cover screw	1912-26	02
3110B	Cylinder valve cover	1921-26	20
3111C	Cylinder valve cover gasket	1921-26	05



3112	Cylinder valve cover screw	1912-26	03
3114	C. C. arm with rivets	1909-26	30
COMMUTATOR			
3162B	Com. case support bolt	1919-26	05
3163	Com. case spring	1912-26	05
3165	Com. brush only	1912-26	20
3210	Com. contact point nut	1910-26	01
3220	Com. lock nut	1909-26	03
3221	Com. case with fibre	1912-26	60


MAGNETO AND FLY WHEEL

3250D	Magneto coil assembly	1915-26	6 00
3252	Magneto spool support screw (Order 3371)	1909-26	
3254	Magnet bolt	1909-26	03
3255	Magnet bolt washer	1911-26	01
3257	Magnet support	1909-26	05
3260	Magneto contact assy.	1909-25	20
**3260B	Magneto contact assy.	1926	30
3261B	Magneto contact nut	1909-26	01
3263	Magneto contact spacer	1909-25	15
3268	Fly wheel ring gear	1919-26	90

**Same as S-303. When used to replace 3260 also purchase 3263.


Insist upon genuine Ford parts

Part No. Name of Part Year Each



MAGNETO AND FLY WHEEL—Continued

3269H.. Fly wheel with ring gear and magnets assembled.....	1919-26	\$15 00
3270... Fly wheel cap screw.....	1909-26	10
3276B... Magnets (16).....	1915-26 set 4	00
3277... Magnet clamp.....	1911-26	03
3278... Magnet clamp screw.....	1911-26	02



TRANSMISSION


3300B.. Transmission assy.....	1919-25	30 00
3300C.. Transmission assy.....	1926	30 00
3301... Trans. reverse plate assy.....	1909-26	2 40
3304... Trans. reverse gear bushing.....	1909-26	40
3305... Trans. reverse and S. S. rivet.....	1909-26 doz.	05

Insist upon genuine Ford parts

Part No. Name of Part Year Each

TRANSMISSION—Continued

3306... Trans. slow speed plate assy.....	1909-26	\$2 30
3309... Trans. slow speed gear bushing.....	1909-26	30
3311... Trans. brake drum assy.....	1909-25	2 60
3311B.. Trans. brake drum assy.....	1926	3 00
3312... Trans. brake drum lug shoe.....	1926	05
3313... Trans. triple gear assy.....	1909-26	1 40
3314 1/2. Trans. triple gear flanged bushing.....	1911-26	20
3317... Trans. driven gear.....	1909-26	70
3318... Trans. driven gear key.....	1909-26	03
3320C.. Trans. driven gear sleeve bushing.....	1909-26	20
3320D.. Driven gear sleeve washer.....	1909-26	05
3321... Trans. driving plate assy.....	1909-25	3 25
3321B.. Trans. driving plate assy.....	1926	3 25
3323... Trans. driving plate screw (Order 3371).....	1909-25	
3323B.. Trans. driving plate screw.....	1926	05
*3327B.. Trans. driving plate bushing.....	1909-26	15
3328... Trans. clutch disc—small.....	1909-26	10
3329... Trans. clutch disc—large.....	1909-26	10
3331... Trans. gear shaft.....	1909-26	1 25
3332... Trans. clutch disc drum.....	1909-26	1 10
3333... Trans. clutch disc drum key.....	1909-26	05
3334... Trans. clutch disc drum set screw.....	1909-26	10
3336... Trans. clutch push ring.....	1909-26	35
3337B.. Trans. clutch finger and screw.....	1909-25	20
3337D.. Clutch finger and screw.....	1926	20
3338... Trans. clutch finger pin.....	1909-25	01
3338B.. Trans. clutch finger pin.....	1926	01
3340... Trans. clutch spring.....	1909-26	25
3341... Trans. clutch spring support.....	1909-26	10
3342... Trans. clutch spring thrust ring pin.....	1909-26	03
3344... Trans. clutch shift.....	1909-26	50




TRANSMISSION COVER

3362... Trans. cover bolt.....	1909-26	03
3362B.. Trans. cover bolt nut (Order 2515).....	1909-26	

*When using short bushing in making repairs remove driving plate key.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
TRANSMISSION COVER—Continued			
3363...	Trans. cover gasket (front)	1909-26	\$0 05
3367...	Trans. cover door screw	1909-26	02
3368...	Universal ball cap (rear)	1909-26	30
3369...	Universal ball cap (front)	1909-26	89
3371...	Universal ball cap screw	1909-26	05
3372...	Universal ball cap bolt and nut (Order 3362 and 2515)	1909-26	
3375...	Trans. cover screw (Order 3072)	1909-26	
13376B...	TRANS. COVER	1919-25	7 00
3376C...	Trans. cover	1926	7 00
3377B...	Trans. cover gasket	1909-26	pr. 10
3378...	Trans. cover door	1911-26	15
3379B...	Trans. cover door gasket	1911-26	05
3380...	Starter drive cover	1919-26	15
3381...	Starter drive cover gasket	1919-26	03
3382...	Trans. cover rear plate	1919-26	05
3383...	Trans. cover front plate	1919-26	05
3384...	Trans. cover to cylinder screw	1926	05




TRANSMISSION CONTROL

CLUTCH RELEASE			
3400...	Trans. clutch release ring	1909-26	20
3402D...	Clutch lever and shaft	1913-26	30
3403...	Clutch lever screw (Order 3973)	1909-26	
3403B...	Clutch lever screw nut (Order 3066B)	1909-26	
3405...	Clutch lever pin	1909-26	01
3406B...	Clutch release fork—R. or L.	1913-26	15
3406C...	Clutch release fork pin (Order 3405)	1913-26	
3411...	Clutch lever clevis pin (Order 2564)	1909-26	
TRANSMISSION BANDS			
3413B...	Trans. band assy. (detach)	1909-26	60
3413C...	Trans. brake band assy.	1926	90
3415...	Trans. band washer	1909-26	03
3416...	Trans. band lining	1909-26	25
3416B...	Trans. band lining—set of 3 including rivets—in carton	1909-25	90
3416C...	Trans. brake band lining	1926	35
3416D...	Trans. band lining—set of 3 including rivets—in carton	1926	1 00
3419...	Trans. band adj. screw	1909-25	15

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.


Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
TRANSMISSION CONTROL—Continued			
TRANSMISSION BANDS—Continued			
*3419B...	Trans. band adj. screw	1926	\$0 15
3420...	Trans. band adj. screw nut	1909-26	05
3423B...	Trans. band brass rivet	1909-26	doz. 05
3425...	Trans. band spring	1909-26	03
3426...	Trans. band adj. nut	1909-26	05



PEDALS AND CONTROLLER SHAFT

3427...	Slow speed shaft	1909-25	15
*3427B...	Slow speed shaft	1926	15
3428...	Slow speed notch	1909-26	25
3429...	Slow speed notch pin	1909-26	01
3432...	Speed lever	1909-26	10
3434...	Reverse pedal	1909-25	50
3435...	Brake and reverse pedal shaft	1909-26	15
3436...	Brake and reverse pedal support	1909-26	15
3437...	Brake and reverse support bolt	1909-25	05
3437B...	Brake and reverse support bolt nut (Order 2515)	1909-26	
3437C...	Brake and reverse pedal support bolt	1926	05
3439...	Brake pedal	1909-25	50
3439B...	Brake pedal	1926	65
3440...	Clutch pedal	1909-25	50
3440B...	Clutch pedal	1926	65
3441...	Pedal pin (Order 3405)	1909-26	
3442...	Clutch pedal support	1909-26	15
3443...	Clutch pedal support bolt	1909-26	05
3443B...	Clutch pedal support bolt nut (Order 2515)	1909-26	
3445...	Slow speed connection	1909-26	05
3446...	Slow speed con. lock nut (Order 2503F)	1909-26	
3447...	Slow speed con. clevis	1909-26	10



*Used with detachable ear band.

Insist upon genuine Ford parts

Part No. Name of Part Year Each


TRANSMISSION CONTROL—Continued

PEDALS AND CONTROLLER SHAFT—Continued

3448	Controller quadrant	1909-26	\$0 20
3449	Con. shaft with speed lever	1909-26	60
3450	Controller shaft bracket	1909-26	15
3452	Controller shaft bracket bolt	1909-26	03
3452B	Controller shaft bracket bolt nut	1909-26	02

HAND BRAKE

3455	Hand brake lever	1909-25	1 00
3456B	Hand brake lever pin (Order 2574)	1909-26	
3458	Hand brake lever pawl	1909-26	05
3459	Hand brake lever pawl pin	1909-26	01
3460	Hand brake lever pawl rod	1909-26	10
3462	Hand brake lever pawl lift assembly	1909-26	10
3463	Hand brake lever pawl lift spring	1909-26	02
3465	Hub brake lever	1909-26	15
3466	Hub brake lever pin (Order 3405)	1909-26	
3467	Hub brake lever clevis (Order 3447)	1909-26	
3468	Hub brake pull rod—R.	1909-25	30
3468C	Brake rod assembly—R. and L.	1926	30
3469	Hub brake pull rod—L.	1909-25	30
3470	Brake rod support—R.	1909-26	10
3471	Brake rod support—L.	1909-26	10
3472	Brake rod support bolt	1909-26	01
3472B	Brake rod support bolt nut (Order 3088E)	1909-26	



STEERING GEAR

STEERING WHEEL AND GEAR CASE

3500D	Steering gear assembly (5 to 1)	1926	10 00
3502	Steering gear rim screw	1909-26	01
3503F	Steering gear spider and rim (17")	1926	2 25
3504	Steering gear cover	1909-26	30
3505	Steering gear cover screw	1909-26	01
3507	Steering gear internal gear case and bushing	1909-26	1 25
3509	Steering gear quadrant	1909-26	15
3511	Steering gear wheel nut	1909-26	10

STEERING GEAR TUBING AND POST

3512C	Steering gear tubing assy.	1912-26	4 00
3513C	Steering tubing flange screw	1913-26	03
3514	Steering tubing flange screw nut	1913-26	02

Insist upon genuine Ford parts


Part No. Name of Part Year Each



STEERING GEAR—Continued

STEERING GEAR TUBING AND POST—Continued

3516D	Steering gear post	1921-26	\$1 75
3516E	Steering gear post (5 to 1)	1926	1 75
3517	Steering gear pinion	1909-25	15
3517B	Steering gear pinion (5 to 1)	1926	15
3519	Steering gear drive pinion	1909-25	30
3519B	Steering gear drive pinion assy. (5 to 1)	1926	45
3520	Steering gear drive pinion key	1909-26	03
3523	Steering gear post castle nut (Order 2551B)	1909-26	




STEERING GEAR THROTTLE AND SPARK RODS

3524E	Throttle rod	1912-26	30
3525E	Spark rod	1912-26	30
3527	Spark and throttle rod spring	1909-26	02
3528	Spark and throttle rod collar	1909-26	02
3529	Spark and throttle rod pin	1909-26	01
3530	Spark rod lever	1909-26	10
3531	Throttle rod lever	1909-26	10
3532	Spark and throttle rod guide	1909-26	05
3534B	Commutator pull rod	1912-25	10
3534C	Commutator pull rod	1926	10
3535	Carburetor pull rod	1909-25	10
3535B	Carb. pull rod—Road—T. C.—Cp.—Tudor	1926	10
3535C	Carb. pull rod—Fordor—Chassis	1926	10

STEERING GEAR BRACKET

3539B	Steering bracket with bushing	1911-25	75
-------	-------------------------------	---------	----



Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
STEERING GEAR—Continued			
STEERING GEAR BRACKET—Continued			
3539C...	Steering bracket with bushing—truck	1918-26	50 75
3539D...	Steering gear bracket assy.—Road.—T. C.—Op.—Tudor	1926	75
3539E...	Steering gear bracket assy.—Fordor—Chassis	1926	75
3544...	Steering bracket felt washer	1909-26	02
3545...	Steering bracket bushing	1909-21	10
3545B...	Steering bracket bushing	1921-26	20
3546...	Steering bracket block	1909-25	10
3546C...	Steering gear bracket block	1926	10
3547...	Steering gear ball arm	1909-26	40
3548...	Steering gear ball arm key	1909-26	03

BODY BRACKETS BODY PARTS

3601B...	Body bracket on body	1910-26	10
3601C...	Body bracket—front—R.	1921-26	20
3601D...	Body bracket—front—L.	1921-26	20
3601E...	Body bracket—rear	1913-26	05
3601F...	Body bracket—rear—R.	1921-26	20
3601G...	Body bracket—rear—L.	1921-26	20
3602E...	Body bracket con. bolt	1916-26	03
3602F...	Body bracket con. bolt nut (Order 2719)	1916-26	

FLOOR BOARDS

3624E...	Front floor rubber mat	1915-24	90
3624F...	Front floor rubber mat	1924-25	90
3624G...	Floor board rubber mat and weather-strip assy.	1926	1 50
3676C...	Rear floor rubber mat	1911-25	60
3626C...	Floor board with plate (first)	1915-25	50
3627C...	Floor board with plate (second)	1915-25	50
3628B...	Floor board with plate (third)	1915-25	65
3630...	Floor board forward plate for pedals	1909-25	10
3632...	Floor board rear plate for pedals	1909-25	10
3633...	Floor board plate for side lever	1909-25	05

**DASH**

3634H...	Dash—steel	1917-23	3 00
3634J...	Dash—steel	1923-25	3 00
3638B...	Dash shield	1919-22	25
3639...	Dash weatherstrip—side	1917-22	05

Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
BODY PARTS—Continued			
DASH—Continued			
3639B...	Dash weatherstrip—top	1917-22	50 15
†3640C...	Dash bracket—left	1917-22	20
‡3640D...	Dash bracket—left	1923-26	15
†3641C...	Dash bracket—right	1917-22	20
‡3641D...	Dash bracket—right	1923-26	15
3642C...	Dash bracket to dash bolt	1917-22	03
	3514)		
3653B...	Dash to body bracket bolt	1915-25	03
3653C...	Dash to body bracket nut (Order 4805C)	1915-25	
3654...	Dash to body gasket	1918-25	05

LICENSE BRACKETS

‡3660E...	Lamp and license bracket support assembly	1923-25	75
3662...	Oil tail lamp and license bracket assy.—Road.—Pick-up	1926	45
3662B...	Oil tail lamp and license bracket assy.—T. C.	1926	75
3662C...	Tail lamp and license bracket support	1926	15
3662D...	Oil tail lamp and license bracket support	1923-26	30
3664...	Front license bracket	1921-26	15
**3664B...	Front license bracket	1926	15
‡3665...	Front license clip	1926	05

SPRINGS**FRONT SPRING**

3800...	Front spring—seven leaf	1909-25	2 25
‡3800B...	Front spring	1926	2 25
3808...	Front spring clip	1909-20	20
3809B...	Front spring clip nut	1921-26	05



3810...	Front spring clip bar	1921-26	25
†3811...	Front spring tie bolt	1909-25	04
‡3811C...	Front spring tie bolt	1926	05
3811B...	Front spring tie bolt nut	1909-26	02
3813B...	Front spring hanger	1909-26	20
3814...	Front spring hanger bar	1909-26	05

†When used on 1911-16 cars, redrill frame.

*Used with steel dash.

‡Used on touring car and roadster without starter and demountable rims. †Seven-leaf spring.

**Use with nine-leaf front spring.

‡‡Used on headlamp tie rod.


Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

SPRINGS—Continued


FRONT SPRING—Continued

3815	Spring hanger nut (Order 2719)	1909-26	
3818B	Front spring perch—right	1909-26	\$0 50
3819B	Front spring perch—left	1919-26	50
3820	Front spring perch bush	1909-26	05
3821B	Front spring perch nut	1921-26	05
3823	Front spring pad	1909-26	05



REAR SPRING

3824	REAR SPRING	1909-26	6 50
3824B	REAR SPRING	1922-26	6 75
3833	Rear spring clip	1909-26	20
3833B	Rear spring clip	1922-26	20
3834	Rear spring clip nut (Order 3809B)	1909-26	
3835	Rear spring clip bar	1909-26	10
3837	Rear spring tie bolt	1909-26	05
3837B	Rear spring tie bolt nut	1909-26	02
3838	Rear spring tie bolt	1922-26	05
3840B	Rear spring hanger	1909-26	25
3841	Rear spring hanger bar	1909-26	05
3842	Rear spring pad	1909-26	05
3843	Rear spring perch	1909-25	40
3843B	Rear spring perch	1926	40
3844	Rear spring perch bush	1909-26	05
3845	Rear spring perch nut	1909-25	05
3846	Spring perch oiler	1917-26	05
3847B	Front spring clamp assembly with bolt and nut	1916-26	10
3848B	Rear spring clamp assembly with bolt and nut	1918-26	10



STARTING CRANK

3905	Starting crank ratchet pin	1909-26	05
3906	Starting crank ratchet	1909-26	20
3908	Starting crank spring	1909-26	03
3910	Starting crank assembly	1909-26	40

†Use with 2501B or 2502B. †Eight-leaf spring.

*Nine-leaf spring for Sedan.

Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
----------	--------------	------	------

RADIATOR—THERMO SYPHON

3925B	Radiator	1917-23	\$16 00
3925C	Radiator—less shell	1917-23	15 00
3925D	Radiator	1923-26	14 00
3925E	Radiator—less shell	1923-26	13 00
3925F	Radiator with nickel shell	1926	16 00
3926	Radiator cap	1909-26	20
3927	Radiator cap gasket	1909-26	02
3928	Radiator pad	1909-19	05
3929B	Radiator stud	1919-25	05
3929B2	Radiator stud	1926	05
3929C	Radiator stud nut	1909-26	03
3930	Radiator stud spring (Order 2742)	1909-26	
3931	Radiator stud washer nut	1909-26	03
3932	Radiator rod	1909-23	15
3932B	Radiator rod	1923	15
3932C	Radiator rod	1923-25	15
3932D	Radiator rod	1926	15
3934	Radiator rod nut (Order 3066B)	1909-26	
3939	Outlet connection pipe	1909-26	25
3940	Outlet connection cock (Order 3079)	1909-26	
3944	Outlet connection hose	1909-26	10
3945	Outlet connection hose clip	1909-26	05
3947B	Radiator shell	1917-23	1 00
3947C	Radiator shell	1923-26	1 00
3947D	Radiator shell (nickel)	1926	3 00
3975	Radiator stud spring upper rhimble	1919-26	02
3976	Radiator stud spring lower rhimble	1919-26	03
3977	Radiator apron	1923-25	35
3977C	Rad. apron and finish strip assy.—Cp.—Tudor—Fordor	1926	75
3977D	Rad. apron finish strip—Cp.—Tudor—Fordor	1926	35
3977E	Radiator apron	1926	40

RADIATOR FAN

3960	Fan and pulley assembly	1909-20	1 25
3961C	Fan blade assembly	1920-26	25




Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

RADIATOR FAN—Continued

3962B...	Dr. fan pulley with bush.....	1920-26	\$3 70
3963...	Fan drive pulley.....	1909-20	30
3963B...	Fan drive pulley.....	1920-26	30
3964C...	Fan belt—26".....	1917-20	40
3964E...	Fan belt.....	1920-25	40
3964F...	Fan belt.....	1926	40
3966B...	Fan shaft.....	1920-25	20
3966C...	Fan shaft.....	1920-26	20
3967B...	Fan bracket.....	1917-25	30
3968...	Fan bracket bolt.....	1909-25	10
3970...	Fan grease cup.....	1909-19	10
3973...	Fan adjusting screw.....	1909-25	02
3973B...	Fan adjusting screw nut (Order 3066B).....	1909-25	
3973C...	Fan eccentric adj. bolt.....	1926	15
3973D...	Fan eccentric adj. bolt nut.....	1926	03
3974B...	Fan driven pulley bush.....	1920-26	15
3980...	Fan pulley plug.....	1920-26	03
3981...	Fan pulley gasket.....	1920-26	02
3982...	Fan shaft cap.....	1920-26	02
3983...	Fan shaft felt washer.....	1920-26	02
3984...	Fan blade screw.....	1920-26	01
3985...	Fan blade screw washer (Order 3261C).....	1920-26	
3986...	Fan shaft nut (Order 2719).....	1920-26	
3987B...	Fan eccentric.....	1926	25
3988...	Fan eccentric plate.....	1926	03




MUFFLER

4025B...	Muffler assembly.....	1909-26	2 50
4026C...	Muffler head—front.....	1921-26	10
4027...	Muffler shell—outer.....	1909-26	25
4028...	Muffler shell—middle.....	1909-26	20
4029...	Muffler shell—inner.....	1909-26	20
4032...	Muffler head retainer.....	1921-26	02
4033...	Muffler head retainer bolt and nut (Order 4819B and 3514).....	1921-26	
4035...	Muffler head bolt washer.....	1921-26	doz. 50

Part No.	Name of Part	Year	Each
----------	--------------	------	------

MUFFLER—Continued

4037C...	Long exhaust pipe.....	1920-26	\$1 40
4040D...	Muffler head—rear.....	1921-26	20
4041B...	Muffler head to frame bolt and nut (Order 3074 and 2515).....	1921-26	



HOOD

4050B...	Hood.....	1917-23	6 00
4050C...	Hood.....	1923-25	6 00
4050D...	Hood (black).....	1926	6 00
4050D2...	Hood (black pyroxylin).....	1926	8 00
4050E...	Hood (Specify Channel green, Drake green, Highland green, Windsor maroon, Royal maroon, Moleskin, Gunmetal blue, Phoenix brown or Fawn gray).....	1926	8 00
4051...	Hood handle.....	1909-26	05
4052B...	Hood clip.....	1917-26	10
4053B...	Hood clip spring.....	1917-26	02
4054...	Hood corner pad.....	1926	02
4056B...	Hood block—lft.....	1917-23	30
4056C...	Hood block—lft.....	1923-25	30
4056D...	Hood block—left.....	1926	40
4057B...	Hood block—right.....	1917-23	30
4057C...	Hood block—right.....	1923-25	30
4057D...	Hood block—right.....	1926	40
4060C...	Hood pad (on dash).....	1917-22	08
4060D...	Hood pad (on rad. shell).....	1917-26	15
4060E...	Hood pad (on dash).....	1923-25	08
4060F...	Hood pad (on dash).....	1926	10
4061C...	Hood clasp (on dash).....	1917-23	02
4861D...	Hood clasp (on dash) screw.....	1920-23	05
4061E...	Hood clasp (on dash).....	1923	05
4061F...	Hood clasp (on dash).....	1923-25	05
4073...	Hood block support—front—R.....	1917-23	10
4073B...	Hood block support—front—R.....	1923-25	10
4073C...	Hood block support—front—R.....	1926	15
4074...	Hood block support—front—L.....	1917-23	10
4074B...	Hood block support—front—L.....	1923-25	10
4074C...	Hood block support—front—L.....	1926	15
4075...	Hood block support—rear—R.....	1917-23	10
4075B...	Hood block support—rear—R.....	1923-25	10
4975C...	Hood block support—rear—R.....	1926	05
4076...	Hood block support—rear—L.....	1917-23	10
4076B...	Hood block support—rear—L.....	1923-25	10
4076C...	Hood block support—rear—L.....	1926	05
4077...	Hood block support bracket—rear.....	1926	20

Insist upon genuine Ford parts

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

CARBURETOR

FORD CARBURETOR (Model "NH")			
46200C...	Carburetor.....	1926	\$3 00
6201	Float with lever.....	1920-26	25
6213	Spray needle assembly.....	1920-25	15
6213B...	Carb. spray needle assembly.....	1926	30
KINGSTON CARBURETOR (Model "L-4")			
*6150B...	Carburetor.....	1926	3 00
6155	Float with lever.....	1921-26	40
6161	Spray needle assembly.....	1921-25	40
6161B...	Spray needle assembly.....	1926	45
6175	Gasoline valve.....	1921-26	30

VAPORIZER

6250	Vaporizer assembly—with fittings.....	1926	9 00
	Float and lever assy (Order 6201).....	1926	
6286	Spray nozzle.....	1926	20
6297	Steering post throttle lever.....	1926	15
6297B...	Steering post throttle lever bolt.....	1926	03
6297C...	Steering post throttle lever bolt nut.....	1926	02
6298	Vaporizer pull rod, all cars, 1925, TT chassis 1926.....	1926	10
6299	Vaporizer pull rod, Road.—T. C.— Cp.—Tudor.....	1926	10
6300	Vaporizer pull rod, Fordor—T. Chassis.....	1925	10
6302	Choke rod.....	1926	05
6303	Adjusting rod collar.....	1926	05
6304	Adjusting rod collar set screw.....	1926	02



CARBURETOR ATTACHMENTS

4129A...	Carburetor adjusting rod.....	1909-25	10
4129B...	Carburetor adj. rod and knob assy.—23 1/16" T.C., Road., Open Cab.....	1925	25
4129C...	Carburetor adj. rod and knob assy.—25 1/16" Cp., Tudor, Fordor.....	1925	25
4129D...	Carburetor adj. rod and knob assy.—15 5/8" T and TT Chassis.....	1926	20
4129E...	Carburetor adj. rod and knob assy.—27 3/8" Closed Cab.....	1926	25
4129F...	Carburetor adj. rod and knob assy.—Cp.—Tudor.....	1926	25

‡When used on cars without instrument board adjustment replace spray needle and adj. nut with 6213 and 6208.

*When used on cars without instrument board adjustment replace spray needle with 6161.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

CARBURETOR ATTACHMENTS—Continued

4129G...	Carburetor adj. rod and knob assy.—Road.—T. C.—Fordor.....	1926	\$0 25
4129H...	Vaporizer adj. rod—Cp.—Tudor—Closed Cab.....	1926	25
4129I...	Vaporizer adj. rod—Road.—T. C.—Fordor.....	1926	25
4129J...	Vaporizer adj. rod and knob assy.—Cp.—Tudor—Fordor.....	1925	25
4129K...	Vaporizer adj. rod and knob assy.—Road.—T. C. Vaporizer adj. rod, Open Cab, (Order 4129G).....	1925	25
	Vaporizer adj. rod, T. and TT chassis (Order 4129D).....	1926	
4130	Carburetor flange bolt (Order 3072).....	1909-26	
4130B...	Carburetor flange bolt nut (Order 3066B).....	1909-26	
4131	Carburetor adj. rod sleeve.....	1926	10
4132	Carburetor univ. joint spider.....	1926	05
4134	Carburetor flange gasket.....	1909-26	05
4431	Carburetor priming rod.....	1909-26	05
4431B	Vaporizer priming rod.....	1926	05
4582	Carburetor hot air pipe.....	1912-25	20
4582B...	Carburetor hot air pipe.....	1925-26	20
4583	Priming bell crank.....	1919-25	10
4588D...	Priming rod—13 1/8".....	1923-25	15
4588E...	Priming rod—17 1/8".....	1923-25	15
*4588F...	Priming rod—16 1/8".....	1923-25	15
4589	Priming rod—20 1/2".....	1919-25	05
4589B...	Priming rod—14 1/2".....	1922-25	05
4589C...	Choke lever rod—7 1/2".....	1925	02
4589D...	Choke lever rod—7 1/4".....	1926	02
4590	Priming rod bumper.....	1926	01
4591	Priming rod lift.....	1926	05
4592	Choke lever rod—8 3/8" T & TT chassis.....	1925	02
4592B...	Choke lever rod—8 1/4" T & TT chassis.....	1926	02

FENDERS

4800B...	Front fender—right.....	1917-23	4 00
4800C...	Front fender—right.....	1923-25	4 00
4800D...	Front fender—right.....	1926	5 00
4801B...	Front fender—left.....	1917-23	4 00
4801C...	Front fender—left.....	1923-25	4 00
4801D...	Front fender—left.....	1926	5 00
4802F...	Rear fender—right.....	1917-25	3 50
*4802G...	Rear fender—right.....	1922-25	3 75
†4802H...	Rear fender—right.....	1923-25	4 00
4802J...	Rear fender—Right—T. C.—Tudor—Fordor.....	1926	4 00
4802K...	Rear fender—Right—Road—Cp.....	1926	4 00
4803F...	Rear fender—left.....	1917-25	3 50

‡For Fordor and Tudor. †Used with steel dash.

*For Coupe.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

FENDERS—Continued

FENDERS—Continued			
*4803C...	Rear fender—left.....	1922-25	\$3 75
†4803H...	Rear fender—left.....	1923-25	4 00
4803J...	Rear fender—left—T. C.—Tudor—Fordor.....	1926	4 00
4803K...	Rear fender—left—Road.—Op.....	1926	4 00

FENDER IRONS

4804D...	Rear fender iron—R. & L.—T.C.	1913-25	20
4804E...	Rear fender iron—right—Cp. & Rbt.....	1913-23	60
4804F...	Rear fender iron—left—Cp. & Rbt.....	1913-23	60
4804K...	Fender iron—R. or L.—Sedan.....	1918-25	15
4804L...	Rear fender iron—T. C.....	1921-25	10
4804M...	Rear fender iron—right.....	1923-25	60
4804N...	Rear fender iron—left.....	1923-25	60
4809...	Front fender iron—right or left.....	1909-25	60

FENDER BOLTS, NUTS AND BRACKETS

4805B...	Rear fender iron bolt.....	1915-25	03
4805C...	Rear fender iron bolt nut.....	1915-25	02
4806B...	Fender eye bolt.....	1909-25	05
4806C...	Fender eye bolt washer.....	1909-25	01
4806D...	Fender eye bolt nut (Order 2825B)	1909-25	05
4808...	Front fender iron bolt (side).....	1910-25	03
4808B...	Front fender iron bolt (bottom) (Order 3362).....	1910-25	03
4808C...	Front fender apron to frame bolt.....	1915-25	03
4808D...	Front fender iron bolt nut (Order 2515).....	1910-25	
4808E...	Front fender apron to frame bolt nut (Order 3088E).....	1915-25	

RUNNING BOARD AND SHIELDS

4812...	Running board—R.....	1909-25	1 25
4813...	Running board—L.....	1909-25	1 25
4813B...	Running board.....	1926	1 50
4814C...	Running board shield—R.....	1917-25	2 40
*4814D...	Running board shield—R.....	1922-24	2 40
*4814E...	Running board shield—R.....	1924-25	2 40
4814F...	Running board shield—R.....	1926	2 75
4815C...	Running board shield—L.....	1917-25	2 40
*4815D...	Running board shield—L.....	1922-24	2 40
*4815E...	Running board shield—L.....	1924-25	2 40
4815F...	Running board shield—L.....	1926	2 75
4816...	R. B. truss rod—front with nuts.....	1909-21	35
4817...	R. B. truss rod—rear with nuts.....	1909-21	35
4817B...	Truss rod nut.....	1909-21	03
4818B...	Running board bracket assy.....	1921-26	1 00
4819B...	Running board to rear fender bolt.....	1921-26	03


FORD SPARK COIL

5000...	Coil (includes switch).....	1909-22	8 50
5001...	Coil.....	1909-25	7 75
5001B...	Coil.....	1926	7 75
5001C...	Coil box bracket—right.....	1926	10

*For Fordor and Tudor.
†For Coupe.


Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------



FORD SPARK COIL—Continued

5001D...	Coil box bracket—left.....	1926	\$0 10
5003...	Coil box with cover.....	1919-25	1 75
5003B...	Coil box with cover.....	1926	1 75
5004...	Coil box cover.....	1915-25	25
5004B...	Coil box cover.....	1926	50
5004C...	Coil box cover gasket.....	1926	10
5006...	Switch plug.....	1914-22	05
5007...	Coil unit.....	1914-26	1 50
5008...	Vibrator.....	1914-26	05
5008B...	Vibrator and lower bridge assy.....	1924-26	06
5009...	Vibrator bridge.....	1914-26	08



SWITCH

5010...	Switch assembly (on coil).....	1914-22	75
5012...	Ignition switch (on instrument board).....	1919-25	75
*5012B...	Ignition switch.....	1926	75
‡5012C...	Ignition switch.....	1926	75
5013B...	Switch key—give serial number.....	1919-25	10
5014...	Starting switch (on floor board).....	1919-26	50
5014B...	Starting switch bracket bolt—long.....	1920-25	03
5015...	Starting switch plunger extension.....	1919-25	10



*Cars with starter. ‡Cars without starter.

Insist upon genuine Ford parts

Part No. Name of Part Year Each

AMMETER

5016B...	Ammeter.....	1926	\$0 75
5017...	Ammeter lens and rim.....	1919-25	20
5017B...	Ammeter lens.....	1919-25	05
5017C...	Ammeter lens.....	1926	05
5017C2...	Ammeter lens.....	1926	05
5017D...	Ammeter adapter plate.....	1926	15

STARTER DRIVE

5018...	Starter drive.....	1919-26	4 00
5019...	Starter drive head.....	1919-26	50
5020...	Starter drive key.....	1919-26	02
5021...	Starter drive shaft and gear.....	1919-26	3 50
5022...	Starter drive spring.....	1919-26	30
5023...	Starter drive shaft spring screw.....	1919-26	03
5024...	Starter drive head spring screw.....	1919-26	05
5025...	St. drive spring screw lock washer.....	1919-26	01

WIRING

5026...	Spark plug wire 14 3/8".....	1909-25	10
5027...	Spark plug wire (also magneto to coil) 10 1/2".....	1909-25	10
5028...	Spark plug wire 7".....	1909-25	10
5029...	Spark plug wire 7 1/4".....	1926	10
5029B...	Spark plug wire 5 1/2".....	1926	10
5030...	Commutator wire.....	1909-22	80
†5030B...	Commutator wire.....	1922-26	1 00
†5031...	Commutator wire (starter type).....	1919-26	1 10
5031B...	Commutator wire.....	1926	50
5033B...	Commutator wire term. retainer.....	1921-26	01
5033C...	Commutator wire clip.....	1919-26	01
5035...	Ammeter to cutout wire—Sedan 49".....	1919-25	20
5037...	Ammeter to cutout wire—Coupe 41".....	1919-25	15
5038...	Ammeter to ignition switch wire.....	1919-25	10
5038B...	Ammeter to ignition switch wire.....	1926	10
5040...	Terminal block to switch wire.....	1919-25	10
5040B...	Terminal block to horn switch wire.....	1926	10
**5041...	Lighting wire.....	1919-25	90
**5041B...	Lighting wire—Truck.....	1921-26	1 00
*5041C...	Lighting wire.....	1922-25	50
*5041D...	Lighting wire.....	1926	65
5041E...	Lighting wire.....	1926	1 50
5042...	Switch wire—Sedan.....	1919-25	75
5042B...	Switch wire—Road.—T. G.—Cp.—Tudor.....	1926	75
*5043...	Switch wire.....	1919-25	70
5043B...	Switch wire.....	1922-25	40
*5043C...	Switch wire.....	1926	45
5043D...	Switch wire—Fordor—Com. Chassis.....	1926	75
5044...	Terminal block.....	1919-22	10


*Used on cars without starter, with switch on instrument panel. **When used with old style tail lamp, remove terminal from end of tail lamp wire. †Used in 1926 on truck only.

Insist upon genuine Ford parts

Part No. Name of Part Year Each

WIRING—Continued

5044C...	Terminal block.....	1922	\$0 10
5044E...	Terminal block with screws.....	1923-26	10
5044F...	Terminal block with screws.....	1923-26	10
5046...	Battery to switch cable—28 1/4".....	1919-26	80
5046C...	Battery to switch cable—Truck.....	1921-26	80
5047B...	Battery to switch cable support—Truck.....	1920-26	10
5047C...	Battery to switch cable support.....	1920-26	10



*Used on cars without starter, with switch on instrument panel. †Used with steel dash.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
WIRING—Continued			
5047D...	Battery to switch cable sup. bush.	1920-26	\$3 05
5047E...	Battery to switch cable sleeve.	1921-26	05
5049B...	Ground connector.	1919-26	30
5051...	Switch to motor cable.	1919-25	50
5051B...	Switch to motor cable sleeve.	1921-26	30
5052...	Battery cable terminal bolt.	1919-26	02
5052B...	Battery cable terminal bolt nut.	1919-26	01

STARTER PARTS


5056...	Motor mounting gasket.	1919-26	02
5057...	Gen. head gasket.	1919-26	02
5058...	Gen. mounting short screw.	1919-26	03
5059...	Bendix cover screw.	1919-26	61
5060...	Term. block to wire screw (Order 5114)	1919-26	
5061...	Ammeter to plate screw.	1919-26	01
5062...	Motor mounting screw.	1919-26	02

STARTING MOTOR AND PARTS

5099...	Starting motor.	1919-26	12 50
5101...	Cover band.	1919-26	10

GENERATOR AND PARTS

5055...	Cut-out (electric)	1919-26	1 00
5119...	Generator	1919-26	12 50



BATTERY BRACKET AND PARTS

5150...	Bracket assembly.	1919-23	75
*5150B...	Battery bracket assembly.	1923-26	75
5151...	Clamp bolt.	1919-26	03
5151B...	Clamp bolt nut (Order 2825B)	1919-26	
5152...	Clamp.	1919-23	05
*5152B...	Battery clamp.	1921-26	05
5153...	Battery support angle—truck.	1921-26	15
5154...	Battery box support—truck.	1921-26	20
5155...	Battery clamp support—rear—truck.	1921-26	20
5156...	Battery clamp support—front—truck.	1921-26	20
5158...	Battery box—less cover.	1921-26	75
5159...	Battery box cover assembly.	1921-26	60
5160...	Battery box cover door.	1921-26	10

Also for generator.

*Used with steel battery box or rubber case battery.

Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
BATTERY (FORD)			
5175...	Battery.	1919-26	\$15 00
5184...	Filler plug with gasket.	1919-22	15
5184B...	Filler plug with gasket.	1921-23	15
5184C...	Filler plug.	1923-26	10
SPARK PLUGS			
5201...	Spark plug "Ford" (Champion)	1909-26	60
5203B...	Spark plug porcelain "Ford" (Champion)	1909-26	30

REPAIR TOOLS

1349...	Hub cap wrench.		15
1387B...	Adjustable wrench.		40
1903...	Pliers.		25
1917...	Double end wrench.		15
2335...	Spark plug and cylinder head bolt wrench.		40
2336...	Tool roll.		20
2337...	Cil can.		20
2338...	Tire pump.		1 00
2340...	Tire irons, each.		15
2343...	Jack (including handle).		1 00
2344...	Jack handle.		15

REPAIR TOOLS—TRUCK

TT3389X...	Jack (including handle).		1 75
TT3391X...	Jack handle.		20
TT4069...	Tire iron (large).		40
TT5893X...	Spark plug, rim nut and cylinder head bolt wrench.		35



FORD SPECIALTIES

3144SX...	Bumper (front) assy., with fittings.		7 50
3145SX...	Bumper (rear) assy., with fittings, Road.		7 50
3146SX...	Bumper (rear) assy., with fittings, Co.		7 50
3147BSX...	Bumper (rear) assy., with fittings, Tudor, T. C.		7 50
3148SX...	Bumper (rear) assy., with fittings, Fordor		7 50
5773X...	Cap (dash lamp).		10
7962ARX...	Kit (Tire repair).		25
5761X...	Lamp (dash).		60
3180SX...	Lamp (stop and tail) with switch and wiring.		2 50
18259X...	Mirror (rear view) assy.—closed cars.		75
7853X...	Mirror (rear view) assy.—open cars.		75

Insist upon genuine Ford parts


Part No. Name of Part Year Each

FORD SPECIALTIES—Continued

18253X..	Mirror (rear view) only.....		\$0 40
17343X..	Nut (windshield wiper).....		02
3251BRX..	Wing (W. S.) assy.—R.....		3 25
3252BRX..	Wing (W. S.) assy.—L.....		3 25
50229X..	Wiper (windshield).....		50
18257X..	Wiper (windshield).....		50
3318SX..	Wiper (automatic W. S.)—closed cars.....		3 50
3320SX..	Wiper (automatic W. S.)—open cars.....		3 50


FORD PAINTS AND POLISHES

M-255F..	Dressing (top) 1 pt.....		65
M-165..	Enamel (black) air-dry—1 qt.....		1 00
M-392..	Enamel (channel green) air-dry—1 qt.....		1 25
M-393..	Enamel (Windsor maroon) air-dry—1 qt.....		1 75
M-230..	Polish (body) 12 oz. bottle.....		75
M-216..	Polish (nickel) 1 lb.....		50
M-111..	Touch-up (black) 1/2 pt.....		1 00



ELECTRIC HORN

6437DX..	Bracket (horn).....		10
6432DX..	Horn—battery type.....		1 50
6432EX..	Horn—magneto type.....		1 50
8028X..	Switch (horn) assembly.....		30
7917BX..	Wire (electric horn to switch)—35 3/8".....		10
7917CX..	Wire (horn to switch).....		10



ELECTRIC HEADLAMPS

6572AX..	Bulb (headlamp) 9 volt—18 c. p.—double contact—used with magneto without dimmer.....	1915-18	30
----------	--	---------	----

§Closed cars 1924-25—Open cars 1924-26. ‡Closed cars 1926.

Insist upon genuine Ford parts

Part No. Name of Part Year Each

ELECTRIC HEADLAMPS—Continued

6572HX..	Bulb (headlamp) 6-8 volt—bright, 21 c. p., dim. 1 3/4 c. p.—double contact—double filament—used with T6576HX lens.....	1922-26	\$0 40
6572KX..	Bulb (headlamp) 6-8 volt—21 c. p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens.....		35
3178X..	Bulb (stop lamp) 6 volt—21 c. p. single contact (also for headlamps for Lincolns and other cars using single contact 6 volt bulb).....		35
6594HX..	Door assembly with refracting lens.....		65
6594JX..	Door (head lamp) assy.—nickel.....		1 00
6575BX..	Door (less lens) nickel.....		75
6578X..	Gasket (door lens).....		03
6511HX..	Headlamp assembly.....	pr.	5 50
†6511KX..	Headlamp assembly.....	pr.	5 50
6511MX..	Headlamp assembly—R. or L. 1926 pr.....		5 00
†6511NX..	Headlamp assembly—R. or L. 1926 pr.....		5 00
†6501ARX..	Headlamp assembly R.....		3 25
6501CRX..	Headlamp assembly R.....		3 25
6576HX..	Lens (headlamp) refracting—in carton—pair.....		50
6518X..	Nut (headlamp swivel bolt).....	1926	02
6592X..	Plug—with thimble.....		10
6590AX..	Reflector assembly.....		75
6517X..	Rod (headlamp tie) and bracket assy.....	1926	75
6580X..	Screw (focusing).....		03
6574X..	Socket (bulb).....		15
6574BX..	Socket (headlamp plug).....		15
6591X..	Spring (focusing screw).....		01
6586X..	Spring (reflector).....		05
6589X..	Switch assembly—with screws.....		30
8650X..	Switch (headlamp and horn) assembly.....		40
6509X..	Washer (headlamp bracket—conical).....		02
7489X..	Wire (lamp to lamp) 40".....		10

SIDE AND TAIL LAMPS

6520X..	Bulb (tail lamp and headlamp dimmer) 6-8 volt—3 c. p.—single contact.....		20
6957X..	Door (tail lamp).....		50
6957BX..	Door (tail lamp).....		50
7609X..	Lamp (electric tail) assembly.....		90
8786CX..	Lamp (electric tail) and license bracket assy.—incl. lamp.....		90
6484BX..	Lens (electric tail lamp) red.....		15
6484CX..	Lens (electric tail lamp) red—celluloid.....	1923-25	03
6484DX..	Lens (electric tail lamp) side—red.....		10

†Cars without starter.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

SIDE AND TAIL LAMPS—Continued

6405CX	Lens (electric tail lamp) white		\$0 15
T1882X	Wire (tail lamp to ground) assembly		15
6392X	Wick (lamp)		05

TOURING CAR AND ROADSTER WINDSHIELDS

—1915-22

7828X	Glass (windshield) lower	1915-22	3 00
7827AX	Glass (windshield) upper	1915-22	2 55
7840ARX	Windshield assembly		10 00

TOURING CAR AND ROADSTER WINDSHIELDS

—1922-25

9066X	Channel (windshield) center	1922-25	35
9534X	Glass (windshield) lower	1922-25	2 55
7827BX	Glass (windshield) upper	1922-25	2 35
7840BX	Windshield assembly	1922-25	10 00
7823BX	Windshield assembly—lower half	1922-25	4 00
7822CX	Windshield assembly—upper half	1922-25	4 10

TOURING CAR AND ROADSTER WINDSHIELDS

—1926

40324X	Channel (windshield) center		35
40308	Glass (windshield) lower	1926	2 30
40323	Glass (windshield) upper	1926	2 55
40328	Windshield assembly—lower	1926	4 15
40327	Windshield assembly—upper	1926	4 10
40300	Windshield assembly	1926	11 00

TOURING CAR TOPS—1915-22

6883ARX	Curtain (touring car storm) R	1913-22	1 75
6882ARX	Curtain (touring car storm) L	1913-22	1 75
6940ARX	Curtain (back) and stay assy.	1915-22	3 00
4966BRX	Curtain (touring car side) right	1915-22	2 00
4967BRX	Curtain (touring car side) left	1915-22	2 00
7940ARX	Top (touring car) complete	1915-22	27 00

TOURING CAR TOPS—1922-25

6882BX	Curtain (front side) assembly—right	1922-25	1 75
6883BX	Curtain (front side) assembly—left	1922-25	1 85
6940CX	Curtain (rear) assembly	1922-25	2 50
4966DX	Curtain (rear side) assembly—right	1922-25	1 75
4967DX	Curtain (rear side) assembly—left	1922-25	1 75
7940BX	Top assembly	1922-25	27 00

TOURING CAR TOPS—1926

*41100ARX	Curtain (front side) assembly—R	2 25
*41100BX	Curtain (front side) assembly—L	2 25
*41101ARX	Curtain (front side) assembly—R	2 25
*41101BX	Curtain (front side) assembly—L	2 25
*41102ARX	Curtain (center side) assembly—R	2 25

*Also used on 1926 Roadster Top.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

TOURING CAR TOPS—1926—Continued

41102BX	Curtain (center side) assembly—R		\$2 25
41103ARX	Curtain (center side) assembly—L		2 25
41103BX	Curtain (center side) assembly—R		2 25
41104ARX	Curtain (rear side) assembly—R		1 00
41104BX	Curtain (rear side) assembly—L		1 00
41105ARX	Curtain (rear side) assembly—L		1 00
41105BX	Curtain (rear side) assembly—L		1 00
41106X	Curtain (back) assembly		3 00
*41045X	Rod (curtain) front—right		20
*41046X	Rod (curtain) front—left		20
41047X	Rod (curtain) rear—right		20
41048X	Rod (curtain) rear—left		20
41011X	Top assembly		27 00

ROADSTER TOP PARTS—1915-22

6937AX	Curtain (side) rear—right	1915-22	1 25
6938AX	Curtain (side) rear—left	1915-22	1 25
6935AX	Curtain (side) front—right	1915-22	1 50
6936AX	Curtain (side) front—left	1915-22	1 50
6950AX	Curtain (back) assembly	1915-22	2 40
7941ARX	Top complete	1915-22	22 00

ROADSTER TOPS—1922-25

6935BX	Curtain (front side) assembly—right	1922-25	1 25
6936BX	Curtain (front side) assembly—left	1922-25	1 35
6937BX	Curtain (rear side) assembly—right	1922-25	90
6938CX	Curtain (rear side) assembly—left	1922-25	90
6950BX	Curtain (rear) assembly	1922-25	2 50
7941BX	Top assembly	1922-25	22 00

†ROADSTER TOPS—1926


41067ARX	Curtain (rear side) assembly—right	1 00
41067BX	Curtain (rear side) assembly—right	1 00
41068ARX	Curtain (rear side) assembly—left	1 00
41068BX	Curtain (rear side) assembly—left	1 00
41069X	Curtain (back) assembly	2 50
41049X	Top assembly	22 00

†For additional 1926 Roadster Top parts see 1926 Touring Car Top parts marked with an asterisk (*).

*Also used on 1926 Roadster Top.

Insist upon genuine Ford parts

Part No. Name of Part Year Each



Price List of Parts for Model T One-Ton Truck

REAR AXLE


1000	... Axle assembly—rear	1918-26	\$110 00
1001	... Axle housing—right	1918-26	15 00
1002	... Axle housing—left	1918-26	15 00
1003	... Axle housing bolt	1918-26	05
1003B	... Axle housing bolt nut (Order 2719)	1918-26	
1004	... Axle housing cap	1918-26	40
1005	... Axle housing cap gasket	1918-26	02
1006	... Axle housing cap screw	1918-26	05
1008	... Axle housing gasket—upper	1918-26	02
1009	... Axle housing gasket—lower	1918-26	05
1010	... Axle brake housing plate—right	1918-26	35
1011	... Axle brake housing plate—left	1919-26	35
1012	... Axle housing drain plug	1918-26	05
1013	... Axle shaft	1918-26	4 00
1014	... Axle shaft cotter	1918-26	doz. 05
1015	... Axle shaft nut	1918-26	10
1016	... Axle shaft washer	1918-26	05
1017	... Axle shaft dust cap	1918-26	03
1018	... Axle shaft inner ball bearing assembly	1918-26	5 00
1019	... Axle shaft outer roller bear.	1918-26	1 00
1020	... Axle shaft outer R. B. sleeve—R.	1918-26	35
1020B	... Axle shaft outer R. B. sleeve—L.	1918-26	35
1021	... Axle shaft bearing felt	1918-26	15

Insist upon genuine Ford parts

Part No. Name of Part Year Each

REAR AXLE—Continued

1022	... Axle shaft bearing retainer	1918-26	\$0 05
1023	... Axle shaft bearing retainer washer	1918-26	02
1024	... Axle shaft felt retainer assy.	1918-26	20
1025	... Axle shaft felt retainer cup	1918-26	03
1026	... Axle shaft felt retainer plate	1918-26	03
1026B	... Rear axle oil retainer	1926	25
1027	... Differential gear	1918-26	1 25
1028B	... Differential gear case—R. or L. half	1923-26	2 50
1029	... Differential gear case bolt (Order 1003)	1918-26	
1031	... Differential gear lock ring	1918-26	02
1032	... Differential pinion	1918-26	50
1033	... Differential pinion shaft	1918-23	30
1033B	... Differential spider	1923-26	1 50



DRIVE SHAFT


1034	... Drive shaft	1918-26	7 00
1036	... D. S. tube assembly	1918-26	10 00
1037	... D. S. tube flange gasket	1918-26	02
1038	... D. S. tube flange screw (Order 1006)	1918-26	
1039	... D. S. felt	1918-26	16
1040	... D. S. felt container	1918-26	03
1041B	... D. S. to worm coupling	1920-26	70
1042	... D. S. to worm coupling pin	1918-26	01

WORM

1043	... Worm—7 3/4 to 1	1918-26	6 00
1043B	... Worm—5 1/2 to 1	1918-26	6 00
1044	... Worm gear—7 3/4 to 1	1918-26	10 00
1044B	... Worm gear—5 1/2 to 1	1918-26	10 00
1045	... Worm cotter (Order 1014)	1918-26	
1046	... Worm roller bearing	1918-26	75
1047	... Worm roller bearing retainer (Order 1023)	1918-26	
1048	... Worm roller bearing sleeve	1918-26	1 00
1049	... Worm roller bear. housing screw	1918-26	03
1050	... Worm thrust bearing collar	1918-26	50
1051	... Worm thrust ball and sep. assy.	1918-26	60
1053	... Worm thrust bear. retainer	1918-26	15

Insist upon genuine Ford parts


Part No. Name of Part Year Each



REAR AXLE—Continued

WORM—Continued

- 1054... Worm thrust bear, retainer nut (Order 1015).....1918-26
 - 1055... Worm thrust bear, retainer pin.....1918-26
- \$0 01



BRAKE PARTS


- 1056... Brake shoe.....1918-26
 - 1057... Brake shoe lining, each.....1918-26
 - 1058... Brake shoe lining rivet.....1918-26
 - 1059... Brake shoe spring.....1918-26
 - 1060... Brake shoe bolt.....1918-26
 - 1060B... Brake shoe bolt nut (Order 2507).....1918-26
 - 1061... Brake expander.....1918-26
 - 1062... Brake expander lever.....1918-26
 - 1064... Brake expander adj. collar.....1918-26
 - 1065... Brake expander bushing.....1918-26
 - 1066... Brake expander pin.....1918-26
 - 1067... Brake expander link.....1918-25
 - 1068... Brake expander link pin.....1918-26
 - 1069... Brake rod.....1918-26
 - 1070... Brake rod support—right.....1918-26
 - 1071... Brake rod support—left.....1918-26
 - 1072... Brake rod support bolt.....1918-25
 - 1072B... Brake rod support bolt nut (Order 3088E).....1918-26
- 1 50
25
01
05
10
40
15
15
10
10
08
03
30
10
10
10
02

Part No. Name of Part Year Each

REAR AXLE—Continued

RADIUS ROD

- 1073... Rear radius rod—right.....1918-26
 - 1073B... Rear radius rod—left.....1918-26
 - 1074... Rear radius rod bolt—front.....1918-26
 - 1075... Rear radius rod bolt—rear.....1918-26
 - 1075B... Rear radius rod bolt nut (Order 2507).....1918-26
 - 1076... Universal joint bushing.....1918-26
- \$3 00
3 00
10
10
10
60



SPRINGS

REAR SPRING

- 1077... Rear spring—right or left, each.....1918-26
 - 1087... Spring bushing.....1918-26
 - 1388... Spring clip.....1918-26
 - 1389... Spring clip nut.....1918-26
 - 1391... Spring clip plate.....1918-26
 - 1092... Spring tie bolt.....1918-26
 - 1093... Spring tie bolt nut (Order 1089).....1918-26
 - 1094... Spring tie bolt cotter.....1918-26
 - 1095... Spring clamp.....1918-26
 - 1096... Spring clamp bolt.....1918-26
 - 1096B... Spring clamp bolt nut (Order 3514).....1918-26
 - 1097... Spring perch.....1918-26
 - 1098... Spring perch nut (Order 1015).....1918-26
 - 1099... Spring perch cotter (Order 1014).....1918-26
 - 1100... Spring perch bushing.....1918-26
 - 1101... Spring perch bush, spacer.....1918-26
 - 1102... Spring hanger assembly.....1918-26
- 4 00
20
45
05
20
15
10
doz.
10
03
90
35
10
30


FRONT SPRING (Nine-leaf)

- 1151... Front spring.....1926
 - 1161... Front spring tie bolt.....1926
 - 1162... Front spring tie bolt nut (Order 3811B).....1925
 - 1164B... C. C. front bearing and spring clip assembly.....1926
 - 1165... Front spring clip bar.....1926
 - 1166... C. C. front bearing and spring clip nut (Order 2507).....1926
- 3 00
05
90
25

Insist upon genuine Ford parts

Insist upon genuine Ford parts

Part No. Name of Part Year Each


**WHEELS**

1105B..	Rear wheel—dem.—Kelsey	1919-24	\$15 00
1105C..	Rear wheel—dem.—Hayes	1919-24	15 00
1105D..	Rear wheel—dem.—less rim and hub—Kelsey	1919-24	6 50
1105E..	Rear wheel—dem.—less rim and hub—Hayes	1919-24	6 50
†1105H..	Rear wheel complete—dem.	1924-26	14 75
†1105J..	Rear wheel—less rim	1924-26	10 75
†1105K..	Rear wheel—less rim and hub	1924-26	6 50
1106C..	Dem. rim only—Hayes	1919-26	3 50
1106D..	Dem. rim only—Kelsey	1922-26	3 50
1106E..	Dem. rim retainer ring— Kelsey	1922-26	45
†1106F..	Dem. rim and flange assy.	1924-26	2 75
†1106G..	Dem. rim flange	1924-26	90
1107B..	Clamp and nut assy.—Kel- sey	1919-26	15
†1107C..	Clamp	1924-26	10
1108B..	Clamp bolt	1919-24	05
†1108C..	Clamp bolt	1924-26	05
†1108D..	Clamp nut	1924-26	05
1109..	Rear wheel complete—solid tire design—less tire	1918-26	17 50
1109B..	Rear wheel—solid tire de- sign—less hub and tire	1919-26	13 25
1111..	Rear hub	1918-26	2 25
1112..	Rear hub flange	1918-26	40
1113..	Rear hub brake drum	1918-26	1 25
1114..	Rear hub bolt	1918-26	05
1114B..	Rear hub bolt nut	1918-25	02
1116..	Rear hub cap	1918-26	25
1117..	Rear hub key	1918-26	03
1118..	Rear hub felt	1918-26	10

†30" x 5" Wheel.

Insist upon genuine Ford parts

Part No. Name of Part Year Each

**FRAME**

1119..	Frame assembly	1918-26	\$25 00
1120..	Side member—right	1918-26	9 00
1121..	Side member—left	1918-26	9 00
1122..	Front cross member	1918-26	1 00
1123..	Rear cross member	1918-26	4 00

TRANSMISSION CONTROL

1133..	Speed lever	1918-26	10
1134..	Control shaft with speed lever	1918-26	60

Insist upon genuine Ford parts

100
Genuine Ford parts may be ordered by mail, for shipment by parcel post, express, or freight, from the authorized Ford dealer whose name appears on the front cover of this list.

Order parts by part number and name, specifying how shipment is to be made.

All mail orders should be accompanied by remittance in the form of a money order to cover the price of the goods. If shipment is to be made by parcel post, include in your remittance a sufficient amount to cover postage.